

Crivit SBL 4 A2

Crivit Silvercrest Bluetooth Speaker SBL 4 A2 User Manual

Model: SBL 4 A2

1. INTRODUCTION

Thank you for choosing the Crivit Silvercrest Bluetooth Speaker SBL 4 A2. This portable speaker is designed for wireless music streaming, offering high-quality audio and convenience. It features a powerful 2200 mAh Li-ion battery, providing up to 16 hours of music playback, and a 4-level LED display to indicate battery status. With Bluetooth v5.0, it ensures stable connectivity up to 10 meters.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Crivit Silvercrest Bluetooth Speaker SBL 4 A2
- USB-A to USB-C charging cable
- 3.5 mm audio cable

3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Figure 3.1: Top View with Controls

This image shows the top surface of the Crivit Silvercrest Bluetooth Speaker, highlighting the control buttons. From left to right, these typically include: Power On/Off, Previous Track/Volume Down, Play/Pause, Next Track/Volume Up, and Mode (for switching between Bluetooth and AUX input).



Figure 3.2: Rear View with Ports and Indicators

This image displays the rear panel of the speaker, revealing the connectivity ports and battery status indicators. Visible elements include a 3.5mm AUX input jack, a USB-C charging port, and a row of four LED lights indicating the battery charge level.



Figure 3.3: Speaker in Use with a Smartphone

This image shows the Crivit Silvercrest Bluetooth Speaker positioned on a white surface next to a smartphone, illustrating its portable size and typical use case for wireless audio playback from a mobile device.

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB-A to USB-C charging cable to connect the speaker's USB-C port to a USB power source (e.g., computer USB port, USB wall adapter). The 4-level LED battery display on the rear will indicate the charging progress. All four LEDs will illuminate when fully charged.

4.2. Powering On/Off

To turn the speaker **ON**, press and hold the **Power button** (usually the leftmost button on the top panel) for a few seconds until you hear an audible prompt or see an indicator light. To turn the speaker **OFF**, press and hold the **Power button** again until it powers down.

5. OPERATING THE SPEAKER

5.1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. If it's not automatically in pairing mode, press the **Mode button** (if available) or the **Bluetooth button** (if dedicated) to switch to Bluetooth mode. The Bluetooth indicator light will typically flash rapidly.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.

3. Search for available devices. The speaker should appear as "SBL 4 A2" or similar.
4. Select the speaker from the list to pair. Once successfully paired, you will hear a confirmation sound, and the Bluetooth indicator light will stop flashing and remain solid.
5. The speaker supports Bluetooth v5.0 and has a range of up to 10 meters. Ensure your device is within this range for optimal connection.

5.2. Audio Playback

Once paired via Bluetooth, you can stream music wirelessly from your device. Alternatively, you can use the provided 3.5 mm audio cable to connect the speaker to any device with a 3.5 mm audio output jack (e.g., MP3 player, computer) via the AUX input port on the speaker's rear.

5.3. Controls

- **Play/Pause:** Press the **Play/Pause button** (center button on top) to play or pause audio.
- **Volume Up/Next Track:** Press the **Next Track/Volume Up button** (right of Play/Pause) briefly to skip to the next track. Press and hold to increase the volume.
- **Volume Down/Previous Track:** Press the **Previous Track/Volume Down button** (left of Play/Pause) briefly to go to the previous track. Press and hold to decrease the volume.
- **Mode:** Press the **Mode button** (rightmost button on top) to switch between Bluetooth and AUX input modes.

6. MAINTENANCE

6.1. Cleaning

Clean the speaker with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents. Avoid getting moisture into any openings.

6.2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3 months) to maintain its lifespan.

6.3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker when the battery level is low. Do not expose the battery to excessive heat or cold.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided USB-C cable.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker not in pairing mode. Device too far from speaker. Previous connection interfering.	Ensure speaker is in Bluetooth pairing mode (flashing LED). Move device closer to the speaker (within 10m). Forget/delete the speaker from your device's Bluetooth list and try pairing again.
No sound or low volume.	Volume too low on speaker or device. Incorrect input mode selected. AUX cable not fully inserted.	Increase volume on both speaker and connected device. Press the Mode button to select the correct input (Bluetooth or AUX). Ensure the 3.5mm AUX cable is securely connected at both ends.
Sound quality is poor or distorted.	Device too far from speaker. Interference from other devices.	Move device closer to the speaker. Move speaker away from other electronic devices that may cause interference.

8. SPECIFICATIONS

Feature	Specification
Brand	Crivit
Model Name	Bluetooth Speaker
Item Model Number	SBL 4 A2
Product Dimensions (L x W x H)	6 x 18 x 8.4 cm
Speaker Type	Bluetooth®
Connectivity Technology	Auxiliary, Bluetooth, USB
Maximum Speaker Output Power	6 Watts (2 x 3 W RMS)
Audio Output Mode	Stereo
Maximum Range	10 Meters
Battery Capacity	2200 mAh
Recommended Uses for Product	For music player, For smartphone or tablet
Controller Type	Remote Control (implied by buttons)
Included Components	USB-A to USB-C charging cable, 3.5 mm audio cable
Manufacturer	crivit
Date First Available on Amazon.com.be	20 July 2023
Software Updates Guaranteed Until	Information not available

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Crivit/Silvercrest website. Keep your proof of purchase for warranty claims.

© 2023 Crivit / Silvercrest. All rights reserved.