

Nerf F8645

NERF Junior Wild Sharkfire Blaster User Manual

Model: F8645

IMPORTANT SAFETY INFORMATION

WARNING: Small parts may be generated. Not for children under 3 years.

Eyewear recommended (not included). Do not aim at eyes or face. Use only official NERF darts. Other darts may not meet safety standards. Do not modify darts or blaster.

PRODUCT OVERVIEW

The Nerf Junior Wild Sharkfire blaster is designed for easy play, making it ideal for young kids. Its lightweight design and comfortable size fit small hands, allowing children to enjoy dart blasting independently.

What's in the Box

- 1 x NERF Junior Wild Sharkfire Blaster
- 8 x Nerf Elite 2.0 Flexible Foam Darts



Image: The NERF Junior Wild Sharkfire Blaster in blue and orange, shaped like a shark, displayed with eight blue and yellow foam darts.



Image: The NERF Junior Wild Sharkfire Blaster shown inside its retail packaging, highlighting its shark design and 'Easy Play' features.

SETUP

Loading Darts

1. Ensure the blaster is not primed.
2. Insert one Nerf Elite 2.0 foam dart into each of the three front-loading barrels located in the shark's mouth. Push the darts in firmly until they are seated.



Image: A child's hand inserting a blue foam dart into one of the barrels located in the shark-shaped blaster's mouth.

Video: A demonstration of how to load darts into the front barrels of the NERF Junior Wild Sharkfire Blaster.

OPERATING INSTRUCTIONS

Priming the Blaster

To prime the blaster, grasp the handle at the rear of the shark's tail and pull it back completely until it clicks into place. This action prepares the blaster for firing.



Image: A child's hand pulling back the white handle at the rear of the blue shark blaster to prime it for firing.

Firing the Blaster

Once primed, aim the blaster at your target. Press the trigger located under the handle to fire a dart. The blaster fires one dart at a time. To fire another dart, you must re-prime the blaster after each shot.



Image: A child wearing safety glasses, smiling, as they fire the blue shark blaster, with a blue foam dart visible in flight.

MAINTENANCE

General Care

- Keep the blaster clean by wiping it with a damp cloth.
- Avoid exposing the blaster to extreme temperatures or direct sunlight for prolonged periods.
- Store the blaster and darts in a dry, safe place when not in use.

Dart Care

- Only use official Nerf Elite 2.0 darts to ensure proper function and safety.
- Do not modify darts. Modified darts may cause the blaster to malfunction or pose a safety risk.
- Inspect darts regularly for damage. Discard any torn or damaged darts.



Image: The blue shark-shaped NERF blaster resting on sand, with several blue foam darts scattered around it, suggesting outdoor play.

TROUBLESHOOTING

Darts Not Firing

- **Check Priming:** Ensure the blaster is fully primed by pulling the handle all the way back until it clicks.
- **Dart Seating:** Make sure darts are fully inserted into the barrels.
- **Dart Condition:** Verify that darts are not damaged or bent. Use only new, official Nerf darts.

Darts Jamming

- **Clear Obstructions:** Look into the barrels and firing mechanism for any foreign objects or jammed darts. Carefully remove them.
- **Use Official Darts:** Non-official or damaged darts are a common cause of jamming.

SPECIFICATIONS

Feature	Detail
---------	--------

Product Dimensions	2.6 x 16 x 9 inches
Item Weight	12.7 ounces
Model Number	F8645
Manufacturer Recommended Age	6 years and up
Darts Included	8 Nerf Elite 2.0 Flexible Foam Darts
Blaster Type	Easy Play Dart Blaster (Front-loading, Low Pull Force)
Manufacturer	Hasbro

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Hasbro website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
Visit the official [Nerf Store on Amazon](#) for more products and information.

© 2024 Nerf. All rights reserved. Trademarks of Hasbro.

Related Documents - F8645

	Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.
	Nerf Rough Cut 2X4 Elite Blaster User Manual User manual for the Nerf Rough Cut 2X4 Elite Blaster, detailing its features, operation, and safety precautions. Includes instructions for loading, single fire, and slam fire modes.
	Nerf N-Strike Elite Strongarm Blaster: User Guide Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.
	Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.
	Nerf Roblox Arsenal Pulse Laser Blaster Instructions Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.



[NERF Modulus ECS-10 Blaster: Instructions and Safety Guide](#)

Official instructions and safety information for the NERF Modulus ECS-10 blaster by Hasbro. Learn how to load, fire, maintain, and safely use your NERF blaster.