

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Nerf](#) /
- > [NERF Wild Lionfury Dart Blaster Instruction Manual](#)

## Nerf F8646

# NERF Wild Lionfury Dart Blaster Instruction Manual

Model: F8646 | Brand: Nerf

<a href="#">Introduction</a>	<a href="#">Safety Information</a>	<a href="#">What's in the Box</a>	<a href="#">Setup</a>	<a href="#">Operating Instructions</a>	<a href="#">Maintenance</a>
	<a href="#">Troubleshooting</a>	<a href="#">Specifications</a>		<a href="#">Warranty &amp; Support</a>	

## 1. INTRODUCTION

The NERF Wild Lionfury Dart Blaster is designed for easy and engaging play, suitable for young users. Its unique lion-themed design and vibrant colors enhance imaginative play. This blaster is lightweight and sized for comfortable handling by small hands, making it ideal for both indoor and outdoor activities. The front-loading mechanism simplifies dart insertion, and the easy-pull handle ensures effortless blasting, allowing children to enjoy the thrill of dart games independently.



*Image: The NERF Wild Lionfury Dart Blaster as packaged, highlighting its design and the 16 included darts.*

## 2. SAFETY INFORMATION

---

**WARNING:** Small parts may be generated. Not for children under 3 years.

- Always wear eye protection when using this blaster (eyewear not included).
- Use only official NERF Elite 2.0 flexible foam darts. Other darts may not meet safety standards.
- Do not modify the blaster or darts.
- Do not aim at eyes or face.
- Keep fingers and other body parts clear of moving parts during operation.



*Image: A child wearing safety glasses while holding the blaster, emphasizing the importance of eye protection.*

### **3. WHAT'S IN THE BOX**

---

Your NERF Wild Lionfury Dart Blaster package includes the following items:

- 1 x NERF Wild Lionfury Blaster
- 16 x NERF Elite 2.0 flexible foam darts



*Image: The blaster and its accompanying 16 darts, ready for use.*

## 4. SETUP

---

Follow these steps to prepare your blaster for play:

1. **Unpack the Blaster:** Carefully remove the blaster and darts from their packaging.
2. **Insert Darts:** Insert the 16 NERF Elite 2.0 flexible foam darts into the front of the blaster. Each dart should slide easily into its designated barrel opening.



*Image: Close-up of a child inserting a dart into the front of the blaster.*

## 5. OPERATING INSTRUCTIONS

---

Once the darts are loaded, you are ready to operate your NERF Wild Lionfury Blaster:

1. **Hold the Blaster:** Grip the blaster firmly with both hands. The design is optimized for comfortable holding by children.
2. **Load the Blaster:** Pull back the handle located at the bottom of the blaster towards you. This action primes the blaster for firing. The handle has a low pull force for ease of use.
3. **Aim:** Point the blaster towards your target, ensuring no one is in the line of fire, especially their eyes or face.
4. **Fire:** Press the trigger to launch a dart.

Your browser does not support the video tag.

*Video: An official product overview demonstrating the loading and firing mechanism of the NERF Wild Lionfury Blaster.*



*Image: A child demonstrating the easy-pull handle to load the blaster.*




Image: A dart being fired from the blaster, illustrating the blasting action.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your NERF Wild Lionfury Blaster, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the blaster with a clean, damp cloth to remove dirt or debris. Do not submerge the blaster in water.
- **Dart Care:** Store darts in a clean, dry place. Avoid bending or crushing darts, as this can affect their flight performance.
- **Storage:** When not in use, store the blaster in a cool, dry place away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

If you encounter any issues with your NERF Wild Lionfury Blaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dart does not fire or fires weakly.	Blaster not fully primed; damaged or incorrect darts; dart jammed.	Ensure the handle is pulled back completely until it clicks. Use only official NERF Elite 2.0 darts. Check for any obstructions in the barrel and remove them carefully.
Darts fall out of the barrel.	Darts are worn out or damaged.	Replace old or damaged darts with new, official NERF Elite 2.0 darts.

If the problem persists after trying these solutions, please contact customer support.

## 8. SPECIFICATIONS

---

**Model Number:** F8646

**Brand:** Nerf

**Product Dimensions:** 3.19 x 17.99 x 10 inches

**Item Weight:** 1.55 pounds

**Recommended Age:** 6 years and up

**Dart Type:** NERF Elite 2.0 flexible foam darts

**Dart Capacity:** 16 darts included

**Manufacturer:** Hasbro

**Release Date:** April 1, 2024

## 9. WARRANTY & SUPPORT

---

For warranty information or customer support regarding your NERF Wild Lionfury Dart Blaster, please refer to the contact details provided on the product packaging or visit the official Nerf website. Keep your purchase receipt as proof of purchase.

**Manufacturer:** Hasbro

For further assistance, please visit: [Nerf Official Store on Amazon](#)