

HOOBRO WT61XJ01

HOOBRO Vertical Shoe Rack WT61XJ01 Instruction Manual

INTRODUCTION

Thank you for choosing the HOOBRO Vertical Shoe Rack WT61XJ01. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your product. Please read this manual thoroughly before assembly and retain it for future reference.

SAFETY INFORMATION

For your safety and to prevent damage to the product, please observe the following:

- Install the supplied anti-tip kit to fix the product against the wall before use. This prevents accidental tipping.
- Do not exceed the maximum weight capacity of 11 pounds per shelf.
- Keep small parts away from children during assembly.
- Ensure all screws and fasteners are securely tightened before use.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Wooden Panels (various sizes for shelves and frame)
- Connecting Hardware (screws, dowels, etc.)
- Hooks (2 pieces)
- Anti-Tip Kit (wall anchor, strap, screws)
- Assembly Tool (e.g., Allen wrench)
- Instruction Manual

SETUP: ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your HOOBRO Vertical Shoe Rack WT61XJ01. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

Step 1: Prepare Components

Unpack all components and identify them using the provided parts list (refer to the separate parts diagram if included). Ensure you have all necessary hardware.






Image: Main product view of the HOOBRO Vertical Shoe Rack WT61XJ01, showing its 7 tiers and overall white finish.

Step 2: Assemble the Frame

Connect the main vertical support panels using the designated hardware. Ensure they are aligned correctly before tightening screws.

Step 3: Attach Shelves

Insert the shelves into the pre-drilled holes on the vertical supports. The shelves are designed to be detachable, allowing for flexible storage of different shoe types, including boots or high heels. Secure each shelf with the appropriate fasteners.



Image: Close-up view illustrating the detachable shelf design, accommodating various shoe heights like boots and high heels.

Step 4: Install Top Protective Fence

Attach the three-sided fence to the top panel of the shoe rack. This fence helps secure items placed on the top surface.



Image: The top shelf of the shoe rack featuring a protective fence, designed to prevent items like keys or small decorations from falling.

Step 5: Attach Hooks

Secure the two hooks to the designated points on the side of the shoe rack. These hooks can be used for hanging umbrellas, keys, or small bags.



Image: Side view of the shoe rack highlighting the integrated hooks, suitable for hanging small items such as keys or umbrellas.

Step 6: Install Anti-Tip Device

For safety, attach the anti-tip device to the back of the shoe rack and secure it to a wall stud according to the instructions provided with the kit. This prevents the unit from tipping over, especially in households with children or pets.



Image: Diagram showing the installation of the anti-tip device, which secures the shoe rack to the wall for stability.

OPERATING INSTRUCTIONS

The HOOBRO Vertical Shoe Rack WT61XJ01 is designed for versatile storage in various home environments.

Shoe Storage

- Place shoes on the 7 tiers. The open design allows for easy access and visibility.
- For taller footwear like boots or high heels, remove one or more shelves to create larger vertical spaces.

Multi-functional Use

- The top shelf with its protective fence is suitable for placing small decorative items, keys, wallets, or small storage baskets.
- Utilize the side hooks for hanging umbrellas, bags, or other accessories.
- This unit can also function as a general shelving unit in living rooms, studies, or bedrooms for books, alarm clocks, or art decorations.



Image: The shoe rack repurposed as a general shelving unit in a living room, holding various household items and decorations.

MAINTENANCE

To maintain the appearance and longevity of your shoe rack:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Placement:** Avoid placing the unit in direct sunlight or in areas with high humidity to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your HOOBRO Vertical Shoe Rack WT61XJ01, refer to the following common solutions:

Unit is Unstable

- Ensure all screws are fully tightened.
- Verify that the unit is placed on a flat, level surface.
- Confirm the anti-tip device is correctly installed and secured to the wall.

Difficulty Assembling

- Review the assembly instructions carefully, paying attention to part orientation.
- Ensure you are using the correct hardware for each step.
- Do not overtighten screws during initial assembly; tighten fully once all parts are in place.

Missing Parts

- Double-check the packaging for any small components.
- Contact HOOBRO customer support with your model number and a description of the missing part.

SPECIFICATIONS

Feature	Detail
Model Name	Vertical Shoe Rack
Model Number	WT61XJ01
Brand	HOOBRO
Material	Engineered Wood
Color	White
Product Dimensions (L x W x H)	11"D x 11"W x 41.3"H (28 x 28 x 105 cm)
Number of Shelves	7
Weight Capacity per Shelf	11 pounds (5 kg)
Special Features	Includes 2 Hooks, Top Protective Fence, Detachable Shelves, Anti-tip Device
Mounting Type	Floor Mount (with wall anchor option)
Assembly Required	Yes, easy assembly with included instructions



Image: Technical drawing showing the detailed dimensions of the 7-tier HOOBRO Vertical Shoe Rack, including height, width, and depth.

WARRANTY AND SUPPORT

HOOBRO products are manufactured with quality and customer satisfaction in mind. For any questions, concerns, or to report missing/damaged parts, please contact HOOBRO customer support directly. Please have your model number (WT61XJ01) and purchase information ready when contacting support.

For more information, visit the official HOOBRO store: [HOOBRO Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question