Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

X-PRO MC-N99

X-PRO X19 150cc Moped Instruction Manual

Brand: X-PRO | Model: MC-N99

1. Introduction and Overview

This manual provides essential information for the safe assembly, operation, and maintenance of your X-PRO X19 150cc Moped. Please read it thoroughly before using the vehicle.



Figure 1: X-PRO X19 150cc Moped, front-side view.

Key Features:

- 150cc, air-cooled, 4-stroke engine for predictable power and fuel efficiency.
- Fully automatic transmission for ease of use.
- 12-inch aluminum wheels with DOT-approved tires for traction.
- Equipped with an odometer.

2. Setup and Assembly

Your X-PRO X19 150cc Moped requires some assembly upon arrival. This section outlines the general steps. For a detailed visual guide, please refer to the assembly video provided below.



Figure 2: Moped as received in its shipping crate.

Assembly Steps:

1. **Uncrating:** Carefully remove the outer cardboard box and then detach the metal frame securing the moped.
2. **Handlebar Installation:** Unpack the handlebars and attach them to the steering column. Ensure all bolts are securely tightened.
3. **Mirror Attachment:** Install the rearview mirrors onto the handlebars.
4. **Front Fender:** Attach the front fender to the front fork assembly.
5. **Exhaust Heat Shield:** Secure the exhaust heat shield.
6. **Rear Shock Absorber:** Connect the lower end of the rear shock absorber to the swingarm.
7. **Front Wheel Installation:** Mount the front wheel onto the front fork, ensuring the brake caliper aligns correctly with the disc. Connect the speedometer cable.
8. **Battery Connection:** Locate the battery compartment (typically under the floorboard). Connect the positive (red) and negative (black) terminals.

Video 1: X-PRO X19 Moped Scooter Assembly Guide. This video demonstrates the complete assembly process from uncrating to final checks.

3. Operating Instructions

Familiarize yourself with the controls and features before operating the moped.

Starting the Moped:

1. Ensure the moped is on its center stand.
2. Insert the key into the ignition and turn it to the 'ON' position.
3. Engage the brake lever (left or right, depending on model) and press the electric start button.
4. Allow the engine to warm up for a short period before riding.

Riding:

- The X-PRO X19 features a fully automatic transmission. Simply twist the throttle to accelerate.
- Use both front and rear brakes for balanced stopping power.
- Always wear appropriate safety gear, including a helmet.

Stopping:

- Release the throttle completely.
- Apply both brake levers smoothly and evenly.
- Once stopped, turn the ignition key to 'OFF' and remove it.

4. Maintenance

Regular maintenance is crucial for the longevity and safe operation of your moped.

Key Maintenance Areas:

- **Oil Changes:** Refer to your owner's manual for recommended oil type and change intervals.
- **Tire Pressure:** Check tire pressure regularly. Correct inflation is vital for safety and handling.
- **Brakes:** Inspect brake pads and fluid levels periodically. Ensure brake levers operate smoothly.
- **Fasteners:** Regularly check all bolts and fasteners for tightness, especially after initial assembly and during routine inspections.
- **Lights and Signals:** Verify all lights (headlight, taillight, turn signals) and the horn are functioning correctly.

5. Troubleshooting

This section addresses common issues you might encounter.

Common Issues:

- **Engine Not Starting:** Check fuel level, ensure the ignition is on, and the battery is connected and charged.
- **Loose Components:** If you notice any loose bolts or parts, secure them immediately. Regular checks can prevent this.
- **Speedometer Inaccuracy:** Some users have reported speedometer discrepancies. If this occurs, consider professional calibration or using a GPS-based speedometer for accurate readings.
- **Unusual Noises:** Investigate any new or unusual sounds from the engine or chassis promptly.

For issues beyond basic troubleshooting, consult a qualified technician or contact X-PRO customer support.

6. Specifications

Feature	Specification
Bike Type	Moped
Age Range	Adult
Brand	X-PRO
Number of Speeds	12
Color	Red (variant)
Wheel Size	12 Inches
Frame Material	Alloy Steel
Suspension Type	Dual
Special Feature	Odometer
Power Source	Gasoline
Wheel Material	Aluminum
Brake Style	Disc, Drum
Drivetrain Type	Automatic
Electric Assist Type	Electric Start
Maximum Weight Recommendation	330 Pounds
Assembly Required	Yes
Model Name	MC-N99

7. Warranty and Support

Your X-PRO X19 150cc Moped comes with a Standard Warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase.

Customer Support:

For technical assistance, parts inquiries, or any other support needs, please contact X-PRO customer service. It is recommended to have your model number (MC-N99) and purchase information readily available when contacting support.

Manufacturer: X-PRO

Seller: XPROUSA

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCHZYJGJ

More documents and user manuals: **https://manuals.plus/**