Avrsol SGZZ-1

Avrsol Kids Play Tent with Mat Instruction Manual

Model: SGZZ-1

Introduction

Welcome to the world of imaginative play with your new Avrsol Kids Play Tent! This large playhouse tent, complete with a comfortable mat and charming pompoms door curtains, is designed to provide a private and enchanting space for children aged 18 months to 12 years. It's perfect for indoor adventures, reading nooks, or simply a cozy retreat.

Important Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.
Always supervise children during play. Ensure all components are securely assembled before use. Keep away from open flames and heat sources. Regularly inspect the tent for any damage or wear and tear. Discontinue use if any part is broken or compromised.

What's in the Box

Please check the contents of your package to ensure all items are present:

- Poles and connectors (for frame assembly)
- Play tent fabric (main tent cover, including roof, walls, and curtains)

Setup and Assembly

The Avrsol Kids Play Tent is designed for easy assembly, typically taking an adult about 10 minutes with no additional tools required. Follow these steps for a quick setup:

1. **Unpack Components:** Carefully remove all poles, connectors, and the tent fabric from the packaging. Lay them out to identify each part.
2. **Assemble the Base Frame:** Connect the appropriate poles using the connectors to form the rectangular base of the tent. Ensure all connections are secure.
3. **Construct the Vertical Supports:** Attach the vertical poles to the base frame's corners, connecting them with the appropriate connectors to create the upright structure.
4. **Form the Roof Structure:** Connect the roof poles to the top of the vertical supports, creating the A-frame shape for the tent's roof.
5. **Drape the Tent Fabric:** Carefully slide the play tent fabric over the assembled frame. The fabric is designed to fit snugly over the poles, covering the roof and all sides. Ensure the star pattern on the roof is correctly oriented.
6. **Position the Mat:** Place the included pink quilted mat inside the tent on the floor for added comfort.
7. **Arrange Curtains:** The ethereal gauze curtains with pompoms can be tied back using the attached ribbons for an open entrance or left down for a more enclosed feel.



Image: The fully assembled play tent, ready for use.



Image: A view inside the tent, highlighting the comfortable mat and open curtains.



Image: Detail of the decorative pompoms and sheer curtains.

Assembly Demonstration Video

Your browser does not support the video tag.

Video: A step-by-step guide to assembling the Kids Play Tent with Mat, demonstrating the ease of setup and the final appearance.

Features

- **Spacious Design:** Measuring 57" L x 35.5" W x 53" H, this play tent offers ample room for children to play, read, and relax.
- **Comfortable Mat:** Includes a soft, quilted mat for a cozy and comfortable play surface.
- **Ethereal Curtains:** Features gauze door curtains adorned with cute pompoms, adding a magical touch and defining

the play space.

- **Durable Construction:** Hand-made with sturdy materials designed to last for years of imaginative play.
- **Easy Assembly:** Quick and straightforward setup in approximately 10 minutes by an adult, with no special tools required.
- **Charming Aesthetics:** Pink fabric with white stars creates a delightful and inviting atmosphere for children.



Image: Visual representation of the tent's dimensions.

Operating Instructions

The Avrsol Kids Play Tent is designed for intuitive use. Once assembled, children can immediately begin their adventures.

- **Entering and Exiting:** The front opening with sheer curtains allows for easy access. Curtains can be tied back using

the attached ribbons for an open entrance or left loose for a more private space.

- **Creative Play:** Encourage children to use the tent for various activities such as reading, playing with toys, napping, or hosting imaginary tea parties.
- **Ventilation:** The tent features windows on the sides and back to ensure adequate airflow during play.

Maintenance

To ensure the longevity and cleanliness of your play tent, follow these maintenance guidelines:

- **Cleaning the Fabric:** The tent fabric can be spot cleaned with a damp cloth and mild soap. For deeper cleaning, hand wash the fabric in cold water and air dry. Do not bleach or tumble dry.
- **Cleaning the Mat:** The quilted mat can be machine washed on a gentle cycle with cold water. Air dry or tumble dry on low heat.
- **Frame Care:** Wipe down the poles and connectors with a damp cloth as needed. Ensure they are completely dry before storage to prevent rust or mildew.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place away from direct sunlight to prevent fading and material degradation.

Troubleshooting

If you encounter any issues with your play tent, please refer to the following common solutions:

Problem	Possible Cause	Solution
Tent is wobbly or unstable.	Poles or connectors are not fully secured.	Ensure all poles are firmly inserted into their connectors. Double-check each joint.
Fabric does not fit correctly.	Fabric is oriented incorrectly or frame is not fully assembled.	Remove fabric and re-drape, ensuring it aligns with the frame's shape. Verify all frame components are correctly connected.
Missing parts.	Packaging error.	Refer to the "What's in the Box" section. If parts are genuinely missing, contact Avrsol customer support.

Specifications

Attribute	Detail
Product Dimensions	57 x 35.5 x 53 inches (L x W x H)

Attribute	Detail
Item Weight	9 pounds
Model Number	SGZZ-1
Manufacturer	Avrsol
Recommended Age	18 months - 12 years
Country of Origin	China

Warranty and Support

Avrsol stands behind the quality of its products. For any warranty claims, technical support, or inquiries regarding your Kids Play Tent, please contact Avrsol customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.
For more information about Avrsol products, visit the officialAvrsol Store.

© 2025 Avrsol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The instructions for the Avrsol SGZZ-1 Kids Play Tent are incomplete; how do I know which poles (marked A, B, C, and D) go in the base, the vertical supports, and the roof structure?

While the general manual for the Avrsol SGZZ-1 describes the assembly steps, it does not explicitly list the dimensions for each lettered pole. However, based on the rectangular design (57" L x 35.5" W...

Read full answer

What size batteries are needed for the lights in the Avrsol SGZZ-1 Kids Play Tent?

Based on the instruction manual for the Avrsol SGZZ-1 Kids Play Tent, there is no mention of included lights or specific battery requirements. The standard package contents include the poles, connectors, tent fabric, and...

Read full answer