



Manuals.plus /

› Strex /

› Strex SP270 DVD Player User Manual

Strex SP270

Strex SP270 DVD Player User Manual

Model: SP270



1. INTRODUCTION

Thank you for purchasing the Strex SP270 DVD Player. This manual provides detailed instructions for setting up, operating, and maintaining your new device. Please read this manual thoroughly before use to ensure proper operation and to maximize your viewing and listening experience. This region-free DVD player is designed to play DVDs and CDs from any region worldwide, offering versatile media playback with Full HD 1080P output.

2. PRODUCT OVERVIEW

The Strex SP270 DVD Player is a compact and versatile media device designed for high-quality video and audio playback. It features multiple connectivity options and broad media compatibility.

Key Features:

- **Full HD 1080P Support:** Enjoy crisp, clear video quality for your movies.
- **Region-Free Playback:** Compatible with DVDs from all regions worldwide.
- **USB Connectivity:** Play digital media files (photos, videos, music) directly from a USB flash drive (up to 128GB).
- **Multiple Output Options:** Connect to your TV via HDMI or RCA cables (both included).
- **Enhanced Audio & Video Quality:** Features an updated laser for smooth, interference-free playback and clear sound.
- **Compact and Modern Design:** Sleek black finish with anti-slip feet, fitting easily into any entertainment setup.
- **Remote Control Included:** For convenient operation from a distance.



Figure 2.1: The Strex SP270 DVD Player, showing the unit, included remote control, and HDMI cables.

ALLES IN EEN

Al jouw favoriete media via 1 apparaat




Figure 2.2: Overview of the Strex SP270's capabilities, including DVD, CD, and USB playback, HDMI output, 1080P Full HD support, and region-free functionality.

MODERN ONTWERP



Figure 2.3: Front and side view of the Strex SP270 DVD Player, highlighting its various components and ports for easy identification.

3. PACKAGE CONTENTS

Please check the box for the following items:

- Strex SP270 DVD Player
- Remote Control
- HDMI Cable
- RCA Cable
- User Manual

IN DE DOOS



● DVD Speler



● Verpakking



● Afstandsbediening, HDMI/RCA kabel ● Handleiding



Figure 3.1: All items included in the Strex SP270 DVD Player package.

4. SETUP

Follow these steps to connect your Strex SP270 DVD Player to your television.

4.1 Connecting to a Television

The Strex SP270 offers two primary connection methods: HDMI and RCA.

1. HDMI Connection (Recommended for HD Quality):

- Locate the HDMI OUT port on the back of the DVD player.
- Connect one end of the included HDMI cable to the HDMI OUT port on the DVD player.
- Connect the other end of the HDMI cable to an available HDMI IN port on your television. Note the HDMI input number (e.g., HDMI 1, HDMI 2) on your TV.

2. RCA Connection (Standard Definition):

- Locate the RCA (Red, White, Yellow) ports on the back of the DVD player.
- Connect the included RCA cable by matching the colors: Yellow to Yellow (Video), White to White (Left Audio), Red to Red (Right Audio).
- Connect the other end of the RCA cable to the corresponding RCA IN ports on your television.



Figure 4.1: Rear view of the Strex SP270 DVD Player, illustrating the HDMI and RCA connection points and their respective cables.

4.2 Power Connection

- Connect the power cord to the AC IN port on the back of the DVD player.
- Plug the other end of the power cord into a standard electrical outlet.

4.3 Initial Power On

- Turn on your television and select the correct input source (e.g., HDMI 1, AV) that corresponds to where you connected the DVD player.
- Press the Power button on the DVD player or the remote control to turn on the unit.
- The Strex logo or a setup menu should appear on your TV screen.

5. OPERATING INSTRUCTIONS

5.1 Disc Playback

1. Ensure the DVD player is powered on and connected to your TV.
2. Press the Eject button (▲) on the front panel or remote control to open the disc tray.
3. Place a DVD or CD disc gently onto the disc tray with the label side facing up.
4. Press the Eject button again to close the disc tray. The player will automatically begin reading the disc.
5. Use the remote control to navigate menus, play, pause, stop, fast forward, and rewind.

VERNIEUWDE LASER

Speel vloeiend en storingsvrij al je favoriete dvd's af



Zonder regio
bescherming



Figure 5.1: Inserting a disc into the Strex SP270 DVD Player's disc tray.

5.2 USB Media Playback

The Strex SP270 allows you to play digital media files directly from a USB flash drive.

1. Insert your USB flash drive into the USB port on the front of the DVD player.

2. The player should automatically detect the USB drive and display a media selection menu (e.g., Photo, Music, Video). If not, press the "USB" button on the remote control or navigate to the USB input.
3. Use the arrow keys on the remote to navigate through your files and folders.
4. Press the "OK" or "Play" button to select and play a file.

Note: The USB port supports flash drives up to 128GB. Ensure your USB drive is formatted to a compatible file system (e.g., FAT32).



Figure 5.2: The USB port on the Strex SP270 DVD Player, ready for a USB flash drive.

5.3 Remote Control Functions

The included remote control provides full functionality for operating your DVD player. Familiarize yourself with the buttons for power, disc tray, playback controls (play, pause, stop, fast forward, rewind, skip), navigation, volume, and input selection.

6. MEDIA COMPATIBILITY

The Strex SP270 DVD Player supports a wide range of disc and digital media formats:

- **Disc Formats:** DVD, DVD+R/RW, DVD-R/RW, CD, CD/R/RW, VCD, CPRM
- **Digital File Formats (via USB):** JPEG (images), MP3 (audio), DIVX, MPEG4 (video)
- **Video Resolution:** Up to 1080P Full HD
- **Region Compatibility:** Region-free (plays DVDs from any region)
- **TV System Compatibility:** NTSC/PAL/Auto

Important Note: This DVD player does NOT support Blu-Ray discs.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Strex SP270 DVD Player, follow these maintenance guidelines:

- **Cleaning the Unit:** Use a soft, dry cloth to wipe the exterior of the player. Do not use liquid cleaners or abrasive chemicals.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of dust, fingerprints, and scratches. Use a soft, lint-free cloth to wipe discs from the center outwards.
- **Ventilation:** Ensure the player is placed in a well-ventilated area. Do not block any ventilation openings.
- **Storage:** When not in use for extended periods, unplug the player and store it in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your Strex SP270 DVD Player, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working	Ensure power cord is securely plugged into the player and a working outlet. Try a different outlet.
No picture on TV	Incorrect TV input selected; Loose HDMI/RCA cables; Player not powered on	Select the correct input source on your TV. Check that HDMI/RCA cables are securely connected. Ensure the DVD player is powered on.
No sound	TV volume too low/muted; Loose audio cables (RCA); Incorrect audio settings	Increase TV volume and check mute status. Ensure RCA audio cables (Red/White) are connected. Check audio settings on the player/TV.
Disc not playing/reading	Disc is dirty or scratched; Incorrect disc type (e.g., Blu-Ray); Disc inserted incorrectly	Clean the disc with a soft cloth. Ensure the disc is a compatible format (not Blu-Ray). Insert the disc with the label side facing up.
USB drive not detected	USB drive not properly inserted; Incompatible format/size; Corrupted files	Re-insert the USB drive. Ensure it is formatted to FAT32 and is 128GB or less. Check if files are corrupted.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and player	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions. Point the remote directly at the player's sensor.

9. SPECIFICATIONS

Feature	Detail
Brand	Strex
Model Number	SP270
Color	Black
Dimensions (L x W x H)	22 x 19 x 4.5 cm (8.66 x 7.48 x 1.77 inches)
Weight	850 Grams (1.87 lbs)
Connectivity Technology	HDMI, USB, RCA
Resolution	1080P Full HD
Special Feature	Region-Free Playback
Compatible Media Types	DVD, DVD+R/RW, DVD-R/RW, CD, CD/R/RW, VCD, JPEG, MP3, DIVX, CPRM, MPEG4
USB Support	Up to 128GB flash drives
TV System Compatibility	NTSC/PAL/Auto
Power Source	100-240V~, 50/60Hz



Figure 9.1: Dimensions of the Strex SP270 DVD Player.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer/major manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Strex

Model: SP270

ASIN: B0CCJCCPYV

