

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Brightever](#) /

› [Brightever 10 Inch LED Ceiling Light Fixture Instruction Manual](#)

### Brightever 63025008-03

# Brightever 10 Inch LED Ceiling Light Fixture Instruction Manual

Model: 63025008-03

## 1. PRODUCT OVERVIEW

---

The Brightever 10 Inch LED Ceiling Light Fixture is a modern flush mount lighting solution designed for various indoor spaces. It features adjustable color temperature and dimming capabilities to suit different lighting needs and preferences. This fixture provides high brightness and is designed for easy installation.



Image: Brightever 10 Inch LED Ceiling Light Fixture, brushed nickel finish.

### Key Features:

- **Versatile Lighting:** Offers 5 color temperatures (2700K Warm White, 3000K Soft White, 4000K Neutral White, 5000K Daylight White, 6500K Cool White) to adapt to different environments.
- **Powerful Illumination:** Provides 4000 lumens of brightness with a 30W power consumption, ensuring efficient lighting.
- **Stepless Dimmable:** Allows brightness adjustment from 5% to 100% (dimmer not included) for customized ambiance.
- **Modern Design:** Features a sleek, contemporary design that integrates with various decor styles.
- **Easy Installation:** Designed for quick and straightforward flush mount installation.

## 2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Always turn off the power at the circuit breaker before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Do not attempt to modify the fixture. Any modifications may void the warranty and pose a safety risk.
- Handle the light fixture with care to avoid damage.

### 3. PACKAGE CONTENTS

---

Verify that all components are present before installation:

- LED Ceiling Light Fixture (2 units for 2-pack)
- Mounting Hardware
- Instruction Manual

### 4. SPECIFICATIONS

---

Feature	Specification
Brand	Brightever
Model Name	63025008-03
Size	10 Inch
Color	Brushed Nickel
Material	Plastic
Wattage	30 Watts
Brightness	4000 Lumens
Color Temperature	2700K-6500K Adjustable
Dimmable	Yes (5%-100% Stepless, dimmer not included)
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Light Source Type	LED

### 5. INSTALLATION INSTRUCTIONS

---

Follow these steps for proper installation. Ensure power is OFF at the circuit breaker before starting.



Image: Step-by-step diagram for installing the ceiling light fixture.

1. **Prepare the Fixture:** Unscrew the canopy screws on the fixture to remove the mounting plate.
2. **Mounting Plate Installation:** Secure the mounting plate to the junction box on the ceiling using the provided screws. Before proceeding, select the desired color temperature using the switch located on the fixture (refer to Operating Instructions for details).
3. **Wire Connection:** Connect the electrical wires from the ceiling to the corresponding wires on the fixture (typically black to black, white to white, and ground to ground). Use wire nuts to secure connections.
4. **Attach the Fixture:** Carefully align the fixture with the mounting plate and secure it using the canopy screws.
5. **Power On:** Once the fixture is securely installed, restore power at the circuit breaker.

**Important Note:** The color temperature selection switch must be set *before* the fixture is fully installed and covered. Once the cover is in place, the switch is not accessible.

## 6. OPERATING INSTRUCTIONS

## Adjusting Color Temperature:

This fixture offers 5 selectable color temperatures. A switch is located on the fixture itself for this adjustment. This switch must be set during installation before the light cover is secured.



## 5 Color Temperatures Adjustable

With 5 CCTs in one ceiling light, there are no more worries about color temperature selection and can save the trouble of returning or replacing items because of unsuitable color temperatures.

**Note: Please set the color temperature before installation**




Image: Visual representation of the 5 adjustable color temperatures.

- **2700K:** Warm White, suitable for cozy and relaxing environments.
- **3000K:** Soft White, a slightly brighter warm tone.
- **4000K:** Neutral White, balanced light for general tasks.
- **5000K:** Daylight White, bright and crisp, ideal for task lighting.
- **6500K:** Cool White, very bright, often used in utility areas.

## Dimming Function:

The Brightever LED Ceiling Light Fixture is stepless dimmable from 5% to 100% brightness. To utilize this feature, a compatible LED dimmer switch (not included) must be installed in your electrical circuit.



## 5%-100% Stepless Dimming

Our flush mount ceiling light is 5%-100% dimmable and compatible with most LED dimmers on the market, making it ideal to provide relaxing mood lighting for your home

**Dimmer Not Included**

Image: Depiction of the light fixture's dimming range.

Once a compatible dimmer is installed, you can adjust the light output to your desired level by operating the dimmer switch.

### **Flicker-Free Operation:**

This light fixture is designed to provide flicker-free illumination, which helps reduce eye strain and fatigue often associated with conventional lighting.



**No Flicker**

Our ceiling lights could eliminate eyes exhaustion caused by conventional lights, effectively protecting your family's eyesight

10.0 inch / 25.4cm

2.68 inch / 6.8cm



Image: Illustration of the light's flicker-free performance.

## 7. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your light fixture.

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, dry or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes, as these can damage the finish or electrical components.
- **Bulb Replacement:** This LED fixture has integrated LEDs and does not require bulb replacement. The LEDs are designed for a long lifespan.
- **Inspection:** Periodically check for any loose connections or signs of damage. If any issues are found, turn off the power and consult a qualified electrician.

## 8. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power supply Loose wiring connection Faulty switch	Check circuit breaker and wall switch. Turn off power, check wire connections. Test the switch with another device or replace if faulty.
Light flickers or dims unexpectedly	Incompatible dimmer switch Loose wiring Voltage fluctuations	Ensure a compatible LED dimmer is used. Turn off power, check wire connections. Consult an electrician to check household voltage.
Incorrect color temperature	Color temperature switch set incorrectly	Turn off power, remove the fixture cover, and adjust the color temperature switch to the desired setting. Reinstall cover.
Light is too dim or too bright (without dimmer)	No dimmer installed or used	This fixture requires an external dimmer switch for brightness adjustment. If no dimmer is present, the light will operate at full brightness for the selected color temperature.

If the problem persists after trying these solutions, please contact customer support.

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact Brightever customer service. Keep your purchase receipt as proof of purchase.

Contact information for Brightever customer support can typically be found on the product packaging or the official Brightever website.