YESTEL T15

YESTEL T15 Android 13 Tablet User Manual

Model: T15

1. Introduction

Welcome to the YESTEL T15 Android 13 Tablet user manual. This guide provides essential information to help you get started with your new device, understand its features, and maintain optimal performance. The YESTEL T15 is an 11-inch tablet designed for both entertainment and productivity, featuring a high-resolution display, powerful processor, and ample storage.



The YESTEL T15 Android 13 Tablet, showcasing its sleek design.

Key Features:

- **Display:** 11-inch 2K (2000 x 1200) IPS FHD screen for detailed visuals.
- **Performance:** Octa-Core 2.0 GHz processor with 16GB RAM (8GB physical + 8GB virtual) for smooth multitasking.
- **Storage:** 256GB ROM, expandable up to 1TB via Micro SD card.
- **Operating System:** Android 13 for a secure and fluid user experience.
- **Battery:** 8600mAh large capacity battery with 18W USB-C fast charging.
- **Cameras:** 5MP front camera, 13MP rear camera, and 2MP macro camera.
- **Connectivity:** Dual-band 5G Wi-Fi, Bluetooth 5.0, and GPS.
- **Accessories:** Includes a wireless keyboard and mouse for enhanced productivity.

2. Setup Guide

2.1 Unboxing and Initial Power On

Carefully remove all components from the packaging. Ensure you have the tablet, charger, USB-C cable, wireless keyboard, and wireless mouse. Press and hold the power button located on the side of the tablet until the YESTEL logo appears on the screen. Follow the on-screen prompts to select your language and region.

2.2 Connecting to Wi-Fi

1. From the home screen, swipe down from the top to open the Quick Settings panel.
2. Tap and hold the Wi-Fi icon to open Wi-Fi settings.
3. Toggle Wi-Fi ON if it's off.
4. Select your desired network from the list of available networks.
5. Enter the network password if prompted and tap 'Connect'.



The tablet connected to Wi-Fi, demonstrating its use for video calls.

2.3 Google Account Setup

During the initial setup, you will be prompted to sign in with your Google account. This is necessary to access the Google Play Store, Gmail, and other Google services. If you don't have an account, you can create one during this step.

2.4 Pairing Keyboard and Mouse

The YESTEL T15 comes with a wireless keyboard and mouse. To pair them:

1. Ensure the keyboard and mouse are powered on and in pairing mode (refer to their individual manuals for specific instructions).
2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
3. Toggle Bluetooth ON.
4. The tablet will scan for nearby Bluetooth devices. Select the keyboard and mouse from the list to pair them.
5. Follow any on-screen prompts to complete the pairing process.



The YESTEL T15 tablet paired with its wireless keyboard and mouse, ready for productivity.

2.5 Expanding Storage with a Micro SD Card

The tablet supports Micro SD card expansion up to 1TB. Locate the Micro SD card slot on the side of the tablet. Gently insert the Micro SD card into the slot until it clicks into place. The tablet will recognize the new storage, and you can configure it for portable or internal storage as needed.


3. Operating Instructions

3.1 Basic Navigation and Gestures

- **Tap:** Select an item or open an app.
- **Swipe:** Navigate through screens, menus, or content.
- **Pinch-to-zoom:** Enlarge or shrink content like photos and web pages.
- **Long press:** Access contextual menus or move icons.

3.2 Android 13 Features

Your YESTEL T15 runs on Android 13, offering enhanced privacy controls, a customizable interface with widgets, and improved efficiency features like split-screen multitasking.



The YESTEL T15 tablet showcasing the Android 13 operating system with various applications.

3.3 Display and Audio

The 11-inch 2K IPS FHD display provides a rich visual experience. The tablet features automatic brightness adjustment to match ambient light, and eye protection modes to reduce blue light. Four high-quality speakers deliver clear and immersive audio.



The tablet's 2K display and powerful speakers provide an immersive gaming experience.

3.4 Camera Usage

The tablet is equipped with a triple camera system:

- **5MP Front Camera:** Ideal for video calls and selfies.
- **13MP Rear Camera:** For capturing high-resolution photos and videos.
- **2MP Macro Camera:** For detailed close-up shots.

Open the 'Camera' app to switch between modes and capture moments.



A detailed view of the YESTEL T15 tablet's triple camera system.

3.5 GPS Functionality

The integrated GPS allows for accurate location tracking and navigation. Use pre-installed map applications or download your preferred navigation apps from the Google Play Store.

3.6 Parental Control

Android 13 includes robust parental control features. You can set screen time limits, restrict app access, and monitor usage to ensure a safe digital environment for children. Access these settings through the 'Digital Wellbeing & parental controls' section in your tablet's settings.

4. Maintenance

4.1 Charging the Battery

The YESTEL T15 features an 8600mAh battery and supports 18W USB-C fast charging. Use the provided charger and USB-C cable for optimal charging speed. Connect the USB-C cable to the tablet's port and the charger to a power outlet. The battery indicator on the screen will show charging status.

4.2 Cleaning Your Tablet

To clean the screen, use a soft, lint-free cloth specifically designed for electronics. For the tablet body, a slightly damp cloth can be used. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the device.

4.3 Software Updates

Periodically check for system updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings > System > System update** to check for and install available updates.

4.4 Storage Management

Regularly manage your tablet's 256GB internal storage. Delete unnecessary files, uninstall unused apps, and move large media files to the Micro SD card or cloud storage to maintain optimal performance. You can check storage usage in **Settings > Storage**.

5. Troubleshooting

This section addresses common issues you might encounter with your YESTEL T15 tablet.

5.1 Tablet Not Powering On

- Ensure the battery is charged. Connect the tablet to the charger and wait a few minutes before attempting to power it on again.
- Press and hold the power button for at least 10-15 seconds to perform a forced restart.

5.2 Wi-Fi Connectivity Issues

- Toggle Wi-Fi off and on in Quick Settings.
- Restart your Wi-Fi router.
- Forget the network and reconnect by re-entering the password.
- Ensure you are within range of the Wi-Fi signal.

5.3 Slow Performance or Freezing

- Close unused applications running in the background.
- Clear app caches (**Settings > Apps > [App Name] > Storage > Clear cache**).
- Free up internal storage space.
- Restart the tablet.

5.4 Accessories Not Connecting

- Ensure the keyboard and mouse are charged and powered on.
- Re-pair the Bluetooth accessories (refer to Section 2.4).
- Check if other Bluetooth devices are interfering.

5.5 Factory Reset (Last Resort)

If issues persist, you may consider a factory reset. **Warning: This will erase all data on your tablet. Back up important data before proceeding.** Go to **Settings > System > Reset options > Erase all data (factory reset)**

6. Specifications

Below are the detailed technical specifications for the YESTEL T15 Android 13 Tablet:

Feature	Specification
Brand	YESTEL
Model Name	T15
Storage Capacity	256 GB ROM (expandable up to 1 TB with Micro SD)
RAM	16 GB (8 GB physical + 8 GB virtual)
Screen Size	11 inches
Max Display Resolution	2000 x 1200 Pixels (2K FHD IPS)
Operating System	Android 13
Color	Blue
Item Weight	517 Grams
Processor Speed	2.0 GHz
Processor Brand	MediaTek (Octa-Core)
Rear Camera	13 MP + 2 MP (Macro)
Front Camera	5 MP
Dimensions (L x W x H)	20L x 15W x 0.5H centimeters
Battery Capacity	8600 mAh (Lithium-polymer)
Connectivity	5G Wi-Fi, Bluetooth 5.0, GPS, Micro SD, USB Type C
USB Ports	1 (Type C)
Audio Formats Supported	MP3, AAC, WAV
Headphone Jack	USB Type C
Included Components	Tablet

7. Warranty and Support

YESTEL offers a comprehensive support policy for your T15 tablet:

- **Return Policy:** Enjoy a 30-day unconditional return policy from the date of purchase.
- **Warranty:** Your tablet is covered by a two-year warranty against manufacturing defects.
- **Technical Support:** Lifetime technical support is available for all YESTEL products.

For further assistance, please refer to the contact information provided with your product packaging or visit the official YESTEL website.

© 2026 YESTEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question