Pemberly Row PR-4753-2682880

Pemberly Row 3-Piece Traditional Solid Wood Breakfast Nook Set (Model PR-4753-2682880) - Instruction Manual

Brand: Pemberly Row | Model: PR-4753-2682880

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Pemberly Row 3-Piece Traditional Solid Wood Breakfast Nook Set. Designed for functionality and style, this set includes a table, two benches, and a foldable corner shelf, offering versatile seating and integrated storage solutions for your home. Please read these instructions carefully before assembly and use to ensure safe and proper operation.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the table or benches.
- Distribute weight evenly on benches and table. Avoid placing heavy objects on the edges.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not use power tools for assembly unless specifically instructed, as this may overtighten fasteners and damage the wood.

Product Features

- **Solid Mahogany Wood and Veneers:** Constructed for durability and a traditional aesthetic.
- **Multiple Configurations:** Benches are reversible to fit various kitchen or dining layouts.
- **Integrated Storage:** Lift-top seats on the benches provide convenient hidden storage space.

- **Two-Toned Finish:** Features a stylish gray and brown finish that complements diverse decor.
- **Foldable Corner Shelf:** Maximizes space utilization and offers additional display or storage.

Setup and Assembly

Assembly of the Pemberly Row Breakfast Nook Set is designed to be straightforward. It is recommended that two adults perform the assembly. Please ensure all parts are present before beginning.

Required Tools (Not Included):

- Phillips Head Screwdriver
- Allen Wrench (often included with hardware, verify package contents)

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Refer to the included parts list to identify each piece and ensure nothing is missing.
2. **Assemble the Table Base:** Attach the table legs to the central support structure using the provided hardware. Ensure all connections are firm but do not fully tighten until the table top is attached.
3. **Attach the Table Top:** Secure the table top to the assembled base. Once aligned, fully tighten all table hardware.
4. **Assemble the Benches:** For each bench, attach the backrest and side panels to the seat base. The benches are designed with lift-top seats for storage; ensure hinges are correctly aligned and secured.
5. **Configure the Nook:** Position the benches and table in your desired L-shape configuration. The benches are reversible, allowing for left or right-hand orientation.
6. **Install the Corner Shelf:** Secure the foldable corner shelf between the two benches in the corner.
7. **Final Tightening:** Once all components are in place and aligned, go back and securely tighten all fasteners on the entire set.



Image 1: Fully assembled Pemberly Row Breakfast Nook Set, showcasing the table, corner bench, and freestanding bench.



Image 2: The breakfast nook set positioned in a kitchen or dining area, demonstrating its space-saving design.

Operating Instructions

Using the Storage Benches:

The benches feature lift-top seats that reveal ample storage space underneath. To access the storage:

1. Gently lift the front edge of the bench seat.
2. The seat will pivot upwards on its hinges, providing access to the storage compartment.
3. To close, carefully lower the seat until it rests securely on the bench frame.



Image 3: The benches with their lift-top seats open, revealing the integrated storage compartments.

Reversible Configuration:

The corner bench unit can be assembled with the longer section on either the left or right side, allowing you to adapt the nook to your specific room layout. This flexibility ensures optimal space utilization.

Maintenance and Care

Proper care will extend the life and beauty of your breakfast nook set.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the wood finish.
- **Spills:** Promptly clean up spills to prevent staining. Use a dry cloth to blot liquids.
- **Protection:** Use placemats or coasters to protect the table surface from heat, moisture, and scratches.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or cracking of the wood.
- **Humidity:** Maintain a consistent humidity level in your home to prevent wood from expanding or contracting excessively.

Troubleshooting

If you encounter any issues with your breakfast nook set, please refer to the following common solutions:

- **Wobbly Table/Bench:** Check all assembly bolts and screws. Tighten any loose fasteners. Ensure the unit is on a level surface.
- **Difficulty Opening/Closing Storage:** Inspect hinges for any obstructions or misalignment. Ensure no items in the storage compartment are preventing the lid from closing properly.
- **Surface Scratches:** Minor scratches can sometimes be minimized with wood repair markers or polishes designed for furniture. For deeper scratches, professional repair may be necessary.

For issues not covered here, please contact Pemberly Row customer support.

Specifications

Brand	Pemberly Row
Model Number	PR-4753-2682880
Material	Solid Mahogany Wood and Veneers
Color	Dark Gray (with brown finish accents)
Product Dimensions (L x W x H)	56 x 75 x 36 inches
Item Weight	260 pounds
Special Features	Lift-top storage seats, reversible benches, foldable corner shelf
UPC	195493765274

Warranty and Support

For warranty information or customer support, please refer to your purchase documentation or contact Pemberly Row directly through their official website or the retailer where the product was purchased. Please have your model number (PR-4753-2682880) and proof of purchase available when contacting support.

© 2023 Pemberly Row. All rights reserved.