

## Marley EM-JH143-RA

# House of Marley Positive Vibration Frequency Wireless Headphones User Manual

Model: EM-JH143-RA

## INTRODUCTION

Thank you for choosing the House of Marley Positive Vibration Frequency Wireless Headphones. This manual provides detailed instructions to help you set up, operate, and maintain your headphones for an optimal audio experience. Please read this manual thoroughly before use and retain it for future reference.

## PACKAGE CONTENTS

Ensure all items are present in the package:

- House of Marley Positive Vibration Frequency Wireless Headphones
- USB-C Charging Cable
- Quick Start Guide (not included in this digital manual)
- Warranty Information (not included in this digital manual)

## PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your headphones.



Image 1: Front view of the House of Marley Positive Vibration Frequency headphones.



*Image 2: Side view of the headphones showing the control buttons and USB-C port.*

## **Controls and Ports:**

- **Power Button:** Located on the right earcup. Press and hold to power on/off.
- **Volume Up/Next Track Button:** Press to increase volume. Press and hold to skip to the next track.
- **Volume Down/Previous Track Button:** Press to decrease volume. Press and hold to go to the previous track.
- **Multi-function Button (Play/Pause/Call):** Press to play/pause music or answer/end calls. Double-press for voice assistant.
- **USB-C Charging Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection (cable not included).
- **Microphone:** Integrated for calls.

## SETUP

---

### 1. Charging the Headphones

1. Connect the supplied USB-C cable to the charging port on the headphones.
2. Connect the other end of the USB-C cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge takes approximately 2 hours.
4. A 15-minute quick charge provides up to 4 hours of playtime.
5. The headphones offer up to 34 hours of playtime on a full charge.

### 2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power Button for 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices and select "Positive Vibration Frequency" from the list.
5. Once connected, the LED indicator will turn solid blue.
6. The headphones will automatically reconnect to the last paired device when powered on, if within range.

### 3. Wired Connection (Optional)

If you prefer a wired connection or the battery is depleted, you can use a 3.5mm audio cable (not included) to connect your headphones to an audio source. Insert one end into the headphone's 3.5mm jack and the other into your device's audio output.

## OPERATING INSTRUCTIONS

---

### Power On/Off:

- **Power On:** Press and hold the Power Button for 3 seconds.
- **Power Off:** Press and hold the Power Button for 5 seconds.

### Music Playback:

- **Play/Pause:** Press the Multi-function Button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Up:** Press the Volume Up button.
- **Volume Down:** Press the Volume Down button.

Phone Calls:

- **Answer/End Call:** Press the Multi-function Button once.
- **Reject Call:** Press and hold the Multi-function Button for 2 seconds.
- **Activate Voice Assistant:** Double-press the Multi-function Button.

MAINTENANCE

Proper care ensures the longevity of your headphones.

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.
- **Battery Care:** To preserve battery life, charge the headphones regularly, even if not in frequent use. Avoid fully depleting the battery for extended periods.

TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source using the USB-C cable.
Cannot pair with device.	<ul style="list-style-type: none"><li>• Ensure headphones are in pairing mode (LED flashing blue/red).</li><li>• Turn off and on Bluetooth on your device.</li><li>• Forget "Positive Vibration Frequency" from your device's Bluetooth list and try pairing again.</li><li>• Ensure headphones are within 10 meters (33 feet) of your device.</li></ul>
No sound or low volume.	<ul style="list-style-type: none"><li>• Increase volume on both the headphones and your connected device.</li><li>• Ensure the headphones are properly paired.</li><li>• If using a wired connection, ensure the 3.5mm cable is fully inserted.</li></ul>
Poor sound quality.	<ul style="list-style-type: none"><li>• Move closer to your device to reduce interference.</li><li>• Avoid obstacles between the headphones and your device.</li><li>• Ensure the audio source quality is good.</li></ul>

SPECIFICATIONS

- **Model Name:** Positive Vibration Frequency
- **Model Number:** EM-JH143-RA
- **Connectivity:** Wireless (Bluetooth 5.2)
- **Driver Size:** 40mm Dynamic Drivers
- **Battery Life:** Up to 34 hours
- **Quick Charge:** 15 minutes charge for 4 hours playtime

- **Charging Port:** USB-C
- **Audio Jack:** 3.5 mm Jack
- **Frequency Range:** 20Hz - 20,000Hz
- **Material:** Aluminum, Plastic, FSC Certified Wood
- **Item Weight:** 0.57 Kilograms (1.25 pounds)
- **Dimensions:** 3.25 x 8.5 x 4.67 inches
- **UPC:** 846885011188

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official House of Marley website. Keep your proof of purchase for warranty claims.

**Manufacturer:** House of Marley




**Brand:** Marley



© 2023 House of Marley. All rights reserved.

Related Documents - EM-JH143-RA

	<p><a href="#">Marley Liberate Air True Wireless Earbuds Quick Start Guide</a></p> <p>Get started quickly with the Marley Liberate Air True Wireless Earbuds. This guide covers unboxing, setup, pairing, controls for music and calls, voice commands, mono mode, and important compliance information.</p>
	<p><a href="#">Stir It Up Lux Quick Start Guide</a></p> <p>A quick start guide for the Marley Stir It Up Lux turntable, covering setup, operation, Bluetooth pairing, and vinyl playback. Provides essential information for getting started with the device.</p>
	<p><a href="#">Marley Liberate Air True Wireless Earbuds Quick Start Guide</a></p> <p>A concise guide to setting up, pairing, fitting, and using your Marley Liberate Air true wireless earbuds, including controls, mono mode, and compliance information.</p>
	<p><a href="#">Marley Revolution with Speakers Quick Start Guide - Setup &amp; Bluetooth</a></p> <p>Get started with your Marley Revolution with Speakers Bluetooth turntable. This guide covers setup, tonearm balancing, speaker connection, record playback, and Bluetooth pairing for a seamless audio experience.</p>

 <b>INSTRUCTION MANUAL GET TOGETHER DUO</b>	<a href="#">Marley Get Together Duo Instruction Manual</a> This manual provides instructions for setting up, connecting, and troubleshooting the Marley Get Together Duo Bluetooth speaker system. Learn how to pair with mobile devices and turntables via Bluetooth, RCA, and AUX inputs.
 <b>QUICK START GUIDE STIR IT UP WIRELESS</b> 	<a href="#">Marley Stir It Up Wireless Turntable: Quick Start Guide</a> A comprehensive quick start guide for the Marley Stir It Up Wireless Turntable, covering setup, Bluetooth pairing, record playback, connections, and compliance information.

Documents - Marley – EM-JH143-RA



[\[pdf\]](#) Specifications Declaration of Conformity

Keith Wilkinson Bekijk de CE marking House of Marley Positive Vibration Frequency Bluetooth Koptelefoon Hoofdtelefoon bol original media s NnnM6W2p0QvK |||

Declaration of Conformity Product model/product product, type, batch or serial number : **EM-JH143-RA** Name and address of the manufacturer FKA Brands Ltd Somerhill Business Park, Five Oak Green Road, Tonbridge, Kent. TN11 0GP UK whose authorised EU representative is FKA Brands Ltd 29 Earlsfort Te...

lang:en score:21 filesize: 132.91 K page\_count: 1 document date: 2023-06-20