

[Manuals.plus](#) /

› [Moroccanoil](#) /

› Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush User Manual

Moroccanoil RIV001

Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush User Manual

Model: RIV001 | Brand: Moroccanoil

INTRODUCTION

The Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush is a versatile styling tool designed to combine the benefits of a round brush, blow-dryer, straightener, and curler. It aims to reduce hair damage while providing salon-quality results. This tool features advanced ionic technology to help smooth hair and boost shine, alongside far-infrared light which reduces heat exposure and locks in moisture. These technologies work together to minimize static and frizz, leaving hair shiny, frizz-free, and effortlessly styled.



Figure 1: The Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush.

SAFETY INFORMATION

Always read all instructions before use. This appliance is equipped with an ALCI (Appliance Leakage Circuit Interrupter) safety plug, which is a safety feature that renders the appliance inoperable under some abnormal conditions, such as immersion in water. This means the appliance is designed to reduce the risk of electric shock.

- Do not use near water.
- Unplug after use.
- Keep away from children.
- Do not operate with a damaged cord or plug.
- Do not block air openings.
- Always ensure the voltage is compatible with your power outlet.

SETUP

1. Unpack the Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush and ensure all components are present.
2. Inspect the power cord and plug for any signs of damage. Do not use if damaged.
3. Plug the ALCI safety plug into a standard electrical outlet.
4. Before first use, familiarize yourself with the heat and speed settings located on the handle.

OPERATING INSTRUCTIONS

The Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush can be used on damp or dry hair. For best results, ensure hair is towel-dried before use. Separate hair into manageable sections for easier styling.

General Usage

- Select the desired heat/speed setting (Low, High, Cool).
- Place the brush near the roots of a hair section and gently glide it down towards the ends.
- For added volume, lift the hair section at the roots and hold the brush for a few seconds before rolling outwards.
- For waves or curls, wrap the hair section around the brush and hold for a few seconds, then gently release.
- For a smooth finish, brush downwards from roots to ends.

Your browser does not support the video tag.

Video 1: Demonstrating how to achieve various looks (volumized, wavy, smooth) using the 4-in-1 Blow-Dryer Brush.

Your browser does not support the video tag.

Video 2: An introduction to the Moroccanoil Effortless Style 4-in-1 Blow-Dryer Brush, highlighting its features.

MAINTENANCE

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Use a soft, damp cloth to wipe down the handle and barrel. Remove any hair tangled in the bristles regularly to maintain performance.
- **Storage:** Store the brush in a cool, dry place. Do not wrap the cord around the appliance, as this can cause damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly, power outage, or ALCI tripped.	Ensure plug is fully inserted. Check power outlet. Reset ALCI plug by pressing the reset button.
Reduced airflow or overheating.	Air intake/outlet blocked by dust or hair.	Unplug and allow to cool. Clean any obstructions from the air vents.
Hair is not smooth or still frizzy.	Hair not sufficiently damp/dry, incorrect technique, or product not activated.	Ensure hair is towel-dried or completely dry. Use smaller sections. Ensure Frizz Shield Spray (if used) is heat-activated.

SPECIFICATIONS

Feature	Detail
Model Number	RIV001
Manufacturer	Moroccanoil
Product Dimensions	13.31 x 34.8 x 4.33 inches
Item Weight	1 Pound
Wattage	1000 watts
Power Source	Corded Electric
Special Features	ALCI Safety Plug, Ionic Technology, Far-Infrared Light, Lightweight
Hair Type Compatibility	Dry, All
Material Type	Nylon

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included in your product packaging or contact Moroccanoil customer support directly. Protection plans are available for purchase separately through retailers like Amazon, offering extended coverage for 2 or 3 years, or a monthly "Complete Protect" plan. For further assistance or inquiries, please visit the official Moroccanoil website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question