

TRIUMPHKEY 0193

TRIUMPHKEY Height Adjustable Desk User Manual

Model: 0193

Brand: TRIUMPHKEY

1. INTRODUCTION

Thank you for choosing the TRIUMPHKEY Height Adjustable Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before use and retain them for future reference.

This desk is designed to provide a versatile and ergonomic workspace, allowing you to switch between sitting and standing positions with ease. It features a robust electric lifting system, memory presets, a USB charging port, and an anti-collision mechanism for enhanced safety.

2. SAFETY INSTRUCTIONS

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- The maximum recommended weight capacity for this height-adjustable desk is 27 kg (approximately 60 lbs). Do not exceed this limit.
- Ensure the desk operates smoothly without wobbling or collisions during height adjustments.
- Keep children and pets away from the desk during operation to prevent accidents.
- Do not place hands or other body parts near moving parts of the desk frame during adjustment.
- Ensure all cables are properly managed and secured to prevent entanglement or damage during desk movement. Use the provided side hook for cable management.
- Only use the power adapter supplied with the desk.
- Do not disassemble or modify the desk's electrical components. Contact qualified service personnel for repairs.
- Place the desk on a level and stable surface.
- Avoid spilling liquids on the control panel or electrical components.



Image: The TRIUMPHKEY Height Adjustable Desk in a typical office setup, showcasing its spacious desktop and integrated features like cable management and USB port.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. Refer to the separate assembly manual included in your package for a detailed list and illustrations of parts.

- Desktop surface (180 x 80 cm)
- Electric lifting columns (2 units)
- Desk feet/bases (2 units)
- Control panel with USB charging port
- Power adapter and cable
- Cable management hook
- Assembly hardware (screws, tools, etc.)
- User Manual (this document)
- Assembly Guide

4. ASSEMBLY INSTRUCTIONS

Detailed assembly instructions are provided in a separate guide included with your product. Please follow the step-by-step illustrations and instructions carefully to ensure correct and safe assembly.

1. Unpack all components and verify against the package contents list.
2. Assemble the desk frame according to the provided diagrams.
3. Attach the desktop surface to the assembled frame.
4. Install the control panel and connect all necessary cables to the motor and power supply.
5. Secure the cable management hook.
6. Before first use, ensure all screws are tightened and the desk is stable.



Image: The TRIUMPHKEY Height Adjustable Desk positioned in a bright, modern room, demonstrating its aesthetic integration into various environments.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The desk's height can be adjusted electrically between 72 cm and 118 cm. Use the UP (▲) and DOWN (▼) buttons on the control panel to manually adjust the desk to your desired height.

5.2 Memory Presets

The control panel features 3 memory preset buttons (1, 2, 3) to save and recall your preferred sitting and standing heights.

1. **To Save a Height:** Adjust the desk to your desired height using the UP/DOWN buttons. Press the "M" button, then immediately press one of the number buttons (1, 2, or 3) until you hear a beep or see a confirmation on the display. The current height is now saved to that preset.
2. **To Recall a Height:** Simply press the corresponding number button (1, 2, or 3). The desk will automatically move to the saved height.

5.3 USB Charging Port

A convenient USB charging port is integrated into the control panel, allowing you to charge mobile phones and other electronic devices directly from your desk.



Image: A tablet connected to the integrated USB charging port on the desk's control panel, illustrating the charging functionality.

5.4 Sedentary Reminder

The desk includes a sedentary reminder function to encourage regular movement. This feature can be activated or deactivated via the control panel (refer to the detailed assembly guide for specific instructions on setting this feature).

5.5 Anti-Collision System

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage or injury.



Image: A visual representation of the anti-collision system, where the desk detects an object (like a drawer) and stops its movement to prevent impact.

6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Regularly check and organize cables using the integrated cable management system and side hook to prevent tangles and ensure smooth operation.
- **Inspection:** Periodically check all screws and connections to ensure they are secure. Tighten if necessary.
- **Motor Care:** The motor is designed for durability. Avoid overloading the desk beyond its specified weight capacity to prolong motor life.

Underdesk Cable Management

Neat and Tidy



Image: A view of the under-desk cable management tray, demonstrating how wires can be kept neat and tidy, contributing to a clutter-free workspace.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected. Control panel not properly connected. Overload.	Check power connections. Ensure all cables are securely plugged in. Reduce weight on the desk.
Desk moves unevenly or makes unusual noise.	Loose connections or screws. Obstruction.	Check and tighten all assembly screws. Remove any obstructions.

Problem	Possible Cause	Solution
Anti-collision system frequently triggers.	Sensitivity too high. Obstacles in the path.	Adjust anti-collision sensitivity (refer to assembly guide). Clear the area around the desk.
USB charging port not working.	Desk not powered on. Device cable faulty.	Ensure desk is connected to power and turned on. Try a different USB cable or device.

8. SPECIFICATIONS

Feature	Detail
Brand	TRIUMPHKEY
Model Number	0193
Desk Design	Standing Desk
Color	Brown + White
Product Dimensions (L x W x H)	180 cm x 80 cm x 72-118 cm (adjustable height)
Desktop Material	Engineered Wood (Laminated finish)
Frame Material	Alloy Steel
Item Weight	23 Kilograms
Maximum Load Capacity	70 kg (Motor tested), 27 kg (Recommended for stability)
Motor Noise Level	< 50 dB
Features	3 Memory Presets, USB Charging Port, Anti-Collision System, Sedentary Reminder, Cable Management Hook

Larger Size for More Practicality

ⓐ Length: 180cm Width: 80cm



Image: A detailed view of the desk surface highlighting its dimensions: 180 cm in length and 80 cm in width, emphasizing its spacious design.

9. WARRANTY AND SUPPORT

TRIUMPHKEY products are manufactured to high-quality standards. For warranty information, technical support, or replacement parts, please refer to the warranty card included with your purchase or contact TRIUMPHKEY customer service directly. Contact details can typically be found on the brand's official website or through your point of purchase. Please have your model number (0193) and purchase date ready when contacting support.

© 2023 TRIUMPHKEY. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question