

[Manuals.plus](#) /

› [ECONTROLLY](#) /

› ECONTROLLY TRM-WSB600 Replacement Remote Control User Manual for Toshiba TY-WSB600 Soundbar

ECONTROLLY TRM-WSB600

ECONTROLLY TRM-WSB600 Replacement Remote Control User Manual

For Toshiba TY-WSB600 2.1-Channel Soundbar System

1. PRODUCT OVERVIEW

The ECONTROLLY TRM-WSB600 is a dedicated infrared replacement remote control designed for seamless operation with the **Toshiba TY-WSB600 2.1-Channel Soundbar System**. This remote provides direct functionality without the need for complex programming, offering a straightforward solution for controlling your soundbar's features.



Figure 1: Front view of the ECONTROLLY TRM-WSB600 Replacement Remote Control.

2. SETUP AND BATTERY INSTALLATION

The TRM-WSB600 remote control operates using standard AAA batteries. Follow these steps to install the batteries and begin using your remote.

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Gently slide or press the latch to open the cover.
2. **Insert Batteries:** Insert **one (1) AAA battery** into the compartment. Ensure the positive (+) and negative (-) terminals of the battery align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
3. **Close the Battery Compartment:** Replace the battery cover by sliding it back into position until it clicks securely.
4. **Initial Use:** The remote is an infrared (IR) type and typically does not require programming or pairing with the

Toshiba TY-WSB600 soundbar. Once batteries are installed, point the remote directly at the soundbar and test its functions.



Figure 2: Back view of the remote control, indicating the battery compartment.

3. OPERATING INSTRUCTIONS

The TRM-WSB600 remote control provides access to all essential functions of your Toshiba TY-WSB600 soundbar. Below is a description of the primary buttons and their uses.






Figure 3: Detailed view of the remote control buttons.

- **Power Button:** Turns the soundbar on or off.
- **Mute Button:** Mutes or unmutes the soundbar's audio output.
- **Volume Up (VOL+) / Volume Down (VOL-):** Adjusts the soundbar's volume level.
- **Input Selection Buttons (AUX, OPTICAL, COAXIAL, HDMI ARC, BT):** Selects the audio input source for the soundbar.
 - **AUX:** Auxiliary input.
 - **OPTICAL:** Optical digital audio input.
 - **COAXIAL:** Coaxial digital audio input.
 - **HDMI ARC:** HDMI Audio Return Channel input.
 - **BT:** Bluetooth input for wireless audio streaming.
- **Playback Controls (Play/Pause / PAIR, Previous Track, Next Track):**
 - **Play/Pause / PAIR:** Starts or pauses playback. When in Bluetooth mode, this button may also initiate pairing.
 - **Previous Track:** Skips to the beginning of the current track or the previous track.
 - **Next Track:** Skips to the next track.
- **Sound Mode Buttons (NEWS, MOVIE, MUSIC):** Selects preset equalizer modes optimized for different audio content.
 - **NEWS:** Enhances vocal clarity for news broadcasts.
 - **MOVIE:** Provides a dynamic soundstage for movies.
 - **MUSIC:** Optimizes audio for music playback.

4. MAINTENANCE

- **Battery Replacement:** Replace the AAA battery when the remote's range decreases or it stops responding. Always use a fresh, high-quality AAA battery. Do not mix old and new batteries, or different types of batteries.
- **Cleaning:** To clean the remote, wipe it with a soft, dry cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the remote's surface or internal components.
- **Storage:** If the remote will not be used for an extended period, remove the battery to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight.

5. TROUBLESHOOTING

If you experience issues with your TRM-WSB600 replacement remote control, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote is not responding.	- Dead or incorrectly inserted battery. - Obstruction between remote and soundbar. - Remote is out of range.	- Replace the AAA battery, ensuring correct polarity (+/-). - Ensure a clear line of sight between the remote's IR emitter and the soundbar's IR receiver. - Move closer to the soundbar (within approximately 20 feet or 6 meters).
Remote functions are intermittent.	- Low battery power. - Interference from other electronic devices.	- Replace the battery. - Move the soundbar or remote away from other devices that might cause interference.
Remote does not "pair" or "sync" with the soundbar.	- Misconception about remote type. - Compatibility issue.	- This remote is an infrared (IR) replacement remote and is designed to work directly with the Toshiba TY-WSB600 soundbar without any programming or "pairing" steps. It functions by sending IR signals, similar to the original remote. - Ensure your soundbar model is specifically the Toshiba TY-WSB600. This remote is not a universal remote and is only compatible with the specified model. - If the soundbar requires a specific pairing procedure for its original remote (e.g., for Bluetooth functions), this replacement remote may not replicate that specific pairing process for the soundbar itself, but its IR functions should work directly. The "PAIR" button on this remote is typically for initiating Bluetooth pairing on the soundbar, not for pairing the remote to the soundbar.

6. SPECIFICATIONS

- **Model:** TRM-WSB600
- **Compatibility:** Toshiba TY-WSB600 2.1-Channel Soundbar System
- **Remote Type:** Infrared (IR)
- **Power Source:** 1 x AAA Battery (not included)
- **Dimensions:** 2.36 x 1.57 x 0.2 inches (approximately 6 x 4 x 0.5 cm)
- **Weight:** 0.635 ounces (approximately 18 grams)
- **Color:** Black

7. WARRANTY AND SUPPORT

For any questions or assistance regarding your ECONTROLLY TRM-WSB600 replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific warranty details, if applicable.

The manufacturer's product description states: "If any questions, please feel free to contact us."

