

- Manuals.plus /
- › Moimhear /
- › Moimhear Double Bunk Bed with Slide and Ladder User Manual

Moimhear WX000117

Moimhear Double Bunk Bed with Slide and Ladder User Manual

Model: WX000117 | Brand: Moimhear

1. INTRODUCTION

This user manual provides comprehensive instructions for the assembly, safe operation, and maintenance of your Moimhear Double Bunk Bed with Slide and Ladder. Please read this manual thoroughly before assembly and use to ensure safety and proper functionality. Keep this manual for future reference.



Figure 1.1: Fully assembled Moimhear Double Bunk Bed with Slide and Ladder, showcasing its house-shaped design, integrated slide, and side ladder.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in serious injury.

- **Weight Capacity:** The maximum weight capacity for this bunk bed is 120 kg (approximately 265 lbs). Do not exceed this limit.
- **Age Recommendation:** The upper bunk is not suitable for children under 6 years of age.
- **Supervision:** Always supervise children when they are using the bunk bed, especially the slide and ladder.
- **Guardrails:** Ensure guardrails are always in place on the upper bunk. Do not remove them.
- **Mattress Size:** Use only mattresses that are 90 x 200 cm and do not exceed the maximum mattress thickness

indicated in the assembly instructions to ensure proper guardrail height.

- **Prohibited Activities:** Do not allow jumping on the bed. Do not attach or hang items on any part of the bunk bed that are not designed for use with the bed, e.g., hooks, ropes, etc.
- **Assembly:** This product requires assembly by adults. Ensure all fasteners are tightened securely before use.
- **Ventilation:** The semi-enclosed design provides a cozy sleeping environment while maintaining air circulation.

3. PARTS LIST

Before beginning assembly, please ensure all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Bed Frame Components (Headboards, Footboards, Side Rails for both upper and lower bunks)
- Roof Frame Components
- Slats (14 pieces)
- Ladder (3-step)
- Slide
- Hardware Pack (Screws, bolts, nuts, washers, Allen key)
- Assembly Manual (this document)

Note: Small parts should be kept away from young children during assembly.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended that two adults assemble the bunk bed. Please follow the steps carefully.

Tools Required:

- Phillips Head Screwdriver (not included)
- Allen Key (included in hardware pack)

Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a carpet or blanket) to prevent scratching. Identify each part using the provided parts list.
2. **Assemble Bed Frames:** Begin by assembling the main frame for both the upper and lower bunks. Attach the side rails to the headboards and footboards using the provided hardware. Ensure all connections are secure but do not fully tighten until the entire frame is assembled.
3. **Attach Roof Frame:** Connect the house-shaped roof frame components to the upper bunk frame.
4. **Install Slats:** Place the 14 wooden slats onto the designated supports for both the upper and lower bunks. Secure them in place as per the instructions.
5. **Attach Ladder:** Securely attach the 3-step ladder to the side of the upper bunk. The ladder can be positioned on either the left or right side.

6. **Attach Slide:** Securely attach the slide to the upper bunk. The slide can also be positioned on either the left or right side, opposite to the ladder or on the same side if desired.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws and bolts. Do not overtighten.
8. **Safety Check:** Before first use, double-check all connections to ensure they are tight and stable.



Figure 4.1: View of the upper bunk frame with wooden slats installed, illustrating the mattress support structure.

5. OPERATING INSTRUCTIONS

- **Sleeping:** The bunk bed is designed to accommodate two standard 90 x 200 cm mattresses. Ensure mattresses fit snugly within the frame.
- **Ladder Use:** Always use the ladder to access the upper bunk. Ensure hands and feet are dry to prevent slipping.
- **Slide Use:** The slide is intended for supervised play. Ensure the area around the slide exit is clear before use. Only one child should use the slide at a time.
- **Reversible Components:** The ladder and slide can be installed on either the left or right side of the bed during assembly to best suit your room layout.

6. MAINTENANCE

- **Cleaning:** Wipe the bed frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Regular Checks:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary.
- **Inspection:** Inspect the bed for any signs of wear, damage, or loose parts. Address any issues immediately to prevent accidents.
- **Ventilation:** Ensure adequate air circulation around the bed to prevent moisture buildup.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose bolts or screws.	Check and tighten all assembly hardware. Ensure all connections are secure.
Parts do not align during assembly.	Incorrect orientation of parts or overtightened screws.	Loosen all screws slightly, realign parts, then retighten. Refer to assembly diagrams.
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all bolts. If squeaking persists, apply a small amount of paraffin wax or silicone spray to contact points between wood components.

8. SPECIFICATIONS

Feature	Specification
Model Number	WX000117
Brand	Moimhear
Color	White
Overall Product Dimensions (L x W x H)	205 cm x 220 cm x 180 cm (80.7 in x 86.6 in x 70.9 in)
Bed Dimensions (L x W)	200 cm x 90 cm (78.7 in x 35.4 in)
Height	180 cm (70.9 in)
Material	Pine Wood, MDF (Medium-Density Fiberboard), Plywood
Number of Slats	14
Product Weight	36.78 kg (81.08 lbs)
Weight Capacity	120 kg (265 lbs)
Assembly Required	Yes

Einheit: CM




Figure 8.1: Technical drawing illustrating the key dimensions of the bunk bed, including overall length, width, height, and specific measurements for the slide and ladder.

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product issues, please contact the retailer or manufacturer's customer support. Please have your model number (WX000117) and purchase information ready when contacting support.

© 2024 Moimhear. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CCMN2YKN>

More documents and user manuals: **<https://manuals.plus/>**