

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Coaster Fine Furniture](#) /
- › [Coaster Home Furnishings Alcott 45" Round Dining Table Instruction Manual](#)

Coaster Fine Furniture Alcott 120400

Coaster Home Furnishings Alcott 45" Round Dining Table Instruction Manual

Brand: Coaster Fine Furniture | Model: Alcott 120400

INTRODUCTION

This manual provides essential information for the safe and proper assembly, operation, and maintenance of your Coaster Home Furnishings Alcott 45" Round Dining Table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Alcott dining table is designed to elevate your modern dining space, offering comfortable seating for up to four people. Its mid-century modern design, featuring a faux Carrara marble top and a chrome metal base, is both durable and easy to clean. The compact round shape makes it suitable for various dining areas, including kitchens, breakfast nooks, or smaller dining spaces.

SAFETY INFORMATION

- Always assemble according to the instructions.
- Do not exceed the maximum weight recommendation of 300 pounds.
- Ensure the table is stable and placed on a level surface to prevent tipping or collapse.
- Keep small parts away from children during assembly.

PARTS LIST

Please verify that all components are present before beginning assembly. The package should include:

- Dining Table Top (Faux Carrara Marble)
- Chrome Metal Base Components
- Assembly Hardware (screws, bolts, washers, Allen wrench)

If any parts are missing or damaged, please contact customer support before proceeding with assembly.

SETUP

Assembly is required for this dining table. It is recommended to assemble the table on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

1. Unpack all components and hardware. Place them on a soft, flat surface.
2. Attach the metal base components together using the provided hardware. Ensure all connections are secure but do not overtighten.
3. Carefully place the dining table top upside down on the soft surface.
4. Align the assembled metal base with the pre-drilled holes on the underside of the table top.
5. Secure the base to the table top using the remaining hardware. Tighten all screws evenly until snug.
6. With assistance, carefully flip the assembled table upright.
7. Adjust the leveling feet on the base, if applicable, to ensure the table is stable and does not wobble.



The Coaster Home Furnishings Alcott 45" Round Dining Table.

OPERATING INSTRUCTIONS

The Alcott dining table is designed for everyday dining and social gatherings. Its round shape promotes easy conversation and interaction among guests.

- **Seating:** The table comfortably seats up to 4 people.
- **Placement:** Position the table in your desired dining area, ensuring adequate space for chairs and movement around it.
- **Stability:** Always ensure the table is stable before placing items on it or using it for dining.

MAINTENANCE

Proper care will help maintain the beauty and longevity of your dining table.


- **Cleaning the Table Top:** The faux Carrara marble top is easy to clean. Wipe spills immediately with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe dry. Avoid abrasive cleaners, harsh chemicals, or solvents as they may damage the finish.
- **Cleaning the Metal Base:** Wipe the chrome metal base with a soft, dry cloth. Avoid using abrasive materials or chemicals that could scratch or tarnish the finish.
- **General Care:** Avoid placing hot items directly on the table surface; always use coasters or placemats. Do not drag heavy objects across the table top. Periodically check and tighten all hardware connections to ensure stability.

TROUBLESHOOTING

- **Wobbling Table:** If the table wobbles, check that it is placed on a level surface. Adjust the leveling feet on the base by turning them clockwise or counter-clockwise until the table is stable. Also, ensure all assembly screws are securely tightened.
- **Loose Connections:** Over time, screws may loosen. Periodically inspect all hardware and tighten as necessary using the provided Allen wrench.
- **Surface Scratches:** While the faux marble top is durable, excessive force or sharp objects can cause scratches. Use placemats and coasters to protect the surface. Minor scratches may be reduced with specialized furniture repair kits (not included).

SPECIFICATIONS

Feature	Detail
Brand	Coaster Fine Furniture
Model Name	Alcott
Model Number	120400
Product Dimensions	45"D x 45"W x 30.5"H
Item Weight	48.5 Pounds
Maximum Weight Recommendation	300 Pounds
Frame Material	Metal
Top Material Type	Faux Marble
Color	Faux Carrara Marble
Shape	Round
Seating Capacity	4
Required Assembly	Yes



Detailed dimensions of the dining table.

WARRANTY

This product is covered by a 1-year limited manufacturer warranty. For specific details regarding warranty coverage and claims, please refer to the warranty information included with your product packaging or contact Coaster Fine Furniture customer service.

CUSTOMER SUPPORT

For any questions, assistance with assembly, or to report missing/damaged parts, please contact Coaster Fine Furniture customer support. Refer to the contact information provided in your product packaging or visit the official Coaster Fine Furniture website for support options.