

Homall 01

Homall Electric Standing Desk Model 01 (140x60cm, White) User Manual

Model: 01 | Dimensions: 140x60cm | Color: White

1. INTRODUCTION

Welcome to your new Homall Electric Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your desk. Please read these instructions carefully before use and retain them for future reference.

Safety Information

- Do not exceed the maximum weight capacity of 50 kg (110 lbs) on the desktop.
- Ensure the desk is placed on a level surface and properly anchored to prevent tipping.
- Keep children and pets away from the desk during operation to prevent injury.
- Avoid placing liquids directly on the control panel or near electrical components.
- Do not disassemble or modify the desk's electrical components. Contact customer support for service.
- Ensure there are no obstructions in the desk's path during height adjustment.

2. SETUP AND ASSEMBLY

The Homall Electric Standing Desk is designed for straightforward assembly. All necessary tools and detailed instructions are included in the packaging. The desktop is composed of multiple sections that fit together precisely using dowels and screws.

Assembly Steps Overview:

- Unpack all components and verify against the parts list provided in the assembly guide.
- Assemble the desktop sections using the provided dowels and screws. Ensure a flush and secure fit.
- Attach the lifting columns to the desktop using the designated hardware.
- Install the foot supports onto the lifting columns.
- Mount the control panel and motor unit according to the instructions.
- Connect all electrical cables as indicated in the assembly guide.
- Perform an initial test of the height adjustment function.



Figure 2.1: Fully assembled Homall Electric Standing Desk.

3. OPERATING INSTRUCTIONS

Your Homall Electric Standing Desk features an intuitive control panel for easy height adjustment and personalized settings.

Control Panel Functions:

DESIGN ULTRA SILENCIEUX



Figure 3.1: Control Panel with USB charging port.

- **Height Adjustment:** Use the + (Up) and - (Down) buttons to smoothly adjust the desk height between 73 cm and 118 cm. The current height is displayed on the LCD screen.
- **Memory Presets:** The desk supports 3 programmable height memory positions. To save a position: Adjust the desk to your desired height, then press the **M** button followed by **1**, **2**, or **3**. To recall a saved position, simply press the corresponding number button (**1**, **2**, or **3**).
- **Sedentary Reminder:** Activate the sedentary reminder function to receive alerts to change your working posture. Refer to the detailed assembly guide for specific activation and setting instructions.
- **USB Charging Port:** A convenient USB port is integrated into the control panel for charging mobile devices or powering small accessories.
- **Anti-Collision Technology:** The desk is equipped with an anti-collision system that automatically stops and slightly reverses the desk's movement if it encounters an obstruction during height adjustment, enhancing safety.



Figure 3.2: Height adjustment range from 73 cm to 118 cm.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Homall Electric Standing Desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure all cables are neatly managed and not pinched or tangled, especially during height adjustments.
- **Motor Care:** The motor is designed for quiet and stable operation. Avoid overloading the desk, which can strain the motor.

5. TROUBLESHOOTING

If you encounter issues with your Homall Electric Standing Desk, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move up or down.	Power cable disconnected, motor error, overload.	Check power connection. Unplug and replug the desk. Reduce weight on the desktop. Refer to the full manual for error codes.
Desk moves unevenly or makes unusual noises.	Uneven load, loose connections, obstruction.	Distribute weight evenly. Check and tighten all assembly screws. Ensure no objects are interfering with the lifting columns.
Memory presets are not working.	Incorrect saving procedure.	Ensure you press 'M' then the number button to save. To recall, press only the number button.
Anti-collision feature triggers frequently.	Obstruction in path.	Clear any objects above or below the desk that might be causing interference.

If the problem persists after attempting these solutions, please contact Homall customer support for further assistance.

6. SPECIFICATIONS

Detailed technical specifications for the Homall Electric Standing Desk Model 01 (140x60cm, White).

Brand: Homall

Model Number: 01

Color: White

Product Dimensions (L x W x H): 140 cm x 60 cm x 73-118 cm

Adjustable Height Range: 73 cm to 118 cm

Maximum Weight Capacity: 50 kg

Material: Alloy Steel (frame), Painted finish (desktop)

Special Features: Ergonomic, Adjustable, Electric, USB Charging Port, Sedentary Reminder, 3 Memory Positions, Anti-collision Technology

Noise Level: Approximately 55 dB during operation (comparable to quiet conversation)

Item Weight: Approximately 25.5 kg

DIMENSIONS DE LA TABLE



Figure 6.1: Desk Dimensions.

DIFFÉRENTES HAUTEURS POUR TOUTES LES CRÉATIONS

Hauteur de 73 cm à 118 cm



Figure 6.2: Motor Noise Level Comparison.

7. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Homall customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can typically find support contact information on the Homall official website or through the retailer where you purchased the product.