

[Manuals.plus](#) /

> [YeeSite](#) /

> YeeSite 5-in-1 DJ Party Bar Light Set with Stand, Model YS-5IN1 Instruction Manual

YeeSite YS-5IN1

YeeSite 5-in-1 DJ Party Bar Light Set with Stand

Model: YS-5IN1

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective operation, setup, and maintenance of your YeeSite 5-in-1 DJ Party Bar Light Set. This versatile lighting system integrates a rotating disco ball, UV light, strobe light, pattern light, and par light into a single unit, designed for various event settings.

SAFETY INFORMATION

Please read and understand all safety warnings and operating instructions before using this product. Retain this manual for future reference.

- **Electrical Safety:** Ensure the power supply voltage matches the product's requirements (220V). Do not expose the unit to rain or moisture. Disconnect power before cleaning or servicing.
- **Placement:** Position the light on a stable, level surface or securely mount it using the provided tripod. Ensure adequate ventilation around the unit to prevent overheating.
- **Eye Safety:** Avoid direct eye exposure to the light source, especially the laser components, as this may cause eye damage.
- **Children:** Keep this device out of reach of children.
- **Maintenance:** Refer to the maintenance section for proper care. Do not attempt to repair the unit yourself; contact qualified service personnel.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x YeeSite 5-in-1 DJ Party Bar Light Unit
- 1 x Tripod Lighting Stand
- 1 x Remote Controller
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The YeeSite 5-in-1 DJ Party Bar Light Set combines multiple lighting effects into a single, portable unit. Below is an illustration of the main unit and its components.







Figure 1: Complete YeeSite 5-in-1 DJ Party Bar Light Set with Stand and Remote Control.



Figure 2: Detailed view of the light unit components, including Rotating RGB Ball Light, UV/White Strobe Light, Red & Green Pattern Light, Colorful Par Light, Cooling Fan, Mic, and Sound/Auto/OFF switch. Dimensions are also indicated.

The unit features:

- **Rotating Disco Balls:** Two multi-color RGB rotating disco balls for dynamic room coverage.
- **UV Light:** Blacklight effect for glowing materials.
- **Strobe Light:** White strobe effect for pulsating light.
- **Pattern Light:** Red and green laser patterns.

- **Par Light:** Colorful LED par lights for wash effects.

5-IN-1 DJ PARTY LIGHT

2 ROTATING RGB DISCO BALL LIGHT



Figure 3: Visual representation of the individual lighting effects: Blacklight, White Strobe, Red & Green Pattern, and RGB Par Light.

SETUP

Follow these steps to set up your DJ Party Bar Light:

1. **Assemble the Tripod Stand:** Extend the legs of the tripod stand to a stable position. Adjust the height to your desired level, up to a maximum of 62 inches, and secure the locking mechanisms.
2. **Attach the Light Unit:** Securely mount the 5-in-1 DJ Party Bar Light unit onto the top of the tripod stand using the integrated bracket and tightening knob. Ensure the unit is firmly attached and stable.
3. **Connect Power:** Plug the power cord into the light unit and then into a standard electrical outlet (220V).



Figure 4: The DJ Party Bar Light unit mounted on its adjustable tripod stand, ready for operation.

OPERATING INSTRUCTIONS

The YeeSite 5-in-1 DJ Party Bar Light can be operated using the included remote control or via the switch on the unit.

Powering On/Off

Locate the **Sound/Auto/OFF** switch on the back of the light unit (refer to Figure 2). Slide the switch to the desired mode (Sound or Auto) to power on the unit. Slide to OFF to power off.

Remote Control Functions

The remote control allows for convenient adjustment of modes, brightness, and speed.



Figure 5: Remote control for the YeeSite 5-in-1 DJ Party Bar Light, showing buttons for power, auto mode, sound mode, specific light effects (Par, UV, Laser, Strobe, Motor), and speed/sensitivity adjustments.

- **Power Button:** Turns the unit on or off.
- **Auto:** Activates automatic light show mode.
- **Sound:** Activates sound-activated mode, where lights react to music.
- **Par:** Controls the colorful par lights.
- **UV:** Controls the UV (blacklight) effect.
- **Laser:** Controls the red and green pattern lights.
- **Strobe:** Controls the white strobe light.
- **Motor:** Controls the rotation of the disco balls.
- **Speed/Sensitivity Buttons:** Adjusts the speed of effects or sensitivity of sound activation.

Operating Modes



Figure 6: The three primary operating modes: Remote control, Automatic, and Sound-Activated.

- **Auto Mode:** The light unit cycles through various pre-programmed light shows automatically. Select this mode using the switch on the unit or the remote.
- **Sound-Activated Mode:** The lights respond to ambient sound and music, creating dynamic effects synchronized with the beat. Select this mode using the switch on the unit or the remote.
- **Remote Control Mode:** Use the remote to manually select and combine different lighting effects, adjust speeds, and customize your light show.



Figure 7: The light unit operating in sound-activated mode, projecting colorful patterns that synchronize with music.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your light set.

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the exterior of the unit. Do not use abrasive cleaners or solvents. Keep the lenses and light output areas free of dust and debris.
- **Storage:** When not in use, store the light set in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the power cord for any damage. If damage is found, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter issues with your YeeSite 5-in-1 DJ Party Bar Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light unit does not power on.	No power, loose connection, power switch in OFF position.	Ensure power cord is securely plugged in. Check the power outlet. Slide the Sound/Auto/OFF switch to Sound or Auto.
Remote control is not working.	Battery depleted, obstruction, remote too far.	Replace the remote control battery. Ensure no obstructions between remote and unit. Operate within effective range.
Sound-activated mode is not responding.	Low sound volume, microphone obstructed, sensitivity too low.	Increase music volume. Ensure the microphone on the unit is not covered. Adjust sound sensitivity using the remote.
Lights are dim or flickering.	Power fluctuation, unit overheating.	Ensure stable power supply. Check for proper ventilation around the unit. Allow unit to cool down if hot.

SPECIFICATIONS

Key technical specifications for the YeeSite 5-in-1 DJ Party Bar Light Set:

- **Model:** YS-5IN1
- **Dimensions (Light Unit):** 10"L x 5"W x 3"H
- **Max Tripod Height:** 62 inches
- **Item Weight:** 4.99 pounds (2.27 Kilograms)
- **Power Source:** Corded Electric
- **Voltage:** 220 Volts
- **Light Source Type:** Light Emitting Diode (LED)
- **Number of Light Sources:** 5 (Disco Ball, UV, Strobe, Pattern, Par)
- **Bulb Features:** Sound Activated, Multiple Lighting Effects (Disco Ball, Par Lights, Pattern Lights, Strobe, UV), Adjustable Speeds and Modes
- **Material:** Plastic
- **Mounting Type:** Tripod Mount

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official YeeSite website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CCNYR7L9>

More documents and user manuals: <https://manuals.plus/>