Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Ardes /
- > ARDES ARFRYA05L INFINITY 8L Air Fryer User Manual

Ardes ARFRYA05L

ARDES ARFRYA05L INFINITY 8L Air Fryer User Manual

Model: ARFRYA05L

1. Introduction

Thank you for choosing the ARDES ARFRYA05L INFINITY 8L Air Fryer. This appliance is designed to provide a healthy and convenient way to cook your favorite foods with significantly less oil. Its compact design and extra-deep basket make it ideal for preparing a variety of dishes for the whole family.

This manual provides important information on the safe use, operation, and maintenance of your air fryer. Please read it thoroughly before first use and keep it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- · Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- · Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to "off", then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

• Do not block any ventilation openings.

3. PRODUCT OVERVIEW

The ARDES ARFRYA05L INFINITY 8L Air Fryer features a sleek design with an extra-deep cooking cavity, allowing for versatile cooking options.



Figure 3.1: Front-side view of the ARDES ARFRYA05L INFINITY 8L Air Fryer.

Key Features:

- Digital Touch Display: Intuitive interface for easy control.
- 60-Minute Timer: For precise cooking duration.
- 10 Preset Programs: Optimized settings for various dishes.
- Adjustable Temperature: From 80°C to 200°C.
- 8-Liter Capacity: Generous volume for family-sized meals.
- Extra-Deep Basket: 35% deeper than traditional air fryers, suitable for elongated foods.
- Non-Stick Grid and Removable Container: For easy cleaning.



Figure 3.2: Digital control panel with timer, temperature, and preset programs.



Figure 3.3: Illustration of the air fryer's slim profile and deep basket design.

4. SETUP

- 1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Ensure all components are present and undamaged.
- 2. **Initial Cleaning:** Before first use, wipe the exterior of the air fryer with a damp cloth. Wash the removable basket and non-stick grid with warm, soapy water. Rinse thoroughly and dry completely.
- 3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 10 cm) around the appliance for proper air circulation. Do not place it directly against a wall or under cabinets.
- 4. Power Connection: Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

Basic Operation:

1. Prepare Food: Place your ingredients into the air fryer basket. Do not overfill the basket to allow for proper air

circulation and even cooking.

- 2. Insert Basket: Slide the basket firmly back into the air fryer.
- 3. Power On: Plug in the appliance. The digital display will illuminate.
- 4. **Set Temperature and Time:** Use the touch controls to set the desired cooking temperature (80°C to 200°C) and time (up to 60 minutes). Alternatively, select one of the 10 preset programs.
- 5. Start Cooking: Press the start button to begin the cooking process.
- 6. **Shake/Flip (Optional):** For best results, especially with smaller items like fries, shake or flip the food halfway through the cooking time. Carefully pull out the basket, shake, and reinsert. The air fryer will resume cooking.
- 7. **Finish Cooking:** The air fryer will beep when the timer reaches zero. Carefully pull out the basket and remove the cooked food.
- 8. Power Off: Unplug the appliance after use.

Using Preset Programs:

The air fryer comes with 10 preset programs for common dishes. To use a preset program:

- 1. Place food in the basket.
- 2. Select the desired preset icon on the digital touch display. The air fryer will automatically set the optimal temperature and time.
- 3. Press the start button.

6. COOKING GUIDE

The ARDES ARFRYA05L INFINITY 8L Air Fryer is versatile and can cook a wide range of foods with up to 80% less oil compared to traditional frying methods, resulting in healthier and crispier meals.



Figure 6.1: Examples of food that can be cooked in the air fryer: fish, meat, chicken, and skewers.



Figure 6.2: Enjoying healthy, crispy food cooked with significantly less oil.

General Cooking Tips:

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding food.
- Oil Usage: While the air fryer can cook without oil, a small amount of oil (1-2 tablespoons) can enhance crispiness and flavor for some foods. Use oil sprays or toss food with oil before placing it in the basket.
- Even Cooking: Shake the basket or flip food halfway through cooking for even browning and crispiness.
- Batch Cooking: If cooking large quantities, cook in smaller batches to ensure even results.
- Doneness: Always ensure food is cooked to a safe internal temperature.

7. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ARDES ARFRYA05L INFINITY 8L Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.

- 2. **Clean Basket and Grid:** The removable basket and non-stick grid should be washed with warm, soapy water. Use a non-abrasive sponge or cloth. Do not use metal scouring pads or harsh abrasive cleaners, as these can damage the non-stick coating. **Note: The basket and grid are not dishwasher safe.**
- 3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn food residue, use a mild detergent and a soft brush.
- 4. Clean Exterior: Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners.
- 5. **Storage:** Ensure all parts are completely dry before storing the air fryer in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; basket not inserted correctly.	Ensure the power cord is securely plugged in. Check the power outlet. Make sure the basket is fully pushed into the appliance.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Cook in smaller batches. Shake or flip food halfway through cooking.
Food is not crispy.	Not enough oil (for some foods); temperature too low; cooking time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time.
White smoke coming from the appliance.	Grease residue from previous use; cooking fatty foods.	Clean the basket and interior thoroughly. This is normal when cooking very fatty foods, but ensure no excess oil is dripping into the heating element.

9. SPECIFICATIONS

Specification	Detail
Brand	Ardes
Model Number	ARFRYA05L
Color	Black
Dimensions (L x W x H)	46.5 x 26.5 x 29.5 cm
Weight	4.95 Kilograms
Capacity	8 Liters
Power	1700 Watts
Voltage	240 Volts
Material	Polypropylene (PP)
Special Feature	Space-saving and extra-large surface (deep basket)

Specification	Detail
Recommended Uses	Cooking
Manufacturer	Poly Pool
Country of Origin	Italy



Figure 9.1: Product dimensions for the ARDES ARFRYA05L INFINITY 8L Air Fryer.


10. WARRANTY AND SUPPORT

ARDES products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your purchase or contact ARDES customer support directly.

For technical assistance, spare parts availability, or any other inquiries, please visit the official ARDES website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Poly Pool

Brand: Ardes







Ardes AR5PL50 Ceiling Fan: User Manual and Installation Guide

This document provides comprehensive instructions for the Ardes AR5PL50 ceiling fan, covering safe installation, operation, maintenance, disposal, and warranty information. It includes detailed safety warnings and usage guidelines.