

Sunstech CELT23

Sunstech CELT23 Easy-to-Use Flip Phone for Seniors - Instruction Manual

Model: CELT23

1. INTRODUCTION

Welcome to the instruction manual for your new Sunstech CELT23 flip phone. This phone is specifically designed for ease of use, featuring large keys, a clear display, and essential functions like an SOS button for emergencies. Please read this manual carefully to understand how to operate your device safely and efficiently.

2. PRODUCT OVERVIEW

The Sunstech CELT23 is a clamshell-style mobile phone, offering simplicity and security. Its design prioritizes user comfort and accessibility.

Key Features:

- **Flip Design:** Protects the screen and keypad when closed.
- **Large Keys:** Oversized buttons for easy dialing and texting.
- **SOS Button:** Located on the back for emergency calls and SMS.
- **2.4-inch Display:** Clear screen for easy viewing.
- **Quick Dial:** Assign contacts to speed dial keys.
- **Loud Sound:** Enhanced audio for calls and ringtones.
- **FM Radio:** Built-in radio for entertainment.
- **1100 mAh Battery:** Provides reliable battery life.

Phone Components:



Image Description: This image displays the Sunstech CELT23 flip phone in two states: open, showing the screen and large keypad, and closed, resting in its charging dock. The back of the closed phone, featuring the red SOS button, is also visible. This illustrates the phone's compact design and user-friendly interface.



Image Description: This image shows the Sunstech CELT23 flip phone in its charging dock, with the phone in a closed position. The prominent red SOS button on the back of the phone is clearly visible, highlighting a key safety feature. The phone's external display is also visible, showing the time and date.



Image Description: This image presents a collection of Suntech CELT23 flip phones, showcasing different color options (blue and black) and configurations. Some phones are open, displaying their keypads and screens, while others are closed and placed in their charging docks. This provides a comprehensive view of the product's design and available variations.

3. SETUP

3.1. Inserting the SIM Card and Battery

1. **Open the Phone:** Gently open the back cover of the phone.
2. **Insert SIM Card:** Locate the SIM card slot. Carefully insert your activated SIM card into the designated slot, ensuring the gold contacts face downwards and the cut corner aligns correctly.
3. **Insert Battery:** Place the provided Lithium-ion battery into the battery compartment, aligning the contacts.
4. **Close Cover:** Replace the back cover until it clicks securely into place.

3.2. Charging the Phone

1. **Using the Charging Dock:** Place the phone into the charging dock, ensuring it sits firmly and the charging indicator light (if present) illuminates.
2. **Direct USB Charging:** Alternatively, connect the USB Type C cable to the phone's charging port and the other end to a compatible power adapter.
3. **First Charge:** For optimal battery performance, fully charge the phone before its first use.

3.3. Powering On/Off

- **To Power On:** Press and hold the Power/End Call button (usually red) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear, then select "Power Off".

4. OPERATING INSTRUCTIONS

4.1. Making and Receiving Calls

- **To Make a Call:**

- a. Open the phone.
- b. Dial the number using the large keypad.
- c. Press the Green Call button to initiate the call.

- **To Receive a Call:**

- a. When the phone rings, open the flip or press the Green Call button.
- b. To end a call, press the Red End Call button.

4.2. Sending SMS Messages

1. From the main menu, navigate to "Messages".
2. Select "Write Message" or "New SMS".
3. Enter the recipient's number or select from contacts.
4. Type your message using the keypad.
5. Press "Send".

4.3. SOS Emergency Function

The SOS button is designed for emergencies. When pressed, it will activate an audible warning signal and automatically dial up to 5 pre-set emergency contacts. It will also send a customizable emergency SMS message to these contacts.

1. **Setting Up SOS Contacts:**

- Go to "Settings" > "SOS Settings".
- Add up to 5 emergency contact numbers.
- Customize the emergency SMS message if desired.

2. **Using the SOS Button:**

- In an emergency, press and hold the red SOS button on the back of the phone for a few seconds.
- The phone will emit an alarm and begin dialing your emergency contacts sequentially until one answers.
- An emergency SMS will also be sent to all pre-set contacts.

4.4. Speed Dial

Assign frequently called numbers to specific keys for quick dialing.

1. Go to "Contacts" or "Settings" > "Speed Dial".
2. Select an available key (e.g., M1, M2, or number keys 2-9).
3. Assign a contact from your phonebook or enter a new number.
4. To use, simply press and hold the assigned speed dial key.

4.5. FM Radio

To listen to the FM radio, ensure headphones are connected (they act as an antenna).

1. Connect 3.5mm headphones to the phone's audio jack.

2. Navigate to "Multimedia" or "Tools" > "FM Radio".
3. Use the navigation keys to scan for stations or tune manually.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid liquid cleaners.
- **Battery Care:**
 - Avoid extreme temperatures.
 - Do not leave the battery fully discharged for extended periods.
 - Use only the original charger and battery.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.

6. TROUBLESHOOTING

Problem	Possible Cause / Solution
Phone does not turn on.	Battery is discharged. Charge the phone. Battery not inserted correctly. Reinsert the battery.
Cannot make or receive calls.	No SIM card inserted or SIM card not activated. Check SIM card. Out of network coverage. Move to an area with better signal.
No sound during calls.	Volume is too low. Adjust the call volume using the side keys. Speaker/earpiece might be blocked. Clean gently.
SOS button not working.	SOS contacts not set up. Configure emergency contacts in SOS settings.

7. SPECIFICATIONS

- **Brand:** Sunstech
- **Model:** CELT23
- **Product Type:** Flip Phone
- **Operating System:** RTOS
- **Screen Size:** 2.4 Inches
- **Resolution:** 240 x 320
- **Connections:** USB Type C, 3.5 mm Jack
- **Special Features:** SOS Button, FM Radio
- **Battery Composition:** Lithium-ion
- **Battery Capacity:** 1100 mAh (inferred from product description)
- **RAM Size:** 48 MB
- **Storage Capacity:** 128 GB (Note: This capacity is typically for external memory card support in basic phones)
- **CPU Speed:** 800 MHz
- **Manufacturer:** SUNSTECH

- **Country of Origin:** China

8. WARRANTY AND SUPPORT

This product is manufactured by SUNSTECH. For specific warranty details, please refer to the warranty card included with your purchase or contact Sunstech customer support.

- **Spare Parts Availability:** 10 Years (as per manufacturer information).
- **Software Updates:** Information not available.

For further assistance, please visit the official Sunstech website or contact their customer service department.

Related Documents - CELT23

 <p>User Manual uSUN200</p> 	<p>Sunstech uSUN200 User Manual: Comprehensive Guide to Features and Operations</p> <p>Explore the full capabilities of your Sunstech uSUN200 smartphone with this detailed user manual. Learn about setup, features, connectivity, applications, and troubleshooting.</p>
 <p>TEL205 - Mobile phone English & Spanish</p> 	<p>Sunstech TEL205 Mobile Phone User Manual</p> <p>User manual for the Sunstech TEL205 mobile phone, covering features like dual SIM, SMS, MP3, camera, FM radio, and safety precautions.</p>
 <p>DEDALOIII MP3 PLAYER USER GUIDE</p> 	<p>Sunstech DEDALOIII MP3 Player User Guide</p> <p>User guide for the Sunstech DEDALOIII MP3 Player, detailing its features, operations, system settings, and safety warnings.</p>
 <p>RPDS32 DIGITAL AM/FM RADIO USER GUIDE</p> 	<p>Sunstech RPDS32 Digital AM/FM Radio User Guide</p> <p>User guide for the Sunstech RPDS32 Digital AM/FM Radio, covering controls, operating instructions, specifications, and important warnings.</p>

 <p>DTB210HD2 DVB-T2 RECORDER USB RECORDER sunstech</p>	<p>Sunstech DTB210HD2 DVB-T2 Receiver User Guide</p> <p>Comprehensive user guide for the Sunstech DTB210HD2 DVB-T2 Receiver with USB recorder. Learn about installation, channel management, recording features, multimedia playback, and specifications.</p>
 <p>sunstech User Manual uSUN200</p>	<p>Sunstech uSUN200 User Manual: Comprehensive Guide to Features and Operations</p> <p>Explore the full capabilities of your Sunstech uSUN200 smartphone with this detailed user manual. Learn about setup, features, connectivity, applications, and troubleshooting.</p>

Documents - Sunstech – CELT23



sunstech
CELT23
Teléfonos

El CELT23, el teléfono senior perfecto para personas mayores. Con su diseño en forma de concha, el CELT23 garantiza sencillez, comodidad y seguridad de uso. Lo que, junto a sus grandes teclas, facilitará la introducción y marcación de números. Incorpora un botón SOS en la parte trasera que emite una señal acústica de aviso y permite realizar automáticamente llamadas de emergencia a hasta 9 contactos, además de enviarles un mensaje SMS de emergencia personalizado.

Características
Pantalla LCD color de 2,4" Resolución: 240 x 320 px.
Teclado retroiluminado retroalimentado con teclas grandes.
Botón SOS para llamadas de emergencia.
Doble SIM (línea y reserva SIM). GSM 900 / 1800 MHz.
Bluetooth V3.0 / Procesador: MT62352 / RAM 32 MB, ROM Multimedia: imagen, audio y video.
Radio FM, Calendario, Calculadora, Alarma y Linterna.
Agenda, 300 contactos y 1000 textos SMS mensajería.
Cámara trasera (VGA: 0,3 MP) y Aláreo.
Batería Recargable: 1200mAh.
Conexiones: Dual SIM, USB Tipo C, Puerto para tarjetas de

Dimensiones y peso
Ancho: 53mm
Alto: 131mm
Profundo: 20mm
Peso: 107g

Colores
CELT23BK
Negro
EAN: 842010219647
CELT23BL
Azul
EAN: 842010219654

Unidades por caja:
Unid.: 3, Mayor: 50


ALFA LOM S.A. - N.º de Reg. I.B.I. 08110. Mat. Ins. 08110. B.º de Ins. 08110. I. 034 851 000
sunstech.es - Canal de atención al cliente: sunstech.es - P.º de At. al Cliente: 91 051 19 20 - call@sunstech.es

[pdf]

CELT23 Sunstech leaflet Teléfono Móvil CELT23BL para Personas Mayores Azul 16851 electromueble es img object 1685 |||

CELT23 Telfonos Doble pantalla Dual SIM Teclas grandes Hasta 300 contactos Botn de emergencia El **CELT23**, el telefono senior perfecto para personas mayores. Con su diseo en forma de concha, el **CELT23** garantiza sencillez, comodidad y seguridad de uso, lo que, junto a sus grandes teclas, facilitar...

lang:es score:31 filesize: 344.28 K page_count: 1 document date: 2023-03-01



CELT23
SENIOR PHONE
USER GUIDE

[\[pdf\]](#) User Manual

CELT23 M U Manual de instrucciones Teléfono Móvil Sunstech en Español EN ES FR PT central
manuales telefono sunstech |||

1 2 3 4 1 2 3 4 1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. 1...

lang:es score:29 filesize: 14.51 M page_count: 100 document date: 2023-02-14

