

EGLO 75708

EGLO Coluccia LED Table Lamp User Manual

Model: 75708

INTRODUCTION

Thank you for purchasing the EGLO Coluccia LED Table Lamp. This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your new lamp. Please read this manual thoroughly before use to ensure proper functionality and longevity of the product.





Figure 1: EGLO Coluccia LED Table Lamp (Black)

This image shows the EGLO Coluccia LED Table Lamp in black, featuring its sleek design and the integrated digital display on the base, which shows time, date, and temperature. The lamp head is folded down, highlighting its compact form.

PACKAGE CONTENTS

Before proceeding with the setup, please verify that all components are present in the package:

- EGLO Coluccia LED Table Lamp
- USB-C Charging Cable
- Assembly Instructions (this manual)

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport if

2. **Placement:** Place the lamp on a stable, flat surface. Ensure there is adequate space around the lamp for the 180° folding lamp head to adjust freely.
3. **Initial Charge:** The lamp contains a rechargeable lithium battery. For optimal performance, fully charge the lamp before first use. Connect the supplied USB-C cable to the lamp's charging port and plug the other end into a compatible USB power adapter (not supplied). The display may indicate charging status.
4. **Assembly:** The lamp is designed for minimal assembly. If any components require attachment, refer to the included assembly instructions for specific steps. The lamp head can be folded and unfolded as needed.



This image displays the product packaging, illustrating the lamp's dimensions and key features such as LED specifications, lumen output, and power details. It also shows the lamp in its folded and unfolded states, providing a visual guide for its adjustable design.

OPERATING INSTRUCTIONS

Lamp Operation

- **Power On/Off and Dimming:** The lamp features a touch-sensitive area on its base.
 - Touch once to turn the lamp on at 30% brightness.
 - Touch again to increase brightness to 60%.
 - Touch a third time to reach 100% brightness.
 - Touch a fourth time to turn the lamp off.
- **Adjusting Lamp Head:** The lamp head can be folded up to 180 degrees. Gently adjust the lamp head to direct the light as desired.

Display Functions (Time, Date, Temperature, Alarm)

The integrated display shows various information and offers additional functionalities.



Figure 3: Digital Display Interface

This close-up image focuses on the digital display of the EGLO Coluccia lamp, clearly showing the current time, month, date, day of the week, and ambient temperature. This highlights the multi-functional aspect of the lamp's base.

- **Setting Time and Date:** Specific buttons or touch areas on the base (not explicitly detailed in product info, assume standard controls) are used to set the time, date, and day of the week. Refer to the quick start guide or specific markings on the lamp for these controls.
- **Temperature Display:** The lamp automatically displays the ambient temperature.
- **Alarm Clock:** The lamp includes an alarm clock function. Follow the lamp's specific instructions (likely via buttons near the display) to set and activate the alarm.
- **Snooze Mode:** When the alarm sounds, a snooze function is available. Typically, touching the lamp or a specific button will activate snooze.
- **Timer Function:** A timer function is available for various uses. Consult the lamp's specific controls for setting and activating the timer.
- **Birthday Song:** The lamp can play a birthday song on request. This feature is likely activated through a specific button or setting within the alarm/timer menu.

MAINTENANCE

- **Cleaning:** To clean the lamp, wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or electronic components.
- **Battery Care:** To prolong the life of the rechargeable lithium battery, avoid fully discharging it frequently. Recharge the lamp when the battery indicator is low. If storing the lamp for an extended period, charge it periodically to maintain battery health.
- **LEDs:** The integrated LED light source is designed for long-term use and is not user-replaceable.
- **Storage:** When not in use, store the lamp in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Connect the lamp to a USB power source using the supplied USB-C cable and allow it to charge.
Lamp flickers or light is weak.	Low battery charge.	Recharge the lamp fully.
Touch control is unresponsive.	Surface is dirty or wet; temporary electronic glitch.	Ensure the touch area is clean and dry. Try restarting the lamp by fully discharging and recharging, or if possible, a soft reset.
Display is blank or incorrect.	Battery low; internal error.	Charge the lamp. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	75708
Brand	EGLO
Light Source	Integrated LED
Power Consumption	3.2 Watts
Luminous Flux	380 Lumens
Color Temperature	4000 Kelvin (Neutral White)
Dimming	3-stage touch dimmable (30%, 60%, 100%)
Power Source	Rechargeable Lithium Battery (USB-C charged)
Material	Plastic
Color	Black
Dimensions (L x W x H)	19 cm x 12.5 cm x 26 cm
Weight	0.45 Kilograms

Feature	Detail
Special Features	Integrated display (Time, Date, Day, Temperature), Alarm Clock, Snooze, Timer, Birthday Song function, 180° folding lamp head.
Energy Efficiency Class	F



Figure 4: Energy Efficiency Label

This image displays the energy efficiency label for the EGLO Coluccia lamp, indicating its energy efficiency class as F.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official EGLO website. Keep your purchase receipt as proof of purchase.

EGLO Official Website: www.eglo.com

For recycling information regarding this product, please visit relevant local recycling guidelines or the manufacturer's website.

© 2024 EGLO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question