

[Manuals.plus](#) /

› [Glacier Bay](#) /

› Glacier Bay Market Single-Handle Pull-Out Sprayer Kitchen Faucet User Manual

Glacier Bay HD67737-0008D2

Glacier Bay Market Single-Handle Pull-Out Sprayer Kitchen Faucet

Model: HD67737-0008D2 | **Brand:** Glacier Bay

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Glacier Bay Market Single-Handle Pull-Out Sprayer Kitchen Faucet. Designed for durability and ease of use, this faucet features a stainless steel finish, a single lever handle, and a versatile pull-out sprayer with two spray modes. Please read this manual thoroughly before beginning installation or operation to ensure proper function and longevity of your product.



Figure 1: The Glacier Bay Market Single-Handle Pull-Out Sprayer Kitchen Faucet, showcasing its sleek design and stainless steel finish.

SETUP AND INSTALLATION

The Glacier Bay Market Faucet is designed for quick and easy installation, compatible with both 1-hole and 3-hole kitchen sinks with 8-inch centers. The exclusive FastMount system simplifies the mounting process.

Pre-Installation Steps:

1. Ensure all necessary components are present as listed in the packaging.
2. Turn off the main water supply to the kitchen sink.
3. Clear the area under the sink for easy access during installation.

Installation Procedure:

1. **Mounting the Faucet:** Position the faucet body and deck plate (if using for 3-hole sinks) onto the sink holes. Utilize the FastMount system by pushing the mounting nut over the shank and twisting to tighten securely from underneath the sink.
2. **Connecting Water Supply Lines:** Connect the hot and cold water supply lines from the faucet to your home's water supply valves. Ensure connections are tight to prevent leaks. The faucet includes a 29.5-inch braided supply hose with a 3/8-inch connection.
3. **Connecting Sprayer Hose:** Attach the pull-out sprayer hose to the designated connection point on the faucet's underside.

4. **Installing Weight:** Attach the hose weight to the pull-out sprayer hose at the indicated position to ensure smooth retraction.
5. **Testing:** Once all connections are secure, slowly turn on the main water supply and check for any leaks. Operate the faucet to ensure proper water flow and sprayer function.



Figure 2: Illustration of the FastMount™ system, demonstrating how it simplifies faucet installation by allowing quick and secure tightening from below the sink.

OPERATING INSTRUCTIONS

Your Glacier Bay Market Faucet is designed for intuitive operation, providing convenient control over water flow, temperature, and spray patterns.

Water Flow and Temperature Control:

The single-control lever handle allows for easy adjustment of both water flow and temperature. Move the handle up to increase flow and down to decrease it. Pivot the handle left for hot water and right for cold water.

Pull-Out Sprayer Functionality:

The pull-out sprayer provides extended reach with a workable hose length of 25.2 inches, ideal for various kitchen tasks such as filling large pots or cleaning the sink basin.

Spray Modes:

- **Aerated Spray:** This standard spray mode provides a steady, aerated stream suitable for everyday washing.
- **TurboSpray™:** Activate this exclusive Glacier Bay feature for a stronger, more focused spray pattern, offering 30% more cleaning power than standard pull-out faucets. This is particularly useful for rinsing stubborn food debris.

Switch between spray modes using the buttons located on the sprayer head.



Figure 3: Illustration highlighting the TurboSpray™ feature, which provides focused water columns for enhanced cleaning power.



Figure 4: The Glacier Bay Market Faucet installed and in operation, demonstrating water flow into a kitchen sink.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your Glacier Bay Market Faucet.

Cleaning the Finish:

To maintain the stainless steel finish, clean regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.

Aerator Maintenance:

If water flow becomes restricted, the aerator on the sprayer head may be clogged with mineral deposits. Unscrew the aerator from the sprayer head, clean any debris or mineral buildup, and rinse thoroughly before reattaching.

Hose and Weight Inspection:

Periodically inspect the pull-out hose for any kinks or damage. Ensure the hose weight is securely attached and allows for smooth retraction of the sprayer.

TROUBLESHOOTING

This section addresses common issues you might encounter with your kitchen faucet. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Low water flow	Clogged aerator; partially closed supply valves; kinked supply line.	Clean aerator; ensure supply valves are fully open; straighten supply line.
Leaks from faucet base	Loose mounting nut; damaged O-rings.	Tighten mounting nut; inspect and replace O-rings if necessary.

Problem	Possible Cause	Solution
Sprayer does not retract fully	Hose weight improperly positioned or missing; hose kinked.	Adjust or reattach hose weight; straighten hose.
Water temperature inconsistent	Improper hot/cold supply connections; issue with water heater.	Verify supply line connections; consult water heater manual or professional.

SPECIFICATIONS

Detailed technical specifications for the Glacier Bay Market Single-Handle Pull-Out Sprayer Kitchen Faucet.

Feature	Specification
Brand	Glacier Bay
Model Name	Market
Model Number	HD67737-0008D2
Material	Metal
Finish Type	Stainless Steel
Color	Stainless Steel
Number of Handles	1 (Single-Handle)
Mounting Type	Deck Mount
Hole Count Compatibility	1 or 3-hole (8-inch centers)
Special Feature	Pull Down Sprayer with TurboSpray™
Spout Reach	25.2 Inches (workable hose length)
Item Weight	5 pounds
Product Dimensions	8 x 1.99 x 9 inches
Included Components	Sprayer

WARRANTY INFORMATION

For specific warranty details regarding your Glacier Bay Market Kitchen Faucet, please refer to the warranty card included with your purchase or visit the official Glacier Bay website. Typically, Glacier Bay products come with a limited lifetime warranty covering defects in materials and workmanship for the original consumer purchaser.

CUSTOMER SUPPORT

If you require further assistance, have questions about installation, operation, or need to report a defect, please

contact Glacier Bay customer service. Have your model number (HD67737-0008D2) and purchase information ready when you call.

You can often find contact information on the Glacier Bay official website or on the product packaging.