

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [amazon basics](#) /
- › [amazon basics 16W Bluetooth Soundbar Speaker ABSBX93 User Manual](#)

amazon basics ABSBX93

amazon basics 16W Bluetooth Soundbar Speaker

Model: ABSBX93

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your amazon basics 16W Bluetooth Soundbar Speaker. Please read this guide thoroughly before using the product to ensure optimal performance and safety.

SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Avoid extreme temperatures, direct sunlight, or heat sources.
- Do not disassemble, repair, or modify the device. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Use only the provided charging cable or a certified equivalent.
- Do not block ventilation openings.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1N Soundbar
- 1N Charging Cable
- 1N Aux Cable
- 1N User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your soundbar.



Figure 1: Front view of the amazon basics 16W Bluetooth Soundbar Speaker, showcasing its sleek black design and speaker grille.

EASY

ACCESS CONTROLS



Figure 2: Top panel controls including power, mode, play/pause, and volume buttons.



Figure 3: Rear panel showing multi-connectivity ports: USB, 3.5mm AUX, and Micro SD card slot.

SETUP

Charging the Soundbar

1. Connect the provided charging cable to the charging port on the soundbar.
2. Connect the other end of the charging cable to a compatible USB power adapter (not included) or a USB port on a computer.
3. The charging indicator light will illuminate. Once fully charged, the indicator light may change color or turn off.
4. A full charge provides approximately 10 hours of wireless playback at 50% volume.

Powering On/Off

- **To Power On:** Press and hold the Power button (**U**) on the top panel until the indicator light illuminates.
- **To Power Off:** Press and hold the Power button (**U**) again until the indicator light turns off.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the soundbar is powered on and in Bluetooth mode. If not, press the Mode button (**M**) to cycle through modes until you hear the Bluetooth prompt or see the Bluetooth indicator light flashing.
2. Enable Bluetooth on your mobile device (smartphone, tablet, laptop, etc.).
3. Search for available Bluetooth devices. Select "ABSBX93" from the list.
4. Once paired, the soundbar will indicate a successful connection, and the Bluetooth indicator light will stop flashing.
5. The soundbar will automatically attempt to reconnect to the last paired device when powered on.

AUX Mode

1. Connect one end of the 3.5mm AUX cable to the AUX port on the soundbar.
2. Connect the other end of the AUX cable to the audio output jack of your device (e.g., TV, PC, MP3 player).
3. Press the Mode button (**M**) on the soundbar until you hear the AUX mode prompt.
4. Audio will now play through the soundbar from your connected device.

USB Playback

1. Insert a USB flash drive containing audio files into the USB port on the soundbar.
2. Press the Mode button (**M**) until you hear the USB mode prompt.
3. The soundbar will automatically begin playing audio files from the USB drive.

Micro SD Card Playback

1. Insert a Micro SD card containing audio files into the Micro SD card slot on the soundbar.
2. Press the Mode button (**M**) until you hear the Micro SD mode prompt.
3. The soundbar will automatically begin playing audio files from the Micro SD card.

Controls

- **Power Button (U):** Press and hold to power on/off.
- **Mode Button (M):** Press to switch between Bluetooth, AUX, USB, and Micro SD modes.
- **Play/Pause Button (||):** Press to play or pause audio playback.
- **Volume Up Button (+):** Press to increase volume. Press and hold for continuous volume increase.
- **Volume Down Button (-):** Press to decrease volume. Press and hold for continuous volume decrease.
- **Previous Track Button (|<<):** Press to go to the previous track (in Bluetooth, USB, or Micro SD modes).
- **Next Track Button (>>|):** Press to go to the next track (in Bluetooth, USB, or Micro SD modes).

MAINTENANCE

Cleaning

- Ensure the soundbar is powered off and disconnected from all power sources before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, aerosols, or solvents.

Storage

- Store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its lifespan.

TROUBLESHOOTING

Problem	Possible Solution
Soundbar does not power on.	Ensure the battery is charged. Connect the charging cable and try again.
No sound.	Check volume levels on both the soundbar and the connected device. Ensure the correct input mode (Bluetooth, AUX, USB, Micro SD) is selected. Verify cables are securely connected in AUX mode.
Bluetooth pairing fails.	Ensure the soundbar is in Bluetooth pairing mode (indicator light flashing). Make sure the soundbar is within range (up to 10 meters) of your device. Turn off and on Bluetooth on your device, then try pairing again. Clear previous Bluetooth connections on your device if necessary.
USB/Micro SD playback not working.	Ensure the USB drive or Micro SD card is inserted correctly and contains compatible audio files. Press the Mode button to select the correct input.

SPECIFICATIONS

Feature	Detail
Model Name	ABSBX93
Speaker Type	Soundbar
Output Power	16 Watts
Connectivity Technology	Bluetooth v5.3, Auxiliary, USB
Compatible Devices	Smartphones, Tablets, PCs, Laptops, Televisions
Power Source	Battery Powered
Battery Type	1200mAh Lithium Ion (Rechargeable, Included)
Battery Average Life	Up to 10 Hours (at 50% volume)
Control Method	Touch Buttons
Product Dimensions (D x W x H)	5.5 x 37.8 x 6 Centimeters
Item Weight	582 Grams
Surround Sound Channel Configuration	2
Audio Driver Type	Dynamic Driver
Waterproof	No

WARRANTY AND SUPPORT

This amazon basics 16W Bluetooth Soundbar Speaker comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects but does not cover accessories.

For warranty claims, technical support, or further assistance, please refer to the contact information provided with

your purchase documentation or visit the official amazon basics support website.

Related Documents - ABSBX93

 <p>amazon basics</p> <p>Portable Air Conditioner Dehumidifier Manual Manuel de l'utilisateur pour l'unité portable Bedienungsanleitung für das tragbare Klimagerät mit Luftentfeuchter Manual de usuario para el acondicionador de aire portátil con deshumidificador 取扱説明書 1700W型空気清浄機 除湿機</p> <p>CE</p>	<p>Amazon Basics Portable Air Conditioner Dehumidifier Manual - Safety, Operation, Installation</p> <p>User manual for Amazon Basics portable air conditioner and dehumidifier (models B07ZHQDF7B, B07ZHQFNX8, B07ZHQTBSG, B07ZHQV1GT). Includes safety guidelines, product features, operating instructions, and installation steps for various window types. Available in multiple languages.</p>																				
 <p>amazon basics</p> <p>Computer Speakers for Desktop or Laptop Écouteurs pour Ordinateur de Bureau ou Ordinateur Portable Computer Lautsprecher für Desktop oder Laptop Altoparlante per Computer da Scrivania o Portatile Altavoces de Ordenador Para Ordenador de Escritorio o Portátil Computersprekakers voor Desktop of Laptop デスクトップ用スピーカー/ラップトップ用 スピーカー</p>	<p>Amazon Basics B07D7TV5J3 Computer Speakers User Manual</p> <p>This document provides important safety information, connection and operation instructions, cleaning and maintenance guidelines, and technical specifications for the Amazon Basics B07D7TV5J3 computer speakers.</p>																				
 <p>amazon basics</p> <p>15-in-1 Multi-Tool Pocket Knife</p>	<p>Amazon Basics 15-in-1 Multi-Tool Pocket Knife: Features, Safety, and Care</p> <p>Discover the Amazon Basics 15-in-1 Multi-Tool Pocket Knife. This guide covers its features, essential safety precautions, cleaning instructions, and importer details. Includes a list of all 15 tools.</p>																				
 <p>amazon basics</p> <p>USB Powered Computer Speakers with Dynamic Sound Écouteurs pour Ordinateur Alimentés par USB avec Son Dynamique USB Lautsprecher Computer Lautsprecher mit dynamischem Sound Altoparlante per Computer Alimentati da USB con Suono Dinamico Altavoces de Ordenador con Sistema de Sonido Dinámico USB Computersprekakers van Stroom van Laptop of Desktop (AC Strooming) USB-voeding van de speakers USB-voeding van de speakers USB-voeding van de speakers</p> <table border="1"><tr><td>EN</td><td>Page 2</td><td>NL</td><td>Pagina 30</td></tr><tr><td>FR</td><td>Page 9</td><td>ES</td><td>Página 34</td></tr><tr><td>DE</td><td>Seite 14</td><td>IT</td><td>Pagina 39</td></tr><tr><td>PT</td><td>Página 22</td><td>日本語</td><td>ページ 45</td></tr><tr><td>ES</td><td>Página 26</td><td></td><td></td></tr></table>	EN	Page 2	NL	Pagina 30	FR	Page 9	ES	Página 34	DE	Seite 14	IT	Pagina 39	PT	Página 22	日本語	ページ 45	ES	Página 26			<p>Amazon Basics USB-Powered Computer Speakers Quick Start Guide</p> <p>This quick start guide provides essential setup, operation, and safety information for Amazon Basics USB-Powered Computer Speakers with Dynamic Sound. Covers models B07DDK3W5D, B07DDGBL5T, B07DDGBJ9N, and B07DDDTWDP.</p>
EN	Page 2	NL	Pagina 30																		
FR	Page 9	ES	Página 34																		
DE	Seite 14	IT	Pagina 39																		
PT	Página 22	日本語	ページ 45																		
ES	Página 26																				
 <p>amazon basics</p> <p>In Ear Wired USB-C Earbuds with Microphone Écouteurs intra-auriculaires filaires USB-C avec microphone In-ear Wired USB-C Earbuds with Microphone Auriculares intracanal con micrófono y cable USB-C Buds de auriculares USB-C con micrófono Slushbuds® Wireless In-Ear Earbuds with Microphone イヤホン型ワイヤレス USB-C イヤホン イヤホン型イヤホン</p> <table border="1"><tr><td>EN</td><td>Page 1</td><td>ES</td><td>Página 25</td></tr><tr><td>FR</td><td>Page 1</td><td>DE</td><td>Seite 30</td></tr><tr><td>DE</td><td>Seite 11</td><td>IT</td><td>Pagina 35</td></tr><tr><td>IT</td><td>Página 11</td><td>日本語</td><td>ページ 31</td></tr></table>	EN	Page 1	ES	Página 25	FR	Page 1	DE	Seite 30	DE	Seite 11	IT	Pagina 35	IT	Página 11	日本語	ページ 31	<p>Amazon Basics Wired USB-C Earbuds with Microphone User Manual</p> <p>User manual and specifications for Amazon Basics Wired USB-C Earbuds with Microphone (Model BOCYSS1CP, AMZ-E8090A). Includes safety, usage, and troubleshooting information.</p>				
EN	Page 1	ES	Página 25																		
FR	Page 1	DE	Seite 30																		
DE	Seite 11	IT	Pagina 35																		
IT	Página 11	日本語	ページ 31																		
 <p>amazon basics</p> <p>Cylinder Bagless Vacuum Cleaner 2.5 L 700 W Aspirador Cilíndrico Sin Bolsa 2,5 L 700 W Beutelloses Zylinderstaubsauger 2,5 L 700 W Aspiratore Cilindrico Da Sedia 2,5 L 700 W Aspirador Cilíndrico Sin Bolsa 2,5 L 700 W Cylinder without Bags/2.5 L 700 W</p> <p>BEUTELLOSEM, BEUTELLOS, BEUTELLOS</p> <p>CE</p>	<p>Amazon Basics Cylinder Bagless Vacuum Cleaner 2.5 L 700 W User Manual</p> <p>User manual for the Amazon Basics Cylinder Bagless Vacuum Cleaner (2.5 L, 700 W). Covers assembly, operation, cleaning, maintenance, and troubleshooting. Includes model numbers B071VNC8M4, B072FBY7L4, B07C41FMF1 and safety information.</p>																				

