

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [COULAX](#) /

› Electric Toothbrush for Adults and Kids, Sonic Toothbrushes with 6 Brush Heads Rechargeable Electric Toothbrushes Light White

## COULAX HH06015 U17

# COULAX Sonic Electric Toothbrush User Manual

Model: HH06015 U17

## INTRODUCTION

---

Thank you for choosing the COULAX Sonic Electric Toothbrush. This manual provides detailed instructions on how to use, maintain, and troubleshoot your new electric toothbrush. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your device. This toothbrush is designed for both adults and kids, offering an effective and comfortable brushing experience.

## PRODUCT OVERVIEW

---

The COULAX Sonic Electric Toothbrush system includes the main toothbrush handle, multiple replacement brush heads, and a charging cable. Below is an illustration of the product components.



**Figure 1:** COULAX Sonic Electric Toothbrush, showing the main handle, six replacement brush heads, and the product packaging. The packaging highlights "U17 Series Sonic Electric Toothbrush" with features like fast charging, 5 brushing modes, and 99.99% plaque removal. A toothbrush holder and travel case are also indicated.

## Key Components:

- **Toothbrush Handle:** Contains the motor, battery, control buttons, and mode indicators.
- **Brush Heads:** Replaceable heads with W-shaped bristles for effective cleaning.
- **USB Charging Cable:** For recharging the toothbrush battery.
- **Travel Case:** Provides protection and convenience for travel.
- **Toothbrush Holder:** For convenient storage and charging.

## FEATURES

- **Powerful Sonic Technology:** Delivers 40,000 strokes per minute, removing up to 99.99% of plaque.
- **IPX7 Waterproof:** Allows for easy rinsing under water after each use.
- **Long Battery Life:** Up to 60 days of use on a single full charge (based on 2 minutes, twice a day brushing). Fast

charging via USB cable.

- **Multiple Brushing Modes:** Five distinct modes to cater to various oral care needs.
- **Smart Timer:** Built-in 2-minute timer with 30-second quadrant reminders to ensure thorough brushing.
- **Durable Brush Heads:** Comes with 6 DuPont brush heads, designed to last over 18 months (with recommended 3-month replacement).

## SETUP

---

### 1. Initial Charging

Before first use, fully charge the toothbrush. Connect the USB charging cable to the toothbrush and a compatible USB power source (e.g., power bank, PC, phone charger). A full charge takes approximately 3 hours and can last up to 60 days.



**Figure 2:** The electric toothbrush being charged via a USB cable connected to a wall adapter. The image highlights "3 Hours Fast Charge" and "Lasts Up to 60 Day," with icons for Power Bank, PC, and Phone Charge compatibility.

### 2. Attaching a Brush Head

Align the brush head with the metal shaft on the toothbrush handle and push it down firmly until it clicks into place. Ensure it is securely attached before use.



**Figure 3:** A close-up view of six W-shaped replacement brush heads. The text indicates "6\*3=18 Heads Months" and "Dentist suggested changing toothbrush head every 3 months," emphasizing the long-term supply of brush heads.

## OPERATING INSTRUCTIONS

---

### 1. Powering On/Off

- To turn on: Press the Power button once.
- To turn off: Press and hold the Power button for at least three seconds.

### 2. Selecting a Brushing Mode

The toothbrush features five performance modes. Press the Power button repeatedly (after turning on) to cycle through the modes. The indicator light next to the selected mode will illuminate.



**Figure 4:** An illustration detailing the five personalized brushing modes available on the COULAX electric toothbrush: Sensitive (softer cleaning), Clean (standard brushing), White (remove surface stains), Polish (1 minute whitening), and Massage (massage to healthy gums).

- **Sensitive:** Softer cleaning, recommended for first-time users or those with sensitive teeth/gums.
- **Clean:** Standard mode for daily dental care and thorough cleaning.
- **White:** Designed to remove surface stains and whiten teeth.
- **Polish:** A 1-minute mode for polishing teeth.
- **Massage:** Gentle massage for healthy gums.

### 3. Brushing Technique

Apply a small amount of toothpaste to the brush head. Place the bristles against your teeth at a slight angle towards the gumline. Move the brush slowly across each tooth, allowing the sonic vibrations to do the work. Do not scrub vigorously.

### 4. Smart Timer

The built-in smart timer ensures you brush for the dentist-recommended 2 minutes. The toothbrush will pause briefly every 30 seconds to signal you to move to another quadrant of your mouth (upper right, upper left, lower right, lower left). After 2 minutes, the toothbrush will automatically turn off.

## MAINTENANCE

---

### 1. Cleaning the Toothbrush

- After each use, rinse the brush head thoroughly under running water.
- Wipe the toothbrush handle with a damp cloth. Do not submerge the handle in water for extended periods, despite its IPX7 rating.
- Ensure no toothpaste residue builds up around the metal shaft.

### 2. Replacing Brush Heads

Dentists recommend replacing your toothbrush head every 3 months, or sooner if the bristles become frayed. To replace, simply pull the old brush head off the handle and push a new one on until it clicks.

### 3. Storage

Store the toothbrush in a dry place. For travel, use the provided travel case to protect the toothbrush and brush head.



**Figure 5:** The COULAX electric toothbrush neatly stored inside its white travel case, demonstrating its portability and convenience for travel.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is depleted.	Charge the toothbrush fully (approx. 3 hours).
Vibration is weak.	Low battery.	Recharge the toothbrush.
Brush head feels loose.	Brush head not properly attached or worn out.	Ensure brush head is pushed down firmly until it clicks. Replace if worn.
Toothbrush turns off too quickly.	Smart timer activated (2 minutes).	This is normal operation. If it turns off before 2 minutes, ensure it's fully charged.

## SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	HH06015 U17
Brand	COULAX
Power Source	Battery Powered, Corded Electric (USB)
Battery Type	1 Lithium Ion battery (included)
Battery Life	Up to 60 days (2 min/2x a day)
Charging Time	Approx. 3 hours
Vibrations	40,000 strokes per minute
Waterproof Rating	IPX7
Special Features	Brushing Timer (2-minute with 30-sec quadrant reminders), 5 Brushing Modes
Age Range	Adult and kids
Package Dimensions	7.8 x 5.04 x 1.73 inches
Item Weight	11.64 ounces
Manufacturer	Wenzhou Liangte Electric Co.,Ltd.

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official COULAX website. Please retain your proof of purchase for any warranty claims.