

[Manuals.plus](#) /

› [Bestier](#) /

› Bestier LED TV Stand L101217Y-GRYW Instruction Manual

Bestier L101217Y-GRYW

Bestier LED TV Stand L101217Y-GRYW Instruction Manual

Model: L101217Y-GRYW | Brand: Bestier

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning assembly and use. Retain this manual for future reference.

- **Two-Person Assembly:** Assembly of this TV stand is recommended for two adults to ensure safety and ease.
- **Weight Capacity:** Do not exceed the maximum weight capacity for the top surface or shelves. Refer to the specifications section for details.
- **Stable Placement:** Place the TV stand on a flat, level, and stable surface to prevent tipping.
- **Child Safety:** Keep small parts and packaging materials away from children. Always use the included anti-tip hardware to secure the stand to a wall.
- **Tool Use:** Use appropriate tools as specified in the assembly instructions. Do not overtighten fasteners.
- **Electrical Safety:** Ensure all electrical connections for the LED lighting are properly secured and follow local electrical codes. Unplug the LED lights before cleaning or maintenance.

PACKAGE CONTENTS

Verify that all parts and hardware are present before beginning assembly. If any items are missing or damaged, contact customer support.

Parts List (Illustrative)

- Top Panel
- Bottom Panel
- Side Panels (Left & Right)

- Middle Support Panels
- Adjustable Shelves
- Cabinet Doors
- Back Panels
- LED Light Strip & Remote Control

Hardware List (Illustrative)

- Cam Locks and Cam Dowels
- Wood Dowels
- Screws (various types)
- Hinges for Cabinet Doors
- Door Handles
- Shelf Pins
- Anti-Tip Hardware

ASSEMBLY INSTRUCTIONS

Before You Begin

- Clear a spacious area for assembly.
- Lay out all parts and hardware on a soft, clean surface to prevent scratches.
- Tools required: Phillips head screwdriver, hammer (optional, for dowels).

Step-by-Step Assembly

1. **Assemble the Base Frame:** Attach the side panels to the bottom panel using cam locks and dowels. Ensure all connections are secure.
2. **Install Middle Supports:** Insert the middle support panels into the designated slots, securing them with the appropriate hardware.
3. **Attach Top Panel:** Carefully place the top panel onto the assembled frame, aligning the cam locks and dowels. Tighten all fasteners.
4. **Install Adjustable Shelves:** Insert shelf pins into the desired height positions within the open compartments. Place the adjustable shelves onto the pins. This allows for flexible storage configurations.




Image: Adjustable shelf for customized storage.

Bestier's is Better and More Worthwhile

Bestier

VS

Others

✓

P2 Grade Cellular Board
Green
Stable Structure
Light Weight

✗

Wood Chip Board
Not Green
Easy to Deform
Heavy

Image: Detachable shelf with multiple height options.

5. **Attach Cabinet Doors:** Install hinges onto the cabinet doors and then attach the doors to the main frame. Adjust hinges as needed for proper alignment. Secure door handles. These cabinets provide enclosed storage.

Bestier

Love coming home.

Bestier is committed to creating a comfortable home environment for you and your family.

Our mission is to make sure the love of coming home should never change, no matter who you are, or where you are in life.

We strive to design products that flow with you, match your lifestyle and make your home a place to call your own.

Image: Storage cabinets for concealed items.

6. **Install Back Panels:** Secure the back panels to the rear of the stand using small nails or screws. Ensure the cable management holes are correctly positioned.
7. **Integrate Cable Management:** Utilize the pre-drilled cable management holes in the back panels to organize and route wires from your electronic devices. This helps maintain a tidy appearance.



More to Explore in Bestier Store

Discover your ideal cozy home
Get more inspiration for different styles.
Follow us for the latest featured offers

Image: Cable management hole for organized wiring.

Image: Overview of open display, cable management, and storage features.

8. **Install LED Lighting:** Adhere the LED light strip to the designated areas (usually along the inner edges of the open compartments). Connect the power supply and remote receiver.
9. **Apply Anti-Tip Hardware:** Secure the TV stand to a wall using the provided anti-tip hardware to prevent accidental tipping. Follow the instructions included with the anti-tip kit.

Once assembled, place your television and media devices on the stand. Ensure the weight is evenly distributed.



Image: Fully assembled Bestier LED TV Stand.

OPERATING INSTRUCTIONS

LED Lighting System

The Bestier LED TV Stand features integrated LED lighting with multiple color and dynamic modes, controlled by a remote.

- **Power On/Off:** Use the power button on the remote control to turn the LED lights on or off.
- **Color Selection:** Select from 20 static colors using the color buttons on the remote.
- **Dynamic Modes:** Choose from 22 dynamic modes (e.g., flash, strobe, fade, smooth) to create different lighting effects.
- **Brightness Adjustment:** Increase or decrease the brightness of the lights using the dedicated brightness

control buttons.

- **Speed Adjustment:** For dynamic modes, adjust the speed of the effects using the speed control buttons.




Image: LED remote control and lighting options.

Your browser does not support the video tag.

Video: Demonstration of the Bestier LED TV Stand's features, including LED lighting.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the material.
- **Fasteners:** Periodically check all fasteners to ensure they remain tight. Retighten if necessary.
- **LED Lights:** Ensure the LED light strip and connections are free from dust. If the lights malfunction, check connections before troubleshooting.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration.

TROUBLESHOOTING

If you encounter issues with your Bestier LED TV Stand, refer to the following common problems and solutions.

- **Stand is Unstable/Wobbly:**
 - Ensure all cam locks and screws are fully tightened.
 - Verify the stand is on a level surface. Adjust floor glides if present.
- **Cabinet Doors Do Not Align:**
 - Adjust the hinges. Most hinges allow for minor adjustments in height, depth, and side-to-side.

- Ensure the stand is level.

- **LED Lights Not Working:**

- Check if the power adapter is securely plugged into both the wall outlet and the LED strip connector.
- Ensure the remote control has working batteries and is pointed directly at the receiver.
- Verify the LED strip is properly connected to the receiver.

- **Missing or Damaged Parts:**

- Do not proceed with assembly. Contact Bestier customer support immediately for replacement parts.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Bestier
Model Name	L101217Y-GRYW
Product Dimensions	70.8 x 14 x 23 inches (L x W x H)
Item Weight	78.9 pounds
Material	P2 grade cellular board, Metal frame
Color	Wash White
Special Features	Adjustable Shelf, Durable, LED Lighting
Assembly Required	Yes
Room Type	Bedroom, Living Room, Playroom
UPC	810117536923

WARRANTY AND SUPPORT

Bestier is committed to providing quality products and customer satisfaction. This product comes with a standard manufacturer's warranty covering defects in materials and workmanship.

- **Warranty Information:** For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Bestier website.
- **Customer Support:** If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bestier customer support.
- **Contact Information:** Refer to the packaging or the Bestier official website for the most current customer service contact details.

