

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TECLAST](#) /

› [TECLAST T40Air Tablet User Manual](#)

TECLAST T40Air

TECLAST T40Air Tablet User Manual

MODEL: T40AIR

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. Product Overview

The TECLAST T40Air is a high-performance tablet designed for various tasks, from entertainment to productivity. It features a 10.4-inch display, 16GB RAM, 256GB ROM, and runs on Android 13, powered by an octa-core processor. Its lightweight design and robust battery ensure portability and extended usage.

TECLAST

Power in Air

T40 Air^{10.4"}



Image 1.1: Front and back view of the TECLAST T40Air Tablet, showcasing its sleek design and dual rear cameras.

Your browser does not support the video tag.

Video 1.1: An official overview of the TECLAST T40Air Android Tablet, highlighting its key features and design.

2. Initial Setup

2.1 Unboxing and First Use

Carefully remove the tablet and all accessories from the packaging. Inspect the device for any physical damage. Before first use, it is recommended to fully charge the tablet.

2.2 Charging the Tablet

Connect the provided USB-C cable to the tablet's charging port and the other end to the 18W PD fast charging adapter. Plug the adapter into a power outlet. The battery indicator on the screen will show the charging status. A full charge typically takes approximately 2-3 hours.

2.3 Powering On/Off

- To Power On:** Press and hold the Power button located on the side of the tablet until the TECLAST logo appears on the screen.

- **To Power Off:** Press and hold the Power button until a power menu appears. Select 'Power off' and confirm.
- **To Restart:** From the power menu, select 'Restart'.

2.4 Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Wi-Fi Connection:** Select your Wi-Fi network and enter the password to connect to the internet.
3. **Google Account:** Sign in with your Google account or create a new one. This is essential for downloading apps from the Google Play Store and syncing data.
4. **Date & Time:** Set the correct date and time, or allow the network to set it automatically.
5. **Security:** Set up a screen lock (PIN, pattern, password, or Face Unlock).

2.5 SIM Card Installation (Optional)

The T40Air supports 4G LTE connectivity. To install a SIM card:

1. Locate the SIM card tray on the side of the tablet.
2. Use the provided SIM ejector tool to open the tray.
3. Place the Nano-SIM card(s) into the designated slots, ensuring correct orientation.
4. Gently push the tray back into the tablet until it clicks into place.



接続を維持する

T40 Air は、地球の大部分をカバーしている北^斗、GPS、GLONASS、GALILEO の 4 つの主要衛星測位システムをサポートします。A-GPS ネットワークアシスト測位と組み合わせることで、高精度の方向ガイドを提供します。



Image 2.1: The TECLAST T40Air Tablet highlighting its 4G LTE support and SIM card tray location.

3. Operating Instructions

3.1 Navigating Android 13

The TECLAST T40Air runs on Android 13, offering an intuitive user experience. Use touch gestures to navigate:

- **Tap:** Select an item.
- **Swipe:** Scroll through screens or lists.
- **Pinch-to-zoom:** Zoom in or out on images and web pages.
- **Long press:** Access contextual menus or move icons.

Android 13 OS ユーザーのお好みに合わせます


これまでにないパーソナライゼーションをご体験ください。カラー、テーマと言語を調整して、アプリとメディアプレーヤーを独自の好みにカスタマイズできます。安全とプライバシーが最優先されます。アプリのアクセス許可の制御を強化してプライバシーを管理し、写真、ビデオ、クリップボードの履歴をより効果的に保護します。

 **Android 13**
あなたのために

 **プライバシーとセキュリティ**
権限の管理

 **タスクバー**
便利なマルチタスク


 **ペアレンタルコントロール**
スクリーンタイムを管理する



あなたのスタイルに応じて



パーソナライズされたカスタマイズ



セキュリティとプライバシー



エフォートレスマルチタスク



エンターテイメントハブ

Image 3.1: The Android 13 interface on the TECLAST T40Air Tablet, showing personalization and security features.

3.2 Display Features

The 10.4-inch 2K FHD IPS display provides vibrant colors and sharp details. It features:

- TDDI Fully Laminated:** Enhances touch responsiveness and visual clarity.
- Eye Protection Mode:** Reduces blue light to prevent eye strain.
- Reading Mode:** Optimizes the screen for comfortable reading.
- Dark Mode & Dim Mode:** Adjusts screen brightness and color for different lighting conditions.

10.4" 2K FHD IPSディスプレイ ピクセルをポートレートに変える



 **インセル**
タッチ・テクノロジー

 **TDDI**
フルラミネート

 **2000×1200**
2K解像度

 **120Hz**
タッチサンプリングレート

 **敏感なタッチ**
スマートな体験

 **Tカラー3.0**
色の最適化



Image 3.2: Visual representation of the TECLAST T40Air Tablet's display features, including eye protection and reading modes.

3.3 Camera Usage

The tablet is equipped with a 13MP rear dual camera and an 8MP front camera.

- **Taking Photos:** Open the Camera app, frame your shot, and tap the shutter button.
- **Recording Videos:** Switch to video mode in the Camera app and tap the record button.
- **Front Camera:** Use for video calls and selfies.



Image 3.3: The TECLAST T40Air Tablet showcasing its camera capabilities and 3.5mm headphone jack.

3.4 Audio and Connectivity

- SWEET 4 Speakers:** Enjoy immersive audio with the tablet's quad-speaker system and Smart K Digital Amplifier.
- 3.5mm Headphone Jack:** Connect your wired headphones for private listening.
- Wi-Fi:** Supports 2.4GHz and 5GHz dual-band Wi-Fi (802.11ac) for stable and fast internet.
- Bluetooth 5.0:** Connect wireless accessories like headphones, keyboards, and mice.
- VoLTE:** Enables high-quality voice calls over 4G LTE networks.

3.5 Face Unlock

The tablet supports Face Unlock for convenient and secure access. Set it up in the Security settings. Ensure good lighting conditions for optimal performance.

4. Maintenance

4.1 Cleaning the Tablet

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or

a screen cleaner. Avoid using harsh chemicals, abrasive materials, or excessive moisture.

4.2 Battery Care

- Avoid exposing the tablet to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charger or a certified 18W PD charger for optimal charging.

4.3 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings > System > System update**

4.4 Storage Management

The tablet comes with 256GB of internal storage, expandable via microSD card up to 1TB. Regularly manage your storage by:

- Deleting unnecessary files and apps.
- Moving large files to a microSD card.
- Utilizing cloud storage services.

**究極の空間を体験しよう
最大8GBまで拡張(16GB RAM)**

ストレージ 256 GB ROM LPDDR4 16GB (8GB+8GB拡張) マイクロSD 最大1TB

注: 拡張可能ストレージは調整可能で無効にすることもできます。ストレージを使用する場合があります。使用前に十分なスペースを確保してください。

**比類のないスピードを
体験してください**

UNISOC Tiger T616 オクタコアプロセッサは、マルチコア性能のために大幅に最適化されており、2つのA75高性能コアと6つのA55高効率コアで、発熱を抑えながら優れた性能を維持できます。

**T616オクタコア
UNISOC**
**A75高性能
A55高効率**
**2.0GHz
ピーク周波数**
**12nmプロセス
低消費 低温**

ビヨンドファストゲーミング

高性能の Mali-G57 グラフィックスプロセッサを搭載し、ゲーム体験を新たな高みへと引き上げます。素晴らしい没入感ある体験を提供してくれて、苦もなくその楽しみをピークに引き上げます。

**Mali-G57
グラフィックプロセッサ**
**750MHz
動作周波数**
**30%
性能の向上***

**パルホール構造
AR、VRに対応**

* 注: 前モデルの Mali-G52 との比較。

5. Troubleshooting

This section addresses common issues you might encounter with your TECLAST T40Air Tablet.

5.1 Device Not Powering On

- Ensure the battery is sufficiently charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

5.2 Wi-Fi Connection Issues

- Check if Wi-Fi is enabled in **Settings > Network & internet > Wi-Fi**
- Ensure you have entered the correct Wi-Fi password.
- Restart your Wi-Fi router and the tablet.
- Try connecting to a different Wi-Fi network to isolate the issue.

5.3 Slow Performance

- Close unused background applications.
- Clear cache data for apps that are running slowly (**Settings > Apps > [App Name] > Storage & cache > Clear cache**).
- Ensure you have sufficient free storage space.
- Restart the tablet.

5.4 Screen Not Responding

- Restart the tablet by holding the Power button.
- Ensure the screen is clean and free from moisture or debris.

5.5 Factory Reset (Last Resort)

If issues persist, you may consider performing a factory reset. **Warning: This will erase all data on your tablet. Back up important data before proceeding.**

Go to **Settings > System > Reset options > Erase all data (factory reset)** and follow the on-screen instructions.

6. Specifications

Below are the technical specifications for the TECLAST T40Air Tablet:

Feature	Specification
Model Number	T40Air
Display Size	10.4 Inches
Screen Resolution	1920 x 1080 pixels (2K FHD IPS)
RAM	16 GB
Flash Memory Size (ROM)	256 GB

Feature	Specification
Processor Brand	Rockchip or Unisoc (Octa-core)
Operating System	Android 13
Wireless Type	5 GHz Radio Frequency, 802.11a/b/g/n/ac
Bluetooth	Bluetooth 5.0
Average Battery Life	5 Hours (7200mAh)
Item Weight	1.01 pounds (approx. 460g)
Product Dimensions	9.6 x 6.1 x 0.3 inches
Special Feature	Lightweight

7. Warranty and Support

7.1 Product Warranty

The TECLAST T40Air Tablet comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

7.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact TECLAST customer support. You can typically find contact information on the official TECLAST website or through your retailer's support channels.

- Visit the official TECLAST website for FAQs and support resources.
- Contact the seller or retailer for product-specific support and return policies.