

Mia&Coco SM-WB9085-B

Mia&Coco Heated Hooded Blanket User Manual

Model: SM-WB9085-B

1. INTRODUCTION

Thank you for choosing the Mia&Coco Heated Hooded Blanket. This oversized wearable blanket is designed to provide warmth and comfort with its integrated heating elements. Please read this manual thoroughly before use to ensure safe and optimal operation of your product.

2. SAFETY INFORMATION

- Do not use if the blanket is wet.
- Ensure the USB power bank (not included) is 5V, 2A. Using an incompatible power source may damage the product or pose a safety risk.
- Do not use while sleeping or if you are unable to feel heat adequately.
- Keep out of reach of children and pets when in use.
- Do not puncture or modify the heating elements.
- Disconnect the power bank before cleaning or storing.
- The blanket features an automatic shut-off after 2 hours of continuous heating to prevent overheating.

3. PRODUCT OVERVIEW

The Mia&Coco Heated Hooded Blanket combines the functionality of a hoodie with the comfort of a blanket, featuring integrated heating for enhanced warmth.

Key Features:

- **Material:** Double-layer fabric with soft flannel exterior (200 g/m²) and plush sherpa lining (200 g/m²). Oeko-Tex certified for safety.
- **Heating System:** 3 heating zones (neck, back, abdomen) with synthetic fiber heating elements.
- **Heat Settings:** 3 adjustable heat levels (High, Medium, Low).
- **Auto Shut-off:** Automatically turns off after 2 hours for safety.
- **Design:** Oversized fit, generous hood, elastic cuffs, and a large kangaroo pocket.
- **Portability:** Foldable and lightweight for easy transport.

Components:

The heated hooded blanket includes:

- Oversized Hooded Blanket with integrated heating elements.
- USB power cable (integrated).

Note: A USB 5V, 2A power bank is required and not included with the product.



Figure 1: User wearing the Mia&Coco Heated Hooded Blanket, illustrating the heating zones in the front pocket area.



Figure 2: Front and back view of the blanket, highlighting the three heating zones in the abdomen, neck, and back regions.

4. SETUP

1. **Prepare Power Bank:** Ensure your USB power bank (5V, 2A) is fully charged. The power bank is not included.
2. **Locate USB Cable:** Find the integrated USB cable inside the blanket's pocket.
3. **Connect Power Bank:** Plug the USB cable into your power bank. Place the power bank securely inside the pocket.

3 HEIZSTUFEN

Werden Sie jederzeit und überall warm



Figure 3: Illustration of connecting a power bank to the internal USB cable. Note: Power bank is not included.

5. OPERATING INSTRUCTIONS

- Power On:** Press and hold the power button located on the front of the blanket for a few seconds until it illuminates. The blanket will start heating, typically reaching desired temperature within 10 seconds.
- Adjust Heat Level:**
 - Press the power button once to cycle through heat settings:
 - Red Light:** High heat (55-65°C)
 - Blue Light:** Medium heat (45-55°C)
 - Green Light:** Low heat (35-45°C)
- Automatic Shut-off:** The blanket will automatically turn off after 2 hours of continuous operation for safety. You can restart it by pressing the power button again.
- Power Off:** Press and hold the power button until the light turns off. Disconnect the power bank when not in use.



Figure 4: Demonstrates the power button and its corresponding light colors for different heat settings: Red for High, Blue for Medium, Green for Low.

EINE GRÖSSE PASST ALLEN

Geeignet für Erwachsene, Mädchen und Jungen



Größentabelle

Schulterbreite	Kleiderbreite	Länge	Ärmellänge	Ärmelbreite	Haubenlänge
80cm	85cm	90cm	64cm	32cm	45cm

Figure 5: Highlights various design features including the large hood, elastic cuffs, front pocket with heating elements, and a spacious kangaroo pocket for personal items.

6. MAINTENANCE

Cleaning Instructions:

1. **Disconnect Power:** Always disconnect the power bank before cleaning.
2. **Washing:** The blanket is machine washable. Wash in warm water, preferably separately.
3. **Drying:** Tumble dry on low temperature or air dry. Do not iron.
4. **Bleaching:** Do not bleach.

Storage:

Ensure the blanket is completely dry before folding and storing in a cool, dry place. Do not store with the power bank connected.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blanket is not heating.	Power bank not connected or discharged.	Ensure power bank is connected and charged.
	Power button not pressed or held long enough.	Press and hold the power button until the light illuminates.
	Automatic shut-off activated.	Restart the blanket by pressing the power button.
Heat is too low or too high.	Incorrect heat setting selected.	Press the power button to cycle through the heat settings (Red: High, Blue: Medium, Green: Low).

8. SPECIFICATIONS

Model Number	SM-WB9085-B
Dimensions (approx.)	Length: 90 cm, Width: 85 cm, Shoulder Width: 66 cm, Sleeve Length: 50 cm
Power Input	USB 5V, 2A (Power bank not included)
Heat Levels	High (55-65°C), Medium (45-55°C), Low (35-45°C)
Auto Shut-off	2 hours
Fabric Type	Flannel (exterior) and Sherpa (lining)
Care Instructions	Machine wash, tumble dry low, do not bleach, do not iron.
Weight	200 grams (product only, without packaging)

Der kuschelige
Decken-Hoodie ist
ein Must-Have für
eine gute Zeit!



Übergroß



Weicher
Flanell



Waschmaschinenfest



Bestes
Geschenk



Eine Größe
passt allen

Figure 6: Detailed size chart for the Mia&Coco Heated Hooded Blanket, indicating dimensions for length, width, shoulder width, sleeve length, and hood length.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Mia&Coco Heated Hooded Blanket, please contact our customer service. While specific warranty details are not provided in this manual, we are committed to ensuring your satisfaction with our products.

Please refer to your purchase documentation or the retailer's website for specific warranty terms and contact information.