Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COSTWAY GT4027GRDE

COSTWAY Wooden Garden Storage Cabinet with Metal Worktop and Roll-Up Doors (Model GT4027GRDE)

Instruction Manual

1. Introduction

Thank you for choosing the COSTWAY Wooden Garden Storage Cabinet. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new garden cabinet. Please read these instructions carefully before use and retain them for future reference.

2. Safety Instructions

Important: Always follow these safety guidelines to prevent injury or damage to the product.

- Assemble the product correctly according to the provided instructions. Incorrect assembly can lead to instability and potential hazards.
- Do not exceed the maximum weight capacity for the work surface (50 kg) and shelves (20 kg). Overloading can cause structural failure.
- Ensure the cabinet is placed on a stable, level surface to prevent tipping.
- Keep children and pets away from the assembly area.
- Wear appropriate safety gear during assembly, such as gloves.
- Regularly inspect the cabinet for any signs of wear, damage, or loose components. Tighten fasteners as needed.
- This product is designed for outdoor use. While painted for weather resistance, extreme weather conditions may require additional protection.

3. Product Features

The COSTWAY Garden Storage Cabinet is designed for versatility and durability, combining a potting bench with a storage shed. Key features include:

- **Durable Construction:** Made from selected fir wood, known for its hardness and crack resistance, and painted with an odorless lacquer for weather protection.
- **Spacious Metal Worktop:** A large (53 x 46 cm) metal work surface provides ample space for gardening tasks. It is rust-resistant and easy to clean, supporting up to 50 kg.
- **Ample Storage:** Features two internal shelves for organizing gardening tools, watering cans, storage baskets, and

other supplies, each supporting up to 20 kg.

- **Unique Roll-Up Doors:** Three roll-up doors allow natural light to enter, promoting plant growth. The inner side is made of highly elastic PVC, and the outer side is wear-resistant Oxford fabric.
- **Ventilated Louvered Doors:** Front louvered doors facilitate ventilation, keeping stored items dry.
- **Ergonomic Height:** Designed at an optimal height to reduce bending and squatting, making gardening more comfortable, especially for individuals with back pain.
- **Secure Closures:** Equipped with door handles, magnetic latches, and Velcro fasteners for flexible and secure door operation.
- **Raised Feet:** Elevated design helps protect the cabinet from ground moisture.

4. Setup and Assembly

Assembly is required for this product. Please refer to the detailed installation instructions provided in the PDF manual for step-by-step guidance. A power drill and a second person are recommended for easier assembly.
Download Installation Manual: Installation Instructions (PDF)

4.1. Components Overview

Before starting, ensure all parts are present and undamaged. Refer to the parts list in the PDF manual.



Image: Close-up of the cabinet's fir wood and metal worktop, highlighting its solid, crack-resistant, and weather-resistant properties, along with the rust-resistant and high-load-bearing metal work surface.



Image: Detail of the unique roll-up door mechanism, showing the highly elastic PVC interior and wear-resistant Oxford fabric exterior, along with a velcro fastener for securing the door.



Image: Close-up showing the door handle, magnetic closure, ventilated louvered doors, and raised feet of the garden cabinet, illustrating design details for functionality and durability.

4.2. Assembly Steps (Summary)

1. Unpack all components and verify against the parts list.
2. Assemble the main frame of the cabinet.
3. Attach the metal worktop securely.
4. Install the internal shelves.
5. Mount the louvered doors and ensure magnetic closures are functional.
6. Install the roll-up doors, ensuring they can be smoothly rolled up and secured with Velcro fasteners.
7. Place the cabinet on a firm, level surface.

Note: Some users have reported challenges with pre-drilled holes and alignment. Patience and careful adherence to the

PDF instructions are crucial.

5. Operating Instructions

5.1. Using the Worktop

The metal worktop is designed for potting plants, mixing soil, or as a general workspace for gardening tasks. Its ergonomic height reduces strain. Ensure the weight on the worktop does not exceed 50 kg.

5.2. Accessing Storage

The cabinet features two internal shelves. Open the louvered doors using the handles and magnetic latches to access your tools and supplies. Each shelf can hold up to 20 kg.



Image: The garden cabinet with its louvered doors open, revealing two internal shelves stocked with gardening tools, watering cans, and potted plants on the worktop, demonstrating its 2-in-1 functionality.

5.3. Using the Roll-Up Doors

The three roll-up doors can be opened to allow natural sunlight to reach plants placed inside or on the shelves. To open, simply roll them upwards. Use the integrated Velcro fasteners to secure them in the open position. To close, unfasten the Velcro and gently roll them down.

6. Maintenance

Regular maintenance will extend the life of your COSTWAY Garden Storage Cabinet.

- **Cleaning:** Wipe the wooden surfaces with a damp cloth. The metal worktop can be cleaned with mild soap and water. Avoid harsh chemicals that may damage the finish.
- **Wood Care:** The fir wood is painted for weather resistance. Periodically check for any signs of wear or peeling paint and reapply a suitable outdoor wood sealant or paint if necessary to maintain protection.
- **Roll-Up Doors:** Clean the PVC and Oxford fabric with a damp cloth. Ensure they are dry before rolling them down for extended periods to prevent mold or mildew.
- **Hardware:** Periodically check all screws, bolts, and fasteners to ensure they are tight. Tighten any loose hardware to maintain stability.
- **Winter Storage:** While designed for outdoor use, consider moving the cabinet to a sheltered location or covering it during harsh winter conditions to prolong its lifespan.

7. Troubleshooting

If you encounter issues with your garden cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners; uneven ground; incorrect assembly.	Ensure all screws and bolts are securely tightened. Move the cabinet to a level surface. Review the assembly instructions to confirm all steps were followed correctly.
Doors do not close properly or are difficult to operate.	Misaligned hinges; warped wood; magnetic latches not engaging; roll-up door mechanism obstructed.	Check hinge alignment and adjust if necessary. Ensure the cabinet is square. Clear any obstructions from the roll-up door tracks. Verify Velcro fasteners are correctly attached.
Wood splitting or paint peeling.	Exposure to harsh weather; natural wear and tear; minor manufacturing defect.	Apply an outdoor wood sealant or paint to affected areas. Consider placing the cabinet in a more sheltered location or using a protective cover. Contact customer support if the damage is significant and unexpected.
Overloading the worktop or shelves.	Exceeding stated weight limits.	Remove excess weight. Ensure the worktop does not exceed 50 kg and each shelf does not exceed 20 kg.

8. Specifications

Detailed specifications for the COSTWAY Garden Storage Cabinet:

- **Brand:** COSTWAY
- **Model Number:** GT4027GRDE
- **Color:** Grey
- **Materials:** Fir Wood, Metal (worktop), Oxford Fabric (roll-up doors), PVC (roll-up doors interior)
- **Overall Dimensions (L x W x H):** 67 cm x 47 cm x 100 cm (approximately 26.4 in x 18.5 in x 39.4 in)
- **Worktop Load Capacity:** 50 kg (approximately 110 lbs)
- **Shelf Load Capacity:** 20 kg (approximately 44 lbs) per shelf
- **Door Style:** Roll-up and Louvered doors
- **Assembly Required:** Yes
- **Water Resistance Level:** Not waterproof (weather-resistant paint)

- **Net Weight:** 11 kg (approximately 24.2 lbs)



Image: Diagram illustrating the overall dimensions of the garden cabinet, including height (100cm), width (67cm), depth (47cm), and internal shelf dimensions (38cm height, 39cm height, 44cm depth).

9. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact COSTWAY customer service directly or refer to the retailer's return policy. Keep your purchase receipt as proof of purchase.

© 2023 COSTWAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCSGF3G1

More documents and user manuals: **https://manuals.plus/**