

YESHOMY YH-EC23-0165-BN

YESHOMY Farmhouse Barn Door Cabinet YH-EC23-0165-BN
Instruction Manual

Model: YH-EC23-0165-BN

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the YESHOMY Farmhouse Barn Door Cabinet. This versatile piece of furniture is designed to provide functional storage and enhance the aesthetic of various rooms in your home. Its robust construction and thoughtful design make it suitable for use as a coffee bar, kitchen cabinet, entryway storage, or a general accent cabinet.

Key features include:

- **Multi-functional Design:** Adaptable for use in kitchens, dining rooms, living rooms, bathrooms, or entryways.
- **Ample Storage Capacity:** Features a spacious drawer and a lower cabinet with adjustable shelving to accommodate various item sizes.
- **Farmhouse Aesthetic:** Crafted from wood with a rustic grain finish, complemented by barn-door style cabinet fronts and decorative metal corner accents.
- **Stable Construction:** Engineered with quality wooden materials and metal connectors for enhanced stability and durability.



Image 1.1: Front view of the YESHOMY Farmhouse Barn Door Cabinet, showcasing its rustic design and hardware.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the cabinet on a soft, clean surface (e.g., carpet or cardboard) to prevent scratches.
- Ensure all connections are securely tightened before using the cabinet. Periodically check and re-tighten fasteners as needed.

- Do not overload the shelves or drawer. Distribute weight evenly to maintain stability.
- For added safety, especially in homes with children, consider anchoring the cabinet to a wall using appropriate hardware (not included) to prevent tipping.
- Do not stand or climb on the cabinet.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (top, bottom, sides, back, drawer components, door panels)
- Adjustable shelves
- Hardware pack (screws, dowels, cam locks, drawer slides, handles, hinges, magnetic catches)
- Assembly Manual

Tools Required (Not Included): Phillips head screwdriver, hammer, drill (optional, for pilot holes if needed).

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward with the included detailed manual. Follow the step-by-step illustrations carefully. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Lay out all components on a soft, clean surface. Match each part to the corresponding label in the assembly manual.
2. **Assemble the Frame:** Begin by connecting the side panels to the bottom and top panels using the provided hardware. Ensure all cam locks and screws are tightened.
3. **Install Back Panel:** Secure the back panel to the assembled frame. Ensure it is properly aligned to maintain the cabinet's squareness.
4. **Assemble and Install Drawer:** Follow the instructions to assemble the drawer box. Attach the drawer slides to both the drawer and the cabinet interior. Carefully insert the assembled drawer into the cabinet. *Note: Some users have reported missing pilot holes for drawer slides or door hinges. If encountered, carefully pre-drill small pilot holes to ensure proper alignment and prevent wood splitting.*
5. **Attach Doors:** Secure the hinges to the cabinet doors and then attach the doors to the cabinet frame. Adjust hinges as necessary to ensure proper door alignment and smooth operation. Install the magnetic catches.
6. **Insert Adjustable Shelves:** Place the shelf pins into the desired holes within the cabinet. Position the adjustable shelves on top of the pins.
7. **Attach Handles:** Secure the handles to the drawer and cabinet doors.

PRODUCT DIMENSION

Removable partitions

 150LBS



Image 4.1: Diagram illustrating product dimensions and the internal structure with adjustable shelves and a drawer.



Image 4.2: Detail showing the adjustable shelf feature within the cabinet.

5. OPERATING INSTRUCTIONS AND USAGE

The YESHOMY cabinet is designed for versatile use in various settings.

- **Drawer:** Utilize the top drawer for storing smaller items, utensils, or accessories.
- **Adjustable Shelves:** The lower cabinet features adjustable shelves. To change shelf height, remove the shelf, reposition the shelf pins to the desired level, and then place the shelf back on the pins. This allows customization for taller or shorter items.
- **Barn Doors:** The cabinet doors open to reveal the main storage compartment. Magnetic catches ensure the doors remain closed when not in use.
- **Multi-purpose Functionality:** This cabinet can serve as a coffee bar, a buffet sideboard for dining essentials, an accent piece in a living room, or a storage unit in an entryway or bathroom.



Image 5.1: The cabinet configured as a coffee bar, demonstrating its wide desktop and storage capabilities.



Image 5.2: The cabinet providing organized storage for kitchenware and pantry items.

6. MAINTENANCE

Proper care will help maintain the appearance and longevity of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the wood.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.

7. TROUBLESHOOTING

If you encounter issues with your cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and cam locks are fully tightened. Place the cabinet on a level surface. Consider using furniture levelers if needed.
Drawer does not close fully or smoothly.	Drawer slides misaligned; obstruction; incorrect assembly.	Check that drawer slides are correctly installed and aligned on both the drawer and cabinet. Ensure no items are obstructing the drawer's path. Re-check assembly steps for the drawer.
Cabinet doors do not close properly or are misaligned.	Hinges misaligned or loose; magnetic catches not engaging.	Adjust the hinges to align the doors. Ensure all hinge screws are tight. Verify that the magnetic catches are properly installed and making contact with the door plates.
Missing pilot holes during assembly.	Manufacturing variation.	Carefully mark the correct position and use a small drill bit to create pilot holes before inserting screws. Exercise caution to avoid drilling too deep or damaging the material.

8. SPECIFICATIONS

- **Brand:** YESHOMY
- **Model Name:** Coffee Bar and Accent Cabinet
- **Model Number:** YH-EC23-0165-BN
- **Color:** Brown
- **Product Dimensions:** 15.75"D x 31.5"W x 33.46"H
- **Item Weight:** 71.3 pounds
- **Material:** Wood (Frame, Top, Back)
- **Handle Material:** Metal
- **Special Feature:** Adjustable Shelf
- **Number of Shelves:** 2 (adjustable)
- **Number of Levels:** 2
- **Mounting Type:** Floor Mount
- **Installation Type:** Freestanding
- **Door Style:** Shaker (Barn Door aesthetic)
- **Finish Type:** Unfinished (referring to the natural wood look)
- **Assembly Required:** Yes
- **UPC:** 774816239625

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. If you require assistance with assembly, missing parts, or have any questions regarding your YESHOMY Farmhouse Barn Door Cabinet, please reach out to the manufacturer or the retailer from whom you purchased the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CCSJFJ7C>

More documents and user manuals: <https://manuals.plus/>