

[Manuals.plus](#) /

> [Skullcandy](#) /

> Skullcandy Terrain XL Wireless Bluetooth Speaker User Manual

Skullcandy Terrain XL

Skullcandy Terrain XL Wireless Bluetooth Speaker

USER MANUAL

Introduction

The Skullcandy Terrain XL is a robust and portable wireless Bluetooth speaker designed for various environments. It features IPX7 waterproofing, ensuring durability against water immersion, and offers up to 18 hours of battery life for extended listening. With its Multi-Link technology, you can connect multiple Terrain speakers for a broader sound experience. This manual provides essential instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your speaker.

What's in the Box

Verify that all items are present in the packaging:

- SKDY Terrain™ XL Wireless Speaker
- USB-C to USB-A Charging Cable (3 ft)
- Quick Start Guide (not included in this manual)






Image: The Skullcandy Terrain XL speaker in Navy color, shown with its packaging.

Product Overview

Familiarize yourself with the speaker's controls and ports:

- **Power Button:** Located on the side, used for powering on/off and pairing.
- **Bluetooth Pairing Button:** Activates Bluetooth pairing mode.
- **Volume Up/Next Track Button:** Increases volume or skips to the next track.
- **Volume Down/Previous Track Button:** Decreases volume or goes to the previous track.
- **Multi-Link Button:** Initiates connection with other Skullcandy Terrain speakers.
- **USB-C Charging Port:** For charging the speaker.
- **LED Indicators:** Display battery level and connection status.
- **Nylon Wrist Wrap:** For convenient portability.



Image: A detailed view of the side panel of the Skullcandy Terrain XL speaker, showing the power button, Bluetooth button, LED indicators, and USB-C charging port.

Setup

1. Charging the Speaker

1. Connect the provided USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable (USB-A) to a compatible USB power adapter (not included) or a computer's USB port.
3. The LED indicators will show the charging status. A full charge is indicated when all LEDs are solid.

A full charge provides up to 18 hours of playtime.

2. Powering On/Off

- **To Power On:** Press and hold the Power button for 2 seconds. You will hear an audible tone, and the LED indicators will light up.
- **To Power Off:** Press and hold the Power button for 2 seconds. You will hear an audible tone, and the LEDs will turn off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within range of your Bluetooth device.
2. Press the Bluetooth Pairing button on the speaker. The LED indicator will flash, indicating it is in pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and enable Bluetooth.
4. Select "Skullcandy Terrain XL" from the list of available devices.
5. Once connected, you will hear a confirmation tone, and the LED indicator will turn solid.

4. Multi-Link Pairing (True Wireless Stereo)

The Terrain XL speaker supports Multi-Link, allowing you to connect up to 99 Skullcandy Terrain speakers for a synchronized audio experience.

1. Ensure all speakers you wish to link are powered on and not currently paired to any Bluetooth device.
2. On the first speaker (which will act as the primary), pair it with your Bluetooth device as described in step 3.
3. On the primary speaker, press the Multi-Link button. The LED will flash.
4. On each additional speaker you want to link, press its Multi-Link button.
5. The speakers will automatically connect to each other. A confirmation tone will sound, and the Multi-Link LEDs on all connected speakers will turn solid.



Image: Three Skullcandy Terrain speakers of different colors (pink, green, navy) shown together, illustrating the Multi-Link feature.

Operating Instructions

Basic Controls

- **Play/Pause:** Press the Power button once.
- **Volume Up:** Press the Volume Up button once.
- **Volume Down:** Press the Volume Down button once.
- **Next Track:** Press and hold the Volume Up button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down button for 2 seconds.

Multi-Link Operation

- Once speakers are linked, audio playback and volume control from your paired device will be synchronized across all connected speakers.
- To disconnect a single speaker from the Multi-Link group, press its Multi-Link button.
- To disconnect all speakers, power off the primary speaker or disconnect it from your Bluetooth device.

Maintenance

Cleaning

- Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the USB-C port cover is securely closed when not charging to maintain IPX7 water resistance.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% to preserve battery health.



Image: Multiple Skullcandy Terrain speakers partially submerged in water, demonstrating their IPX7 waterproof capability.

Troubleshooting

- **Speaker not turning on:** Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
- **Cannot pair via Bluetooth:**
 - Ensure the speaker is in pairing mode (flashing LED).

- Make sure Bluetooth is enabled on your device and it is within 10 meters of the speaker.
 - Forget "Skullcandy Terrain XL" from your device's Bluetooth list and try pairing again.
 - Power cycle both the speaker and your Bluetooth device.
- **No sound or low volume:**
 - Check the volume levels on both the speaker and your connected device.
 - Ensure the speaker is properly paired and connected.
- **Multi-Link not working:**
 - Ensure all speakers are Skullcandy Terrain models and are not individually paired to a Bluetooth device before initiating Multi-Link.
 - Follow the Multi-Link pairing steps carefully, starting with the primary speaker.
- **Sound quality issues:** Ensure the speaker's firmware is up to date via the Skullcandy app. Some users have reported improved sound quality after a firmware update.

Specifications

Model Name	2SKSK1848
Brand	Skullcandy
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Water Resistance Level	IPX7 (Waterproof)
Battery Life	Up to 18 Hours
Power Source	Battery Powered (1 Lithium Ion battery included)
Product Dimensions	3.5"D x 3.5"W x 7.5"H
Item Weight	2.07 pounds (33.12 Ounces)
Speaker Type	Outdoor
Audio Output Mode	Stereo
Bluetooth Range	10 Meters
UPC	812350262546



Image: A diagram showing the dimensions of the Skullcandy Terrain XL speaker: 7.5 inches tall, 3.5 inches wide, and 3.5 inches deep.

Warranty and Support

The Skullcandy Terrain XL Wireless Bluetooth Speaker comes with a manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Skullcandy website. For technical support, product registration, or to access additional resources, please visit [Skullcandy Support](#).