

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [AMONIDA](#) /

> [AMONIDA X3 Pro Video Doorbell User Manual](#)

AMONIDA X3 Pro

AMONIDA X3 Pro Video Doorbell User Manual

HD Night Vision Smart Doorbell for Home Safety

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AMONIDA X3 Pro Video Doorbell. Please read this manual thoroughly before use to ensure proper functionality and safety. The X3 Pro is designed to enhance home security by providing clear video communication with visitors at your door, featuring high-definition night vision and convenient installation options.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Smart Doorbell (X3 Pro Video Doorbell Unit)
- 1 x Dingdong (Indoor Chime Unit)
- 1 x English Manual
- 2 x Expansion Tubes
- 2 x Expansion Screws
- 1 x Adhesive Sticker



Figure 2.1: Package contents including the doorbell, dingdong, and mounting hardware.




Figure 2.2: Detailed view of the adhesive sticker, two screws, and two green expansion tubes for mounting.

3. PRODUCT OVERVIEW

The AMONIDA X3 Pro Video Doorbell system consists of two main components: the outdoor doorbell

unit and the indoor dingdong chime unit.



Figure 3.1: The X3 Pro Video Doorbell (left) and the indoor Dingdong unit (right).



Figure 3.2: Angled view of the doorbell and dingdong units, showing their compact design.



Figure 3.3: Close-up of the indoor Dingdong unit, highlighting its speaker grille for clear audio alerts.

Key Features:

- **Video Call:** Initiate and receive video calls via the doorbell.
- **APP Voice Call:** Communicate with visitors through a connected mobile application.
- **Voice Change Intercom:** Feature allowing modification of voice during two-way communication for privacy or security.
- **Wide Angle Lens:** Provides a broad field of view for comprehensive monitoring.
- **High Definition Night Vision:** Ensures clear visibility of visitors even in low-light conditions.
- **Extra Long Range:** Extended wireless range between doorbell and dingdong unit.
- **Quick Installation:** Designed for easy setup.
- **Clear and Loud Volume:** Audible alerts from the dingdong unit.
- **Automatic Capture:** Records images or video upon motion detection or doorbell press.




Figure 3.4: Visual representation of the X3 Pro's primary features.

4. SETUP AND INSTALLATION

The AMONIDA X3 Pro Video Doorbell offers two installation methods: adhesive mounting or screw fixing.

4.1. Battery Installation

The doorbell unit requires dry batteries for power (batteries not included). Open the battery compartment on the back of the doorbell unit and insert the specified batteries, ensuring correct polarity. Close the compartment securely.

4.2. Doorbell Unit Installation

Choose a suitable location near your door, ensuring a clear view of the entrance.

Method 1: Adhesive Installation

1. Clean the mounting surface thoroughly to ensure it is dry and free of dust or grease.
2. Peel off the protective film from the industrial-grade adhesive sticker provided.
3. Firmly press the doorbell unit onto the desired location for at least 30 seconds.

4. Allow the adhesive to cure for several hours before regular use to ensure maximum adhesion.

Method 2: Punching Installation with Screws

1. Mark the desired drilling points on the wall using the doorbell unit as a template.
2. Drill two holes at the marked positions.
3. Insert the expansion tubes into the drilled holes.
4. Align the doorbell unit with the holes and secure it using the provided expansion screws.

CONVENIENT INSTALLATION



Figure 4.1: Illustration of convenient installation options: industrial-grade adhesive for non-punching installation (top) and punching installation with expansion screws (bottom).

4.3. Dingdong Unit Setup

The indoor dingdong unit is designed for easy placement. Simply plug it into a standard power outlet within range of the doorbell unit. No complex wiring is required.

5. OPERATING INSTRUCTIONS

5.1. Initial Pairing (if required)

If the doorbell and dingdong units are not pre-paired, follow the instructions in the included English Manual to pair them. Typically, this involves pressing a pairing button on both devices within a short timeframe.

5.2. Visitor Notification

When a visitor presses the doorbell button, the outdoor unit will send a signal to the indoor dingdong unit, which will chime. Simultaneously, a notification will be sent to your connected mobile application.

5.3. Two-Way Audio and Video Communication

Upon receiving a notification, open the mobile application to view the live video feed from the doorbell camera. You can then initiate two-way audio communication with the visitor. The system supports bidirectional voice with high-power speakers and sensitive microphones for clear interaction.

BIDIRECTIONAL CALL, INTELLIGENT VOICE CHANGE

Bidirectional voice design, paired with high-power speakers and high sensitivity microphones, ensures clear and smooth visual communication in front of the door. Support voice changing intercom, easily change boys, and easily respond to various situations

Figure 5.1: Example of bidirectional communication, allowing clear interaction with visitors and supporting voice change features.

5.4. Night Vision Function

The X3 Pro doorbell is equipped with high-definition night vision. This feature automatically activates in low-light conditions, ensuring that visitors' faces and activities can be clearly seen and recorded even in complete darkness.

5.5. Voice Change Intercom

For added privacy or security, the doorbell system includes an intelligent voice change feature. This allows you to modify your voice during intercom conversations, providing an additional layer of safety when interacting with unknown visitors.

6. MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the exterior of both the doorbell and dingdong units. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace the doorbell unit's dry batteries as needed. Low battery indicators will typically appear in the mobile application.
- **Firmware Updates:** Regularly check the mobile application for any available firmware updates to ensure optimal performance and security.
- **Environmental Protection:** While the doorbell is designed for outdoor use, avoid direct exposure to extreme weather conditions if possible to prolong its lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Doorbell not ringing dingdong unit.	Low batteries in doorbell unit; Dingdong unit unplugged; Out of range; Not paired.	Replace doorbell batteries; Ensure dingdong unit is plugged in; Move dingdong closer to doorbell; Re-pair units as per manual.
No video feed or poor video quality.	Weak Wi-Fi signal; Camera lens obstructed; Low battery.	Check Wi-Fi connection and router proximity; Clean camera lens; Replace doorbell batteries.
Two-way audio not working.	Microphone/speaker obstruction; App permissions; Network issue.	Ensure no obstructions; Check app microphone permissions; Verify stable internet connection.
Doorbell unit not powering on.	Batteries inserted incorrectly; Dead batteries.	Check battery polarity; Replace with fresh batteries.

8. SPECIFICATIONS

Feature	Detail
Product Material	ABS

Feature	Detail
Doorbell Camera Size	Approx. 46x25x73mm / 1.81x0.98x2.87in
Dingdong Inner Machine Size	Approx. 43x32x41mm / 1.69x1.26x1.61in
Weight	Approx. 73g / 2.6oz (total package weight)
Battery Type (Doorbell)	Dry Battery (x3, not included)
Night Vision	High-definition
Connectivity	Wireless
Manufacturer	AMONIDA
Model Number	AMONIDAivp0hnr6

PRODUCT SIZE




Figure 8.1: Detailed dimensions of the doorbell camera and indoor dingdong machine.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase documentation or visit the official AMONIDA website. Keep your purchase receipt as proof



of purchase for warranty claims.

For further assistance, please contact customer support:

- **Website:** Visit [AMONIDA's official website for support](#).
- **Email:** Refer to product packaging or official website.

© 2024 AMONIDA. All rights reserved.
This manual is subject to change without notice.

Related Documents - X3 Pro

	<p>Ring Playbook: Ontdek Slimme Deurbellen, Camera's en Beveiligingssystemen Verken het Ring Playbook voor een uitgebreid overzicht van Ring's slimme deurbellen, beveiligingscamera's, Ring Alarm en accessoires. Leer hoe Ring je huis veiliger maakt.</p>
	<p>Wasserstein Doorbell Vinyl Siding Mount: Installation Guide & User Manual Detailed user manual and installation guide for the Wasserstein Doorbell Vinyl Siding Mount. Learn how to easily install the mount for Wyze Video Doorbell Pro, Google Nest Doorbell (Battery), and Blink Video Doorbell. Includes product specifications and support contact.</p>
	<p>Botslab Video Doorbell 2 Pro Quick Start Guide Setup and Installation Get started with your Botslab Video Doorbell 2 Pro. This quick start guide provides step-by-step instructions for installation, network connection, and setup.</p>
	<p>Horizontal Wedge for Wyze Video Doorbell Pro User Manual User manual providing installation instructions for the Wasserstein Horizontal Wedge accessory designed for the Wyze Video Doorbell Pro.</p>
	<p>Smart Video Doorbell Quick Start Guide A quick start guide for the Smart Video Doorbell, covering packing list, appearance introduction, setup instructions, and pairing with the chime.</p>



[Ring Software Version History and Release Notes](#)

Comprehensive release notes and version history for Ring software updates, detailing firmware versions, release dates, device compatibility, and file sizes for Ring Alarm, Video Doorbells, Surveillance Cameras, Access Control devices, and Accessories.