

[Manuals.plus](#) /

> [AODK](#) /

> AODK 3-Drawer Dresser Instruction Manual

AODK 3-Drawer Dresser (B0CCV4X6PJ)

AODK 3-Drawer Dresser Instruction Manual

Model: 3-Drawer Dresser (B0CCV4X6PJ)

Brand: AODK

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your AODK 3-Drawer Dresser. Please read these instructions carefully before beginning assembly and retain them for future reference. This dresser is designed for organizing and storing clothes and other items in various rooms such as bedrooms, living rooms, and closets.





Image 1.1: The AODK 3-Drawer Dresser, featuring a black metal frame, three black fabric drawers, and a dark wooden top surface. It is shown with decorative items on top, highlighting its use as a storage unit.

2. SAFETY INFORMATION

To ensure safe use of this product, please adhere to the following guidelines:

- **Do Not Exceed The Maximum Load Capacity.** Overloading drawers or the top surface can compromise stability and lead to damage or injury.
- Always place the dresser on a flat, stable, and level surface.
- Utilize the anti-tipping design by securing the dresser to a wall, especially if children are present.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Regularly check all connections and fasteners to ensure they remain tight.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Metal Frame Components (legs, crossbars, side supports)
- Wooden Top Board
- Fabric Drawers (3 units)
- Drawer Handles (3 units)
- Adjustable Feet
- Anti-Tipping Hardware
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Follow these steps carefully. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Refer to the parts list to ensure everything is present.
2. **Assemble the Metal Frame:** Connect the vertical frame pieces using the provided crossbars and screws. Ensure all connections are secure but do not overtighten until the frame is fully assembled. The frame includes an X-cross bar for enhanced stability.
3. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the frame legs. These feet help stabilize the dresser on uneven surfaces.
4. **Install the Wooden Top Board:** Place the wooden top board onto the assembled metal frame and secure it with the designated screws.
5. **Prepare Fabric Drawers:** Insert the bottom panel into each fabric drawer and attach the handles. Note that handle designs may vary; both new and old versions are randomly dispatched.
6. **Insert Drawers:** Slide the assembled fabric drawers into the designated slots within the metal frame.
7. **Install Anti-Tipping Device:** Secure the anti-tipping hardware to the back of the dresser and to a wall stud, following the specific instructions provided with the hardware. This step is crucial for safety.



Image 4.1: An illustration showing an 'Upgrade Notice' for the dresser's handle design. Both the older straight handle and the newer curved handle versions are dispatched randomly, maintaining consistent quality and functionality.

5. OPERATING (USAGE)

The AODK 3-Drawer Dresser is designed for versatile storage. Its compact size makes it suitable for various spaces.

- **Drawer Functionality:** The fabric drawers are designed to slide smoothly. To open, gently pull the handle. To close, push the drawer back into the frame until it is fully seated.
- **Storage Capacity:** Each drawer measures 8.3 inches deep, providing ample space for organizing clothes, accessories, and other household items.
- **Versatile Placement:** This unit can function as a nightstand in a bedroom, an end table in a living room, or a storage organizer in a closet.



Image 5.1: The dresser with its drawers open, demonstrating its storage capacity for various items like folded garments and accessories.



Large Capacity of the Dresser

 20+ Toys	 150+ Socks
 30+ Pants	 50+ T-shirt

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the wooden top board and metal frame with a dry cloth. For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then allow to air dry completely. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if any looseness is detected.
- **Environmental Conditions:** Avoid exposing the dresser to excessive moisture or direct sunlight for prolonged periods, as this can cause damage to the materials.




Image 6.1: A detailed view of the dresser's quality wooden top board, emphasizing its sleek texture, waterproof properties, and durability.

7. TROUBLESHOOTING

If you encounter issues with your dresser, consider the following common solutions:

- **Dresser is Unstable/Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet on the bottom of the legs to compensate for uneven flooring.
 - Verify the anti-tipping device is correctly installed and secured to the wall.
- **Drawers Do Not Slide Smoothly:**
 - Check that the fabric drawers are correctly assembled with the bottom panel fully inserted.
 - Ensure no items inside the drawer are obstructing its movement.
 - Verify the metal frame is not bent or damaged, which could impede drawer movement.
- **Missing or Damaged Parts:** If you discover missing or damaged parts during or after assembly, please contact AODK customer service for assistance.

8. SPECIFICATIONS

Key specifications for the AODK 3-Drawer Dresser:

Feature	Detail
Brand	AODK
Model Name	3-Drawer Dresser
Product Dimensions (D x W x H)	11.73"D x 15.74"W x 28.81"H
Color	Black
Room Type	Closet, Bedroom, Living Room, Hallway
Furniture Finish	Polished
Drawer Type	Under Mounted Slide
Item Weight	10.62 pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
UPC	850053190940

Product Dimensions



Image 8.1: A visual representation of the dresser's dimensions, including overall height, width, depth, and individual drawer depth.

9. WARRANTY AND SUPPORT

AODK is committed to providing quality products and excellent customer service. While specific warranty details are not included in this manual, we offer 24/7 installation consultation and support for any quality issues.

For assistance with assembly, troubleshooting, or any product-related inquiries, please contact AODK customer service through the retailer's platform or the official AODK website. Please have your model number (B0CCV4X6PJ) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CCV4X6PJ>

More documents and user manuals: **<https://manuals.plus/>**