

FLEXISPOT MAH0002389

FLEXISPOT 63x24 Inch Electric Height Adjustable Standing Desk Instruction Manual

Model: MAH0002389

1. INTRODUCTION

Thank you for choosing the FLEXISPOT Electric Height Adjustable Standing Desk. This ergonomic desk is designed to enhance your workspace by allowing seamless transitions between sitting and standing positions, promoting better posture and productivity. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk.



Image 1: FLEXISPOT 63x24 Inch Electric Height Adjustable Standing Desk. This desk offers a spacious work area for

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Ensure the desk is properly assembled according to the instructions to support up to 154 pounds. Overloading the desk may cause instability or damage.
- **Clearance:** Ensure there is adequate clearance around the desk during height adjustments to prevent pinching or crushing. Keep children and pets away from moving parts.
- **Power Supply:** Use only the provided power adapter. Do not use the desk if the power cord or plug is damaged.
- **Liquid Spills:** Avoid placing liquids directly on the desk surface. In case of a spill, immediately unplug the desk and wipe it dry.
- **Assembly:** Do not modify the desk structure. All assembly steps must be followed precisely.

3. SETUP

The FLEXISPOT standing desk is designed for hassle-free setup. All necessary assembly tools and clear instructions are included. For visual guidance, please refer to the official installation video below.

3.1 Assembly Steps Overview

1. **Desktop Assembly:** Connect the splice board sections of the desktop using the provided dowels and metal plates. Secure with screws.
2. **Drive Rod Installation:** Insert the drive rod into the motor and ensure it is properly seated.
3. **Frame Assembly:** Attach the beams to the columns, ensuring pilot holes align with bulges. Secure with screws.
4. **Feet Attachment:** Install the desk feet to the bottom of the columns.
5. **Desktop Attachment:** Carefully place the assembled frame onto the underside of the desktop. Align the pre-drilled holes and secure the frame to the desktop using screws.
6. **Cable Management:** Connect the motor and control panel cables. Use cable ties or clips (if provided) to manage cables neatly.

3.2 Installation Video

Your browser does not support the video tag.

Video 1: FLEXISPOT 55/63 inch Standing Desk Installation Guide. This video provides a step-by-step visual guide for assembling your desk.

4. OPERATING INSTRUCTIONS

Your FLEXISPOT desk features an ergonomic memory controller for easy height adjustments and personalized settings.

4.1 Control Panel Overview




Image 2: Multi-function keypad. Features an LED display, up/down arrows for manual adjustment, and four memory preset buttons.

- **LED Display:** Shows the current height of the desk in inches.
- **Up/Down Arrows (^ / v):** Press and hold to manually adjust the desk height. Release to stop.
- **Memory Presets (1, 2, 3, 4):** Save your preferred sitting and standing heights for quick adjustments.

4.2 Adjusting Desk Height

1. **Manual Adjustment:** Press and hold the ^ (up) or v (down) arrow button until the desk reaches your desired height. The motor operates quietly (<50dB) for minimal disturbance.
2. **Setting Memory Presets:**
 - a. Adjust the desk to your desired height using the manual up/down arrows.
 - b. Press the 'M' button (or similar memory set button, if available) followed by one of the number buttons (1, 2, 3, or 4). The display will confirm the setting.
3. **Using Memory Presets:** Simply press the corresponding number button (1, 2, 3, or 4) to automatically move the desk to your saved height.



Image 3: Wide Height Adjustable. The desk adjusts from a minimum of 28.9 inches to a maximum of 46.5 inches.

5. MAINTENANCE

Proper care ensures the longevity and optimal performance of your FLEXISPOT desk.

- **Cleaning the Desktop:** The desktop is waterproof, scratch-resistant, and smooth. Use a soft, damp cloth with mild soap to clean the surface. Avoid abrasive cleaners.
- **Frame Maintenance:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Inspection:** Regularly inspect the power cord and control cables for any signs of damage. Replace immediately if damage is found.



Image 4: High-Quality Desktop. The desk surface is waterproof, scratch-resistant, and smooth for easy maintenance.

6. TROUBLESHOOTING

If you encounter any issues with your desk, please try the following steps:

- **No Power:** Check if the power cord is securely plugged into both the desk and a working wall outlet.
- **Desk Not Adjusting:** Ensure all cables are properly connected. If an error code appears on the LED display, refer to the full user manual (if provided) for specific code meanings.
- **Uneven Movement:** Ensure the desk is placed on a level surface. Check that all leg components are securely fastened.

If the problem persists, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Number	MAH0002389
UPC	810072840028
Product Dimensions (D x W x H)	24"D x 63"W x 29"H
Size	63 x 24-inch
Color	Maple (Top), White (Frame)
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Finish Type	Wood
Special Feature	with Splice Board, Height Range Of 28.9"- 46.5", Hooks
Maximum Weight Recommendation	154 Pounds
Minimum Height	28.9 Inches
Maximum Height	46.5 Inches
Item Weight	20 Kilograms
Required Assembly	Yes
Included Components	Instruction Manual, Assembly Tools




Image 5: Desk Dimensions. The desk measures 63 inches in width and 24 inches in depth.

8. WARRANTY







This FLEXISPOT standing desk comes with a **Limited Warranty**. Please refer to the product packaging or the official FLEXISPOT website for detailed warranty terms and conditions.

9. SUPPORT

For any questions regarding assembly, operation, or troubleshooting, our support team is ready to help!

- **Customer Support:** Refer to the contact information provided on the product packaging or the official FLEXISPOT website.

Related Documents - MAH0002389

	FlexiSpot E7QB Standing Desk User Manual Comprehensive user manual for the FlexiSpot E7QB standing desk, covering components, installation, usage, troubleshooting, and warranty information.
	FlexiSpot E7B/E7W/E7S-Plus Height Adjustable Desk User Manual & Installation Guide Detailed user manual for FlexiSpot E7B-Plus, E7W-Plus, and E7S-Plus height adjustable desks. Includes technical specifications, step-by-step installation instructions, handset operation, troubleshooting guide, and warranty information.
	FlexiSpot E5-UKV2 Standing Desk Frame User Manual and Installation Guide Comprehensive user manual and installation guide for the FlexiSpot E5-UKV2 electric height-adjustable desk frame. It includes detailed specifications, component identification, step-by-step assembly guidance, keypad functions, troubleshooting tips, and safety precautions. Learn how to set up your ergonomic workspace with FlexiSpot.
	FlexiSpot E3LB/E3LS/E3LW Electric Height Adjustable Desk Frame Installation Guide Detailed installation guide for the FlexiSpot E3LB, E3LS, and E3LW electric height adjustable desk frames, including specifications, parts list, assembly steps, handset operation, and warranty information.
	FlexiSpot EH1-EU Electric Standing Desk Frame User Manual Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.
	FlexiSpot Q8B/Q8W Height Adjustable Standing Desk Installation Guide and Warranty Comprehensive installation guide and warranty information for the FlexiSpot Q8B/Q8W height adjustable standing desk, including setup instructions, usage tips, troubleshooting, and warranty details.