



[Manuals.plus](#) /

> [WAMPAT](#) /

> WAMPAT 3-Drawer Dresser (Model W11S4082Q-F1) Instruction Manual

## WAMPAT W11S4082Q-F1

# WAMPAT 3-Drawer Dresser Instruction Manual

Model: W11S4082Q-F1

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your WAMPAT 3-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

### **WARNING: Furniture Tip-Over Hazard**

- Always secure furniture to the wall using the provided anti-tip kit to prevent serious or fatal injuries from furniture tip-over.
- Do not allow children to climb or hang on drawers, doors, or shelves.
- Place heaviest items in the lowest drawers.
- Never open more than one drawer at a time.
- Ensure all parts are correctly assembled and tightened before use.
- Keep small parts and packaging materials away from children.

## PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

### Hardware List

Part	Description	Quantity
Cam Bolts (A)	Used for connecting panels.	30

Part	Description	Quantity
Dowels (B)	Wooden pegs for alignment.	12
Cam Locks (C)	Used with cam bolts to secure panels.	12
Screws (D)	Various sizes for different connections.	36
Back Panel Fasteners (E)	Small clips for securing back panels.	6
Back Panel Screws (F)	Screws for back panel fasteners.	6
Metal Base Bolts (G)	Bolts for attaching the metal base.	6
Drawer Slide Screws (H)	Screws for attaching drawer slides.	18
Small Screws (I)	Small screws for various connections.	12
Slider Arms (J)	Components of the drawer slides.	6

## Panel List (Example)

- Top Panel
- Bottom Panel
- Side Panels (2)
- Back Panels (2)
- Drawer Fronts (3)
- Drawer Sides (6)
- Drawer Backs (3)
- Drawer Bottoms (3)
- Metal Base (2 parts)

## SETUP AND ASSEMBLY

---

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

### Assembly Video Guide

Your browser does not support the video tag.

*Official assembly video for the WAMPAT 3-Drawer Dresser. This video demonstrates the step-by-step process of putting together the dresser components.*

### Step-by-Step Instructions

1. **Prepare Panels:** Screw cam bolts (A) into panels (1, 3, 4). Attach part (18) to panel (1) with bolts (H) correctly.
2. **Attach Drawer Slides to Side Panels:** Separate the slide bracket from the slide arm as per diagram. Attach Slider arms (3,4) to panels (3,4) with screws (D) correctly.
3. **Assemble Base Structure:** Attach panel (6) to panel (7) with bolt (G) correctly. Insert dowels (B) into panel (7). Attach panel (3) to panel (7). Insert and secure cam locks (C) to lock it.
4. **Install Back Panel:** Carefully slide panel (10) into place along the back of the assembly.
5. **Attach Top Panel:** Insert dowels (B) into panels (3,4,7). Attach panel (1) to panels (3,4,7) with screws (I).

6. **Secure Metal Base:** Attach parts (9) to panel (2) with bolts (G). Attach parts (8) to parts (9) with bolts (G).
7. **Secure Back Panels:** Secure parts (E) to panels (1,3,4,7) using screws (F).
8. **Assemble Drawers:** Screw cam bolts (A) into panels (11,12,15). Attach panels (13,14) to panel (15) with screws (I). Insert dowels (B) into panel (17). Attach panel (17) to panel (15). Insert and secure cam locks (C) to lock it. Carefully slide panel (16) into place along the bottom of the assembly.
9. **Attach Drawer Slides to Drawers:** Attach slider brackets to panels (13,14) with screws (D) correctly.
10. **Insert Drawers:** Carefully insert the assembled drawers into the dresser frame.*Note: If a drawer does not go in smoothly, press or lift the plastic release lever on the slider bracket, then re-assemble the drawer until it goes in smoothly.*

## OPERATING INSTRUCTIONS

---

Your WAMPAT 3-Drawer Dresser is designed for easy and smooth operation.

- **Opening Drawers:** Gently pull the hidden handle located at the top edge of each drawer front.
- **Closing Drawers:** Push the drawer firmly until it is fully closed and flush with the dresser frame.
- **Weight Capacity:** Each drawer is designed to hold a reasonable amount of clothing or household items. Avoid overloading drawers to ensure smooth operation and prevent damage to the slides. The dresser top can hold up to 88 lbs (40 kg).

# Large Storage Space

Convenient to store your daily items



Image: Drawers open, illustrating the spacious storage capacity.

## MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe with a dry cloth. Avoid harsh chemicals or abrasive cleaners that may damage the wood finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or water damage.
- **Hardware:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.

## TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Drawers not sliding smoothly:**

- Check if the drawer slides are correctly aligned and securely attached to both the drawer and the dresser frame.
- Ensure no objects are obstructing the slides.
- Lubricate slides with a silicone-based lubricant if needed.
- **Dresser wobbles:**
  - Verify that all cam locks and bolts are fully tightened.
  - Ensure the dresser is placed on a level surface. Adjust protective foot pads if necessary.
- **Missing parts:**
  - Double-check all packaging materials. If parts are genuinely missing, contact WAMPAT customer support with your model number and a description of the missing parts.

## SPECIFICATIONS

Feature	Detail
Brand	WAMPAT
Model Number	W11S4082Q-F1
Material	High-density engineered wood, Metal base
Finish Type	Wood (Walnut)
Product Dimensions (D x W x H)	15.6"D x 31.5"W x 30.6"H (395mm D x 800mm W x 778mm H)
Number of Drawers	3
Drawer Type	Ball Bearing Slide
Maximum Weight Capacity (Top)	88 lbs (40 kg)
Assembly Required	Yes
Color	Brown
Style	Modern
Room Type	Bedroom, Living Room, Hallway, Entryway

# Display Personality



Image: Product dimensions for the WAMPAT 3-Drawer Dresser.

## WARRANTY

This WAMPAT product comes with a Lifetime Warranty. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty information provided at the time of purchase or contact WAMPAT customer support.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact WAMPAT customer support:

- **Online:** Visit the [WAMPAT Store on Amazon](#)
- **Email:** Refer to your purchase documentation for direct email support.