

[Manuals.plus](#) /

> [artfone](#) /

> artfone D6 Flip 4G LTE Senior Mobile Phone User Manual

artfone D6 Flip

artfone D6 Flip 4G LTE Senior Mobile Phone User Manual

Model: D6 Flip

1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your artfone D6 Flip 4G LTE Senior Mobile Phone. Please read this manual thoroughly before operating the device to ensure safe and efficient use. This phone is designed with user-friendly features such as large buttons, a clear display, and an SOS function, making it suitable for seniors.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all items listed below are present and in good condition:

- artfone D6 Flip Mobile Phone
- 1000mAh Lithium-ion Battery
- USB Charging Cable
- Charging Dock
- Power Adapter
- User Manual



Image 2.1: Contents of the artfone D6 Flip package, including the phone, charging dock, USB cable, power adapter, battery, and user manual.

3. DEVICE OVERVIEW

The artfone D6 Flip features a clamshell design with dual screens and large, easy-to-press buttons.

3.1 Front and External Features

DUAL LCD
2.4 inch
1.5 inch

artfone

4G LTE

SOS

A

Calendar

Camera

Music

+ -
x ÷

Flashlight



Image 3.1: The artfone D6 Flip in its closed position, highlighting the external 1.77-inch display, SOS button, and other key icons.

- **External Display:** 1.77-inch screen for quick glance at time, date, and incoming calls.
- **SOS Button:** Located on the back for emergency calls.
- **Side Buttons:** For volume control and other quick functions.

3.2 Internal Features



Image 3.2: The artfone D6 Flip opened, displaying the main 2.4-inch screen and the large, illuminated keypad.

- **Main Display:** 2.4-inch LCD screen for navigation and viewing content.
- **Keypad:** Large, backlit buttons for easy dialing and text input.
- **Navigation Keys:** Dedicated keys for menu, call, end call, and directional navigation.

4. SETUP

4.1 SIM Card and Battery Installation

1. Remove the back cover of the phone by gently prying it open from the notch.
2. If present, remove the battery.
3. Insert your Nano SIM card(s) into the designated slot(s). The phone supports dual Nano SIM cards. Ensure the gold contacts face downwards and the cut corner aligns with the slot.
4. Insert a Micro SD card (up to 64GB, optional) into its slot if you wish to expand storage.
5. Insert the 1000mAh Lithium-ion battery, ensuring the contacts align correctly.
6. Replace the back cover until it clicks securely into place.

4.2 Charging the Phone

Before first use, fully charge the phone's battery.

- **Using the Charging Dock:** Place the phone into the charging dock, ensuring it sits correctly. Connect the USB charging cable to the dock and the power adapter, then plug the adapter into a wall outlet.
- **Direct Charging:** Connect the USB charging cable directly to the phone's USB Type-C port and the power adapter, then plug the adapter into a wall outlet.

The battery indicator on the screen will show charging status. A full charge typically takes 2-3 hours.

4.3 Power On/Off

- **To Power On:** Press and hold the red 'End Call' button until the screen lights up.
- **To Power Off:** Press and hold the red 'End Call' button until the power off options appear, then confirm.

5. OPERATING INSTRUCTIONS

The artfone D6 Flip is designed for straightforward operation with its intuitive interface and large buttons.

User-friendly UI

Excellent operation



Image 5.1: Examples of the user-friendly interface on the artfone D6 Flip, displaying large icons for Contacts, Tools, Message, SOS, Calendar, and Settings.

5.1 Making and Receiving Calls

- **To Make a Call:** Open the flip, dial the number using the keypad, and press the green 'Call' button.
- **To Answer a Call:** When the phone rings, you can either open the flip to answer automatically or press the green 'Call' button. The external screen also allows answering directly via shortcut buttons.
- **To End a Call:** Press the red 'End Call' button or close the flip.

5.2 Sending and Receiving SMS Messages

- Navigate to the 'Message' menu.
- Select 'Write Message' to compose a new SMS.
- Enter the recipient's number or select from contacts.
- Type your message using the keypad.
- Press 'Send'.

5.3 SOS Emergency Function

TWO SIDE BUTTONS AND SOS

Tailored design for old people.

SOS



Two side buttons



Housing with high level painting
and good keypad with PU

Image 5.2: The rear view of the artfone D6 Flip, highlighting the prominent SOS emergency button.

- **Setting Up SOS Numbers:** Go to 'Settings' > 'SOS Settings' to add up to 5 emergency contacts.
- **Using SOS:** In an emergency, press and hold the SOS button on the back of the phone for 3 seconds. The phone will automatically dial the pre-set emergency numbers sequentially until one is answered. It will also send an emergency SMS to these contacts.

5.4 Speed Dial

One button Speed Dial

#A. Jack +39...
#B Dana +39...
#1.Son +33...
#2.Dan +33...
...
...
#9. Jean +01...



Image 5.3: The artfone D6 Flip demonstrating the speed dial feature, allowing quick access to frequently called contacts by pressing and holding assigned keys.

- **Setting Up Speed Dial:** Assign contacts to keys A and B by navigating to 'Contacts' > 'Options' > 'Speed Dial'.
- **Using Speed Dial:** Press and hold the assigned key (A or B) to directly call the associated contact.

5.5 Other Functions

- **FM Radio:** Access through the 'Multimedia' menu.
- **Alarm:** Set multiple alarms via the 'Tools' menu.
- **Calendar & Calculator:** Available in the 'Tools' menu.
- **Bluetooth:** Enable and manage Bluetooth connections in 'Settings'.
- **Time Reporting:** Press the dedicated button to hear the current time announced.

Time reporting button



Image 5.4: The artfone D6 Flip with an illustration of the time reporting button, which announces the current time when pressed.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners or abrasive materials.
- **Battery Care:** Avoid extreme temperatures. Do not expose the battery to direct sunlight or very cold conditions. Charge the battery regularly, but avoid overcharging for extended periods.
- **Storage:** If storing the phone for a long time, ensure the battery is partially charged (around 50%) and store it in a cool, dry place.
- **Water Resistance:** This phone is not waterproof. Keep it away from water and high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Phone does not power on	Battery is depleted or not inserted correctly.	Charge the battery. Ensure the battery is correctly inserted.
Cannot make or receive calls	No SIM card, SIM card not inserted correctly, or no network signal.	Ensure SIM card is correctly inserted. Check network coverage in your area.
Poor call quality	Weak network signal or interference.	Move to an area with better network reception.
SOS function not working	SOS numbers not set up or incorrect.	Verify SOS numbers in settings. Ensure numbers are valid and active.
Phone freezes or becomes unresponsive	Temporary software glitch.	Remove and reinsert the battery to perform a hard reset.

8. SPECIFICATIONS

Feature	Detail
Model Name	artfone D6 Flip
Main Screen Size	2.4 inches
External Screen Size	1.77 inches
Operating System	Feature Phone OS
Cellular Technology	4G LTE (B1/B3/B7/B8/B20), 3G WCDMA (850/1900/2100MHz), 2G GSM (850/900/1800/1900MHz)
Wireless Carrier	Unlocked (Supports all carriers)
SIM Card Type	Dual Nano SIM
Battery Capacity	1000mAh Lithium-ion
Talk Time	3-4 hours
Standby Time	190-200 hours
Internal Storage	32 MB
RAM	512 MB
Expandable Storage	Micro SD card up to 64GB
Connectivity	USB Type-C, 3.5mm Headphone Jack, Bluetooth
Special Features	SOS Button, Speed Dial, Large Keys, Large Font, Dual Screen, FM Radio, Alarm, Calculator, Audio/Video Player, Image Viewer
Languages Supported	19 languages (e.g., English, French, German, Spanish, Italian)
Dimensions	Information not available

Feature	Detail
Weight	Information not available
Manufacturer	Artfone
Country of Origin	China

9. WARRANTY AND SUPPORT

9.1 Manufacturer's Warranty

The artfone D6 Flip mobile phone comes with a **2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your artfone D6 Flip, please contact artfone customer support through their official website or the retailer where the product was purchased. Please have your purchase receipt and product model number (D6 Flip) ready when contacting support.

