

[Manuals.plus](#) /

› [PERFASCIN](#) /

› PERFASCIN YKR-F001 Replacement Remote Control User Manual

PERFASCIN YKR-F001

PERFASCIN YKR-F001 Replacement Remote Control User Manual

For AUX Air Conditioners

INTRODUCTION

This manual provides instructions for the PERFASCIN YKR-F001 replacement remote control, designed for use with various AUX Air Conditioner models. This remote is a direct replacement and does not require programming. Simply insert batteries to begin operation.



Figure 1: Front view of the YKR-F001 Remote Control.

SETUP: BATTERY INSTALLATION

To power your remote control, you will need to install two AAA 1.5V alkaline batteries. Ensure correct polarity during installation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA 1.5V alkaline batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note:

- Do not use rechargeable batteries, as they may not provide sufficient power for optimal operation.
- If the remote does not function, replace with brand new alkaline batteries.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.



OPERATING INSTRUCTIONS

This replacement remote control is designed to function immediately after battery installation. Point the remote directly at your AUX Air Conditioner unit's receiver.

Basic Functions:

- **Power Button ():** Press to turn the air conditioner ON or OFF.
- **Temperature Adjustment (▲ / ▼):** Use the up and down arrow buttons to increase or decrease the desired temperature.
- **Mode Button:** Cycles through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Fan Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Air Swing Button:** Activates or deactivates the automatic louver swing function.

Advanced Functions (Under Cover):

Some models feature additional functions accessible by sliding down the front cover of the remote.



Figure 3: Remote control with advanced function buttons visible.

- **HEALTH Button:** Activates or deactivates health-related functions (e.g., air purification, ionizer), if supported by your AC unit.
- **SLEEP Button:** Engages sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.
- **WATER Button:** Functionality may vary; often related to dehumidification or specific water-related features.
- **TMR/CLOCK Button:** Used for setting timers (ON/OFF) or adjusting the remote's internal clock.
- **TURBO Button:** Activates maximum cooling or heating power for rapid temperature change.

Note: Not all functions may be supported by every AUX Air Conditioner model. Refer to your air conditioner's original manual for specific feature compatibility.

COMPATIBILITY

The PERFASCIN YKR-F001 replacement remote control is compatible with the following AUX Air Conditioner models:

- YKR-F/09E
- YKR-F/001
- YKR-F/006
- YKR-F/09
- YKR-F001
- YKR-F/06
- CA2422
- CA9007
- CA12007

This list is not exhaustive. If your original remote control matches the appearance of the YKR-F001, it is likely compatible.

TROUBLESHOOTING

Problem	Solution
Remote control is not responding.	• Ensure batteries are inserted correctly with proper polarity. • Replace old batteries with new, brand-name alkaline batteries. • Check for any obstructions between the remote control and the air conditioner's receiver. • Ensure you are within the effective range of the air conditioner's infrared receiver.
Some functions do not work.	• This replacement remote may not support all functions of your original remote. • Verify if your specific AUX Air Conditioner model supports the desired function.

SPECIFICATIONS

- **Model:** YKR-F001
- **Power Source:** 2 x AAA 1.5V Alkaline Batteries (not included)
- **Material:** ABS
- **Dimensions:** Approximately 6 x 3 x 0.5 inches
- **Weight:** Approximately 2 ounces (without batteries)
- **Special Feature:** No Programming Required
- **Color:** Black *(Note: Product images may show a lighter color, but the specification states Black)*

WARRANTY AND SUPPORT

This product is provided as a replacement remote control. For any issues or support inquiries, please contact the seller directly through the platform where the purchase was made. Please provide your order details for faster assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CCY1876S>

More documents and user manuals: <https://manuals.plus/>