

BingoPaw XXL Dog Stroller

BingoPaw XXL Dog Stroller Instruction Manual

Model: XXL Dog Stroller

INTRODUCTION

Thank you for choosing the BingoPaw XXL Dog Stroller. This product is designed to provide a comfortable and secure transport solution for large dogs, especially those with mobility issues, elderly pets, or those recovering from surgery. Please read this manual carefully before assembly and use to ensure proper operation and the safety of your pet.

SAFETY INFORMATION

- **Maximum Weight Capacity:** This stroller is designed for dogs up to 65 kg (143 lbs). Do not exceed this weight limit.
- **Pet Size:** Ensure your pet's body length is less than 68 cm (26.8 inches) for comfortable movement within the stroller.
- **Secure Your Pet:** Always use the internal safety harness to secure your pet inside the stroller to prevent them from jumping out.
- **Supervision:** Never leave your pet unattended in the stroller.
- **Brakes:** Engage the wheel brakes when the stroller is stationary.
- **Assembly:** Ensure all parts are correctly assembled and locked into place before use.
- **Folding:** The stroller requires disassembly for folding and transport in a car. It is not designed to fold compactly while fully assembled.

PRODUCT FEATURES

- **Robust Construction:** High-strength anti-deformation tube frame and 600D Oxford fabric.
- **Spacious Interior:** Designed for large dogs, providing ample space.
- **Ventilation:** Three breathable mesh windows for airflow and visibility.
- **Adjustable Handle:** 200-degree rotating EVA handle for ergonomic pushing.
- **All-Terrain Wheels:** 360-degree rotating front wheels and shock-absorbing rear wheels for smooth navigation on various surfaces.

- **Safety Harness:** Internal harness to keep your pet secure.

PACKAGE CONTENTS

The BingoPaw XXL Dog Stroller package includes:

- 1 x XXL Dog Stroller Frame
- 1 x Stroller Cabin (Fabric part)
- 4 x Wheels (2 front, 2 rear)
- 1 x Instruction Manual

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your BingoPaw XXL Dog Stroller:

1. **Unpack Components:** Carefully remove all parts from the packaging and ensure all components listed in the "Package Contents" section are present.
2. **Attach Wheels:**
 - Insert the front wheels into their designated slots until they click securely into place.
 - Attach the rear wheels to the axle, ensuring they are firmly seated.
3. **Unfold Frame:** Carefully unfold the main stroller frame until it locks into its open position. Ensure all locking mechanisms are engaged.
4. **Attach Stroller Cabin:** Secure the fabric cabin to the frame according to the instructions provided in the included guide. This typically involves attaching clips or zippers to the frame.
5. **Adjust Handle:** Adjust the handle to your preferred height and angle by rotating it.
6. **Final Check:** Before first use, double-check all connections, wheels, and locking mechanisms to ensure they are secure.



Image: Detailed view of the BingoPaw XXL Dog Stroller, showing its assembled form and folded state for storage or transport.



Image: Diagram highlighting key features such as breathable mesh windows, safety lock, foot pedal to lock wheels, omni-directional front wheels, adjustable handle, and strong support pole.

OPERATING INSTRUCTIONS


1. **Placing Your Pet Inside:** Open one of the mesh windows or the main opening. Gently guide your pet into the stroller.
2. **Securing Your Pet:** Attach the internal safety harness to your pet's collar or harness. Ensure it is snug but not restrictive.
3. **Closing Openings:** Securely close all mesh windows and openings to prevent your pet from escaping.
4. **Engaging/Disengaging Brakes:** Use the foot pedal on the rear wheels to engage the brakes when stopping. Disengage before moving.
5. **Maneuvering:** The 360-degree rotating front wheels allow for easy steering. The adjustable handle can be set to a comfortable height for pushing.

6. **Folding for Transport:** To fold the stroller for transport or storage, you must first disassemble the cabin from the frame and then fold the frame. Refer to the assembly section for reverse steps.




Image: A woman pushing the BingoPaw XXL Dog Stroller with a husky inside, demonstrating its use in an outdoor setting.

Shock-proof Wheels



Cobbles Road



Cement Road



Speed Bump



Brick Road



Grass



Sand

Image: The shock-proof wheels of the BingoPaw XXL Dog Stroller are shown navigating different terrains, including cobblestones, cement, speed bumps, brick roads, grass, and sand.

MAINTENANCE

- **Cleaning Fabric:** The 600D Oxford fabric can be spot cleaned with a damp cloth and mild soap. Allow to air dry completely. Do not machine wash.
- **Frame Cleaning:** Wipe the metal frame with a damp cloth. Avoid abrasive cleaners.
- **Wheel Maintenance:** Regularly check wheels for debris and clear any obstructions. Lubricate axles periodically if needed for smooth operation.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use. For compact storage, disassemble and fold as instructed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller difficult to steer or push.	Wheels are dirty or obstructed. Axles need lubrication.	Clean wheels and remove any debris. Apply a small amount of lubricant to the wheel axles.
Stroller does not fold correctly.	Cabin not fully detached. Locking mechanisms not disengaged.	Ensure the fabric cabin is fully detached from the frame. Verify all frame locking mechanisms are released before attempting to fold.
Pet seems uncomfortable or anxious.	Not accustomed to the stroller. Harness too tight/loose.	Allow your pet to gradually get used to the stroller. Adjust the safety harness for a comfortable fit. Ensure adequate ventilation.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	108 cm x 75 cm x 113 cm (42.52" x 29.53" x 44.49")
Interior Pet Space (L x W x H)	83 cm x 60 cm x 68 cm (32.7" x 23.6" x 26.8")
Folded Dimensions (L x W x H)	74 cm x 107 cm x 33 cm (29.1" x 42.1" x 13")
Product Weight	12.7 kg (28 lbs)
Maximum Recommended Weight	65 kg (143 lbs)
Frame Material	High-strength anti-deformation tube, EVA
Fabric Material	600D Oxford Fabric
Wheel Material	ABS Plastic
Number of Wheels	4 (360-degree swivel front, shock-absorbing rear)
Handle	200-degree rotating EVA handle
Color	Grey



Image: Guide on how to measure your pet's length, height, and width to select the correct stroller size. It also lists example dog breeds suitable for the stroller.



SELECT
THE RIGHT
SIZE FOR
PET STROLLER


MEASURE YOUR PET

Height

Measure from
top of the head
to foot in a
sitting position

Length

Measure from nose to
where the tail begins



Width

Measure
the distance
between
back feet

WHAT TYPE IS YOUR PET?

Pet Stroller Size:

29.33IN*42.52IN*44.49IN

Please measure your pets body length before purchasing.

You can reserve 2 inches for each interior dimension to keep your pet comfortable.



Rottweiler



Doberman Pinscher



Mastiff



Akita



German Shepherd

Image: Detailed diagram of the BingoPaw XXL Dog Stroller showing overall dimensions and interior pet space dimensions.

WARRANTY AND SUPPORT

This BingoPaw XXL Dog Stroller comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact BingoPaw customer support.

Return Policy: A 30-day return policy is typically offered. Please check with your retailer for their specific return terms.

Customer Support: For any questions, concerns, or assistance with your product, please contact BingoPaw customer service through the retailer's platform or the official BingoPaw website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question