

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Manhattan](#) /

› [Manhattan T4-R 1TB Freeview Play 4K TV Recorder User Manual](#)

Manhattan T4-R 1TB

Manhattan T4-R 1TB Freeview Play 4K TV Recorder User Manual

Model: T4-R 1TB

PRODUCT OVERVIEW

The Manhattan T4-R 1TB Freeview Play 4K TV Recorder is designed to enhance your television viewing experience by integrating over 100 live Freeview channels with extensive on-demand and catch-up TV content. It allows you to record, pause, and rewind live television, providing flexibility in how you consume media. With a 1TB hard drive, you can store up to 600 hours of recordings. The device supports 4K resolution and offers seamless search capabilities across live and on-demand programming.



Image: The Manhattan T4-R 1TB Freeview Play 4K TV Recorder, a sleek black unit with a glowing blue indicator light, showcasing its compact design.

SETUP GUIDE

What's in the Box

- T4-R 1TB TV Recorder
- Power Adapter

- HDMI Cable
- Remote Control
- 2 AAA batteries (included)



Image: The complete contents of the Manhattan T4-R box, including the recorder unit, remote control, power adapter, HDMI cable, and quick start guide.

Connecting Your T4-R

1. **Connect Aerial:** Plug your TV aerial cable into the 'AERIAL IN' port on the back of the T4-R. If you wish to loop the aerial signal to another device, use the 'LOOP OUT' port.
2. **Connect to TV:** Use the supplied HDMI cable to connect the 'HDMI' port on the T4-R to an available HDMI input on your television.
3. **Connect to Network:** For on-demand services and software updates, connect the T4-R to your home network. You can do this via Wi-Fi (setup in software) or by plugging an Ethernet cable into the 'ETHERNET/USB' port.
4. **Connect Power:** Plug the power adapter into the 'DC 12V 2A POWER' port on the T4-R, then plug the adapter into a wall socket.



Image: The rear panel of the Manhattan T4-R, clearly showing the 'AERIAL IN', 'LOOP OUT', 'OPTICAL', 'HDMI', 'ETHERNET/USB', and 'DC 12V 2A POWER' ports for connection.

Initial Setup

Upon first power-on, the T4-R will guide you through the initial setup process. This typically includes:

- **Firmware Update:** The device may check for and install the latest software updates. Ensure your internet connection is active during this step.
- **Channel Scan:** The T4-R will automatically scan for available Freeview channels.
- **Network Configuration:** If using Wi-Fi, you will be prompted to select your network and enter the password.

OPERATING YOUR T4-R

Live TV and On-Demand

The T4-R seamlessly integrates live Freeview channels with a vast library of on-demand content from services like BBC iPlayer, ITVX, Channel 4, and more. Navigate between live TV and streaming apps using the remote control.



Image: The Manhattan T4-R user interface displayed on a TV screen, showing the main menu with options like TV Guide, Recordings, and a selection of top apps including BBC iPlayer, ITVX, and Channel 4.

Recording and Playback

The 1TB hard drive allows you to record up to 600 hours of television. You can record two channels simultaneously while watching a third. Use the remote control to:

- **Record:** Press the 'R' button on the remote to record the current program or schedule recordings via the TV Guide.
- **Pause/Rewind Live TV:** Press the 'Pause' or 'Rewind' buttons to control live broadcasts.
- **Access Recordings:** Navigate to the 'Recordings' section from the main menu to manage and watch your saved programs.



Image: The Manhattan T4-R's TV Guide interface, showing program listings, current time, and options for viewing or recording shows.

Remote Control Functions

The supplied remote control provides full functionality for navigating the T4-R's interface. Key buttons include:

- **Power:** Turns the unit on/off or into standby.
- **Guide:** Opens the electronic program guide.
- **Home:** Returns to the main menu.
- **Navigation (Arrow keys & OK):** Used to move through menus and select options.
- **Volume & Channel:** Adjusts TV volume and changes channels.
- **Playback Controls:** Play, Pause, Stop, Rewind, Fast Forward, Record.



Image: The Manhattan T4-R remote control, featuring a standard layout with navigation, playback, and dedicated function buttons.

MAINTENANCE

To ensure optimal performance and longevity of your Manhattan T4-R, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the exterior of the unit with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the ventilation slots on the device are not blocked. Place the T4-R in a location with adequate airflow to prevent overheating.
- **Software Updates:** The T4-R receives automatic firmware updates to improve performance and add new features. Ensure the device is connected to the internet to receive these updates.

TROUBLESHOOTING

If you encounter issues with your Manhattan T4-R, try the following troubleshooting steps:

- **No Picture/Sound:**

- Check all cable connections (HDMI, Aerial, Power) are secure.
- Ensure your TV is set to the correct HDMI input.
- Verify the T4-R is powered on (blue light visible).

- **Remote Not Responding:**

- Replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote and the T4-R.
- Try power cycling the T4-R by unplugging it from the wall for 30 seconds and plugging it back in.

- **No Channels Found:**

- Check your aerial connection and ensure it is properly connected to a working aerial.
- Perform a new channel scan through the T4-R's settings menu.

- **On-Demand Services Not Working:**

- Verify your internet connection is active and stable.
- Check network settings on the T4-R to ensure it is connected to your Wi-Fi or Ethernet.
- Restart your home router/modem.

SPECIFICATIONS

| Feature | Detail |
|-----------------------------|----------------------------|
| Model Name | T4R |
| Item Model Number | T4•R 1TB |
| Product Dimensions | 27.2 x 19.7 x 4.6 cm |
| Weight | 1.86 kg |
| Connectivity Technology | Wi-Fi, USB, Ethernet, HDMI |
| Connector Type | HDMI |
| Resolution | 4K |
| Supported Internet Services | All 4, BBC iPlayer |
| Controller Type | Remote Control |
| Batteries | 2 AAA batteries (included) |
| Manufacturer | Manhattan TV |
| Country of Origin | China |

WARRANTY AND SUPPORT

The Manhattan T4-R 1TB Freeview Play 4K TV Recorder is backed by Manhattan's 2-year warranty. For technical assistance, troubleshooting, or warranty claims, please contact Manhattan's in-house UK support. Refer to the quick start guide included in your product packaging for specific contact details or visit the official Manhattan TV website for the most up-to-date support information.

© 2024 Manhattan. All rights reserved.