

JOYBOS JOB175

JOYBOS Broom and Dustpan with Adjustable Handle (Model JOB175) User Manual

1. INTRODUCTION

Thank you for choosing the JOYBOS Broom and Dustpan with Adjustable Handle. This manual provides essential information for the proper assembly, operation, maintenance, and troubleshooting of your new cleaning tool. Please read these instructions carefully before use to ensure safe and efficient operation. This broom and dustpan set is designed for effective floor cleaning, featuring a magnetic holding design for convenient storage, an adjustable handle for ergonomic use, and a 130° swivel head for reaching difficult areas. The integrated scraper and dense bristles are engineered to efficiently collect dust, dirt, and hair.

2. PRODUCT COMPONENTS

The JOYBOS Broom and Dustpan set includes the following main components:

- Broom Head with Dense Bristles
- Adjustable Broom Handle (multiple sections)
- Dustpan with Integrated Scraper and Teeth
- Adjustable Dustpan Handle (multiple sections)

3. SETUP AND ASSEMBLY

Follow these steps to assemble your JOYBOS Broom and Dustpan:

1. **Assemble the Broom Handle:** Connect the sections of the broom handle by twisting them clockwise until secure. Attach the assembled handle to the broom head by screwing it in firmly.
2. **Assemble the Dustpan Handle:** Similarly, connect the sections of the dustpan handle and attach it to the dustpan base.
3. **Adjust Handle Length:** The handles are retractable. To adjust the length, twist the handle sections counter-clockwise to loosen, extend or retract to your desired height, then twist clockwise to secure. Ensure the handle is at a comfortable height for sweeping to prevent strain.
4. **Magnetic Storage:** The broom and dustpan handles feature a magnetic holding design. Once

assembled, the broom and dustpan can be magnetically attached for upright, compact storage. Ensure the broom handle is at its lowest position for optimal magnetic connection.



Figure 3.1: Assembled broom and dustpan with dimensions.



Figure 3.2: Detail of the magnetic holding design for secure storage.

4. OPERATING INSTRUCTIONS

Utilize the features of your JOYBOS cleaning set for efficient cleaning:

- **Sweeping:** Hold the broom handle firmly and sweep debris towards the dustpan. The dense bristles are designed to capture fine dust and larger particles effectively.
- **Dustpan Use:** Position the dustpan flat against the floor. The rubber lip on the dustpan ensures a tight seal with the floor, preventing debris from escaping underneath. Sweep collected debris into the dustpan.
- **Hair Removal:** After sweeping, use the elongated hanging teeth (scraper) on the dustpan to comb hair and fibers from the broom bristles. This feature allows for hands-free cleaning of the broom.



Figure 4.1: Broom and dustpan in use, demonstrating the integrated scraper for hair removal.

- **130° Swivel Head:** The broom head features a 130° swivel mechanism, allowing it to rotate and reach under furniture, beds, and other hard-to-access areas without requiring you to bend or move heavy objects.



Figure 4.2: The broom's 130° swivel head allows for easy cleaning under furniture.

5. MAINTENANCE

Regular maintenance will extend the life and effectiveness of your JOYBOS cleaning set:

- **Cleaning Bristles:** After each use, remove any tangled hair or debris from the broom bristles using the dustpan's scraper teeth. For deeper cleaning, rinse the broom head under running water and allow it to air dry completely before storage.
- **Cleaning Dustpan:** Empty the dustpan after each use. Wipe the dustpan with a damp cloth to remove any residue.
- **Storage:** Store the broom and dustpan upright, magnetically attached, in a dry place away from direct sunlight and extreme temperatures. This compact storage method helps maintain the shape of the bristles and saves space.



Figure 5.1: Proper storage of the broom and dustpan using the magnetic holding feature.

6. TROUBLESHOOTING

If you encounter issues with your JOYBOS Broom and Dustpan, consider the following:

- **Broom not picking up debris effectively:**
 - Check if bristles are clean and free of tangled hair or large debris.
 - Ensure the broom head is making full contact with the floor.
- **Dustpan not collecting all debris:**
 - Verify the dustpan's rubber lip is flush with the floor. Adjust your angle if necessary.
 - Ensure the dustpan is empty before use.
- **Difficulty with magnetic storage:**
 - Ensure both handles are fully retracted to their shortest length for the magnets to align properly.
 - Check for any obstructions between the magnetic points.

7. SPECIFICATIONS

Brand	JOYBOS
Model Name	JOB175
Color	White
Recommended Uses	Floor Cleaning
Surface Recommendation	Hard ground
Bristle Material	Plastic
Handle Material	Plastic or Aluminum
Special Feature	Magnetic holding design, elongated hanging teeth and dense bristles, 130° Swivel Head
Included Components	Dustpan
Product Dimensions	8.66 x 40.16 x 3.94 inches
Item Weight	2.2 pounds
Batteries Required	No

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact JOYBOS customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the official JOYBOS store online or contact their support channels.