

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GEORGE KOVACS](#) /

› [GEORGE KOVACS P4326-66A LED Task Table Lamp User Manual](#)

GEORGE KOVACS P4326-66A

GEORGE KOVACS P4326-66A LED Task Table Lamp User Manual

Model: P4326-66A

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembling and operating this product. Failure to do so may result in electric shock, fire, or other injuries.

- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- This product is intended for indoor use only. Do not expose to water or moisture.
- Do not attempt to modify the lamp or its components. Any modifications may void the warranty and create safety hazards.
- Handle the lamp with care to avoid damage to the LED module or electrical components.
- Keep away from flammable materials.
- Please check your local laws and electrical codes before purchasing and installing this product.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with assembly.

- LED Task Table Lamp (Base, Arm, Shade with integrated LED module)
- Mounting Hardware (if applicable for specific installation, though typically freestanding)
- Instruction Manual





Figure 2.1: Fully assembled GEORGE KOVACS P4326-66A LED Task Table Lamp.

3. SETUP AND ASSEMBLY

The GEORGE KOVACS P4326-66A LED Task Table Lamp is designed for freestanding use and requires minimal assembly.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Retain packaging for future transport or storage.
- 2. Position the Lamp:** Place the lamp base on a stable, flat surface. Ensure the power cord can reach a suitable electrical outlet without tension.

3. **Adjust Lamp Arm:** The lamp features an adjustable arm and head. Gently pivot the arm and head to your desired position. Avoid excessive force to prevent damage to the joints.
4. **Connect Power:** Insert the power plug into a standard 120V AC electrical outlet.



Figure 3.1: Lamp base with integrated toggle switch.

4. OPERATING INSTRUCTIONS

The lamp is operated via a toggle switch located on the base.

1. **Turning On/Off:** Press the toggle switch once to turn the lamp on. Press it again to turn the lamp off.
2. **Dimming Function:** This lamp features a dimmable LED module. To adjust brightness, press and hold the toggle switch. The light will cycle through its dimming range. Release the switch at your desired brightness level.
3. **Adjusting Light Direction:** The lamp head and arm are designed to be adjustable. Gently move the lamp head and arm to direct light as needed for your task.



Figure 4.1: Close-up of the LED light source in the lamp head.

5. MAINTENANCE

Regular cleaning will help maintain the appearance and performance of your lamp.

- **Cleaning:** Ensure the lamp is unplugged and cool before cleaning. Wipe the lamp surfaces with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **LED Module:** The LED module (Z05) is integrated and not designed for user replacement. If the LED module fails, please contact customer support.

6. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet.	Check if the outlet is functional by plugging in another device. Check circuit breaker.
Lamp does not turn on.	Power cord not fully plugged in.	Ensure the power cord is securely plugged into the outlet.

Problem	Possible Cause	Solution
Light flickers or is inconsistent.	Loose connection or power fluctuation.	Ensure the power cord is secure. Try plugging into a different outlet. If problem persists, contact support.
Dimming function not working.	Incorrect operation.	Ensure you are pressing and holding the toggle switch to activate dimming.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	P4326-66A
Dimensions (H x W x D)	18.75 in x 6.25 in x 22 in (approximate, depth varies with adjustment)
Item Weight	6.9 lbs
Light Source	Integrated LED Module (Z05)
Wattage	8 Watts (Total)
Lumens	662 Lumens
Color Temperature	3000K
Color Rendering Index (CRI)	82
Voltage	120 Volts
Switch Type	Toggle (with dimming function)
Material	Alloy Steel, Aluminum, Brass
Finish	Coal Black
Indoor/Outdoor Use	Indoor Only
Certification	ETL Certified, ADA Compliant
Assembly Required	Yes (minimal)

8. WARRANTY AND SUPPORT

This GEORGE KOVACS P4326-66A LED Task Table Lamp comes with a one-year limited warranty from the date of purchase.

The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or improper installation.

For warranty claims, technical support, or replacement parts, please contact GEORGE KOVACS customer service. Please have your model number (P4326-66A) and proof of purchase available when contacting support.

For more information, visit the official GEORGE KOVACS website or refer to your purchase documentation.