

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BOOMJOY](#) /

> [BOOMJOY Self-Wringing Twist Mop Instruction Manual \(Model: B0CD11PXKJ\)](#)

BOOMJOY B0CD11PXKJ

BOOMJOY Self-Wringing Twist Mop Instruction Manual

Brand: BOOMJOY | Model: B0CD11PXKJ

1. INTRODUCTION

The BOOMJOY Self-Wringing Twist Mop is designed for efficient and effortless floor cleaning. Its innovative self-wringing mechanism allows for easy removal of excess water without direct hand contact, ensuring a cleaner and more hygienic experience. The mop features a premium microfiber head for superior absorbency and a non-scratch scrub pad for tackling stubborn stains.



Figure 1: BOOMJOY Self-Wringing Twist Mop.

Key Features:

- **Effortless Cleaning:** Innovative self-wringing design for easy water removal.
- **Premium Microfiber Mop Head:** Tightly woven strands for superior absorbency.
- **Non-Scratch Scrub Pad:** Effectively removes stubborn stains while protecting floor surfaces.
- **Easy Installation & Storage:** Threaded swivel connections for assembly and a hanging design for compact storage.
- **Versatile Use:** Suitable for various floor types including wooden, hardwood, tiles, laminate, vinyl, and marble.

2. SETUP AND ASSEMBLY

The BOOMJOY Self-Wringing Twist Mop comes with a 52-inch long handle composed of multiple threaded sections and a microfiber mop head. Follow these steps for assembly:

1. Unpack all components: mop head, handle sections, and any included accessories.
2. Connect the handle sections by twisting them clockwise until securely fastened. Ensure all threaded connections are tight to prevent wobbling during use.
3. Attach the microfiber mop head to the assembled handle by twisting it clockwise onto the threaded base. Ensure it is firmly attached.

Your browser does not support the video tag.

Video 1: Step-by-step guide on how to install the BOOMJOY Twist Mop handle and head.

Your browser does not support the video tag.

Video 2: Visual instructions for assembling the mop components.

Your browser does not support the video tag.

Video 3: Demonstrating the easy installation and use of the mop.

3. OPERATING INSTRUCTIONS

Using your BOOMJOY Self-Wringing Twist Mop is straightforward. Follow these steps for effective cleaning:

1. **Prepare the Mop:** Submerge the microfiber mop head into a bucket of water or cleaning solution. Allow the microfiber strands to fully absorb the liquid.
2. **Wring Out Excess Water:** To wring the mop, lift the handle upwards. The mop head will twist, squeezing out excess water. You can control the dampness by adjusting how much you twist and how many times you repeat the action.
3. **Mop the Floor:** Once the mop head is at your desired dampness, place it on the floor and begin mopping. The microfiber material is effective on various surfaces including hardwood, tile, laminate, and vinyl.
4. **Use the Scrub Pad:** For stubborn spots, utilize the integrated non-scratch scrub pad located on the mop head. Apply gentle pressure to remove grime without damaging your floor.

USAGE INSTRUCTION



Figure 2: Visual guide for the self-wringing mechanism.

Your browser does not support the video tag.

Video 4: Demonstration of the self-wringing action and general mop usage.

4. MAINTENANCE

Proper maintenance ensures the longevity and effectiveness of your BOOMJOY mop:

- **Cleaning the Mop Head:** The microfiber mop head is washable. After each use, rinse the mop head thoroughly to remove dirt and debris. For deeper cleaning, the mop head can be detached and machine washed with similar colors. Avoid using bleach or fabric softeners.
- **Drying:** After cleaning, wring out as much water as possible. Hang the mop to air dry completely to prevent mildew and odors. The handle includes a hook for convenient hanging storage.
- **Storage:** Store the mop in a dry place. The modular handle design allows for disassembly for compact storage if needed.

EASY TO STORAGE



Figure 3: Mop designed for easy hanging storage.

5. TROUBLESHOOTING

If you encounter any issues with your BOOMJOY Self-Wringing Twist Mop, please refer to the following common solutions:

- **Mop head not wringing effectively:** Ensure the handle sections are securely tightened. The twisting mechanism relies on a firm connection. Also, check that the mop head is properly attached to the base.
- **Mop head detaches during use:** Verify that the mop head is fully screwed onto the handle's base. If it continues to detach, inspect the threading for any damage.
- **Mop leaves streaks:** Ensure the mop head is clean and not oversaturated with water. Wring out more liquid before mopping. For best results, use clean water or a diluted cleaning solution.

6. SPECIFICATIONS

Feature	Detail
Brand	BOOMJOY

Model Number	B0CD11PXKJ
Handle Material	Plastic or Aluminum
Head Material	Microfiber
Number of Items	1
Product Dimensions	15.7"L x 4.9"W x 4.5"H
Item Weight	1.96 pounds (0.89 Kilograms)
Assembly Required	Yes
Number of Pieces	5
Batteries Required	No
Surface Recommendation	Floor (Wooden, Hardwood, Tiles, Laminate, Vinyl, Marble)

7. WARRANTY AND SUPPORT

Your BOOMJOY Self-Wringing Twist Mop comes with a warranty. Please register your product within 14 days of purchase to activate your 180-day warranty. For any product-related inquiries, support, or warranty claims, please contact BOOMJOY customer service through the official channels provided with your purchase or on the BOOMJOY brand store.

Note: Specific contact details may vary. Refer to your product packaging or the BOOMJOY official website for the most current support information.