

HOMPANY Rollerbürste

HOMPANY SmartVac 11 2-in-1 Roller Brush Instruction Manual

Brand: HOMPANY | Model: Rollerbürste

1. PRODUCT OVERVIEW

This manual provides detailed instructions for the HOMPANY 2-in-1 Roller Brush, an essential accessory designed specifically for the HOMPANY SmartVac 11 vacuum cleaner. This roller brush combines two types of bristles to effectively clean various floor surfaces, ensuring optimal performance of your SmartVac 11.



Image 1: The HOMPANY 2-in-1 Roller Brush, featuring a combination of red and black bristles for versatile cleaning.

Regular replacement of the roller brush is crucial for maintaining the cleaning efficiency and suction power of your vacuum cleaner. This accessory is designed for easy installation and long-lasting performance.

2. SETUP AND INSTALLATION

Follow these steps to safely install or replace the 2-in-1 Roller Brush in your HOMPANY SmartVac 11 vacuum cleaner.



Image 2: Example of a vacuum cleaner head's brush compartment, similar to the SmartVac 11, where the roller brush is installed.

- 1. Safety First:** Before beginning any installation or maintenance, ensure your HOMPANY SmartVac 11 vacuum cleaner is turned OFF and unplugged from the power outlet. This prevents accidental activation and potential injury.
- 2. Access the Brush Compartment:** Locate the brush roll compartment on the underside of your SmartVac 11 vacuum cleaner's floor head. Refer to your SmartVac 11's main user manual for specific instructions on how to open this compartment. Typically, there will be latches or screws that need to be released.
- 3. Remove Old Brush (if applicable):** Carefully lift out the old roller brush from its housing. Note its orientation to assist with the installation of the new brush. Dispose of the old brush responsibly.
- 4. Clean Compartment:** While the compartment is open, take the opportunity to remove any accumulated hair, debris, or dust from the brush housing and end caps. This ensures the new brush operates smoothly.
- 5. Install New Roller Brush:** Align the ends of the new HOMPANY 2-in-1 Roller Brush with the corresponding slots or gears in the vacuum cleaner's floor head. Gently press it into place until it clicks securely. Ensure it rotates freely by hand.
- 6. Close Compartment:** Securely close the brush roll compartment cover, ensuring all latches or screws are fastened.
- 7. Test:** Plug in and turn on your SmartVac 11 to confirm the new roller brush spins correctly and the vacuum operates as expected.

3. OPERATING INSTRUCTIONS

The HOMPANY 2-in-1 Roller Brush is designed to work seamlessly with your SmartVac 11. Once installed, no special operating procedures are required for the brush itself. Simply use your SmartVac 11 as you normally would.

- **Optimal Performance:** The combination of soft and stiff bristles allows for effective cleaning on both hard floors and carpets.
- **Regular Checks:** Periodically check the roller brush during vacuuming for any large debris or tangled hair that might impede its rotation.

4. MAINTENANCE

Regular maintenance of your HOMPANY 2-in-1 Roller Brush will extend its lifespan and ensure your SmartVac 11 maintains optimal cleaning performance.

1. **Frequency:** It is recommended to inspect and clean the roller brush at least once a month, or more frequently if you have pets or long hair in your household.
2. **Removal:** Turn off and unplug the vacuum. Remove the roller brush as described in the "Setup and Installation" section.
3. **Cleaning Hair and Debris:** Use scissors or a brush cleaning tool (often supplied with vacuum cleaners) to carefully cut and remove any tangled hair, threads, or fibers wrapped around the brush bristles and ends. Be careful not to damage the bristles.
4. **Washing (Optional):** If the brush is heavily soiled, it can be gently rinsed under lukewarm water. **Do not use harsh detergents.** Ensure the brush is completely dry before re-installing it into the vacuum cleaner. Allow at least 24 hours for air drying in a well-ventilated area.
5. **Check for Wear:** Inspect the bristles for signs of wear, such as flattening or excessive fraying. If bristles are significantly worn, it may be time for a replacement.
6. **Re-installation:** Once clean and dry, re-install the roller brush following the steps in the "Setup and Installation" section.

5. TROUBLESHOOTING

If you encounter issues with your HOMPANY 2-in-1 Roller Brush, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Brush not spinning or spinning slowly.	<ul style="list-style-type: none">• Hair or debris tangled around the brush.• Brush compartment not closed properly.• Brush motor issue (less likely for accessory).	<ul style="list-style-type: none">• Turn off and unplug the vacuum. Remove the brush and clean thoroughly.• Ensure the brush compartment is securely latched.• If the issue persists after cleaning and re-installation, consult the SmartVac 11 main manual or HOMPANY customer support.
Reduced cleaning performance.	<ul style="list-style-type: none">• Worn-out bristles.• Brush is dirty or clogged.• Other vacuum issues (e.g., clogged filter, full dustbin).	<ul style="list-style-type: none">• Inspect the bristles for wear. Replace the brush if necessary.• Clean the brush as per maintenance instructions.• Check other components of your SmartVac 11 (filter, dustbin) as per its main manual.

Problem	Possible Cause	Solution
Unusual noise from the brush area.	<ul style="list-style-type: none"> Debris lodged in the brush mechanism. Improper installation. 	<ul style="list-style-type: none"> Turn off and unplug. Remove the brush and inspect for any foreign objects. Re-install the brush, ensuring it is seated correctly.

6. SPECIFICATIONS

Key specifications for the HOMPANY 2-in-1 Roller Brush:

Feature	Detail
Brand	HOMPANY
Model Number	Rollerbürste
Compatibility	HOMPANY SmartVac 11 Vacuum Cleaner
Color	Black and Red
Dimensions (Package)	23.5 x 9.2 x 6.9 cm
Item Weight	100 grams

7. WARRANTY AND SUPPORT

Specific warranty information for this accessory is not provided in this document. For details regarding warranty coverage, technical support, or to purchase replacement parts, please refer to the official HOMPANY website or contact HOMPANY customer service directly.

It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.

For general inquiries or further assistance with your SmartVac 11 vacuum cleaner, please consult its main user manual or visit the manufacturer's support page.

© 2023 HOMPANY. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

 <p>HOMPANY Quick Start Guide</p> <p>SmartVac 13 Cordless Vacuum Cleaner</p> <p>Hompany SmartVac 13 Cordless Vacuum Cleaner Quick Start Guide</p>	<p><u>Hompany SmartVac 13 Cordless Vacuum Cleaner Quick Start Guide</u></p> <p>A quick start guide for the Hompany SmartVac 13 cordless vacuum cleaner, covering installation, operation, charging, dust cup maintenance, and cleaning. Includes important safety precautions.</p>
 <p>HOMPANY CORDLESS VACUUM CLEANER USER MANUAL</p> <p>SmartVac 11</p>	<p><u>HOMPANY SmartVac 11 Cordless Vacuum Cleaner User Manual</u></p> <p>Comprehensive user manual for the HOMPANY SmartVac 11 cordless vacuum cleaner, covering setup, operation, maintenance, and specifications.</p>
 <p>HOMPANY CORDLESS VACUUM CLEANER USER MANUAL</p> <p>SmartVac 11</p>	<p><u>HOMPANY SmartVac 11 Cordless Vacuum Cleaner User Manual</u></p> <p>This user manual provides comprehensive instructions for operating, maintaining, and troubleshooting the HOMPANY SmartVac 11 cordless vacuum cleaner. It includes safety warnings, package contents, assembly guides, usage tips, charging methods, and warranty information.</p>
 <p>HOMPANY CORDLESS VACUUM CLEANER USER MANUAL</p> <p>SmartVac 11</p>	<p><u>Hompany SmartVac 11 Cordless Vacuum Cleaner User Manual</u></p> <p>User manual for the Hompany SmartVac 11 cordless vacuum cleaner, providing instructions on usage, maintenance, troubleshooting, and warranty information.</p>