

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [JadeAudio](#) /

> [JadeAudio JW1 Open Ear Headphones Bluetooth 5.3 Wireless Headphones with Mic with HiFi Sound, 18hrs Playtime Sport Earbuds for Running \(Black\)](#)

JadeAudio JW1

JadeAudio JW1 Open Ear Headphones User Manual

Model: JW1

INTRODUCTION

Welcome to your new JadeAudio JW1 Open Ear Headphones. These headphones are designed for comfort, versatility, and high-quality audio, perfect for active lifestyles and everyday use. This manual will guide you through the setup, operation, and maintenance of your JW1 headphones.



The JadeAudio JW1 Open Ear Headphones and their compact charging case.

KEY FEATURES

- **Open, Non-In-Ear Design:** Comfortable for long periods of wear without discomfort, allowing you to stay aware of your surroundings.
- **All-Around Versatility:** Suitable for outdoor exercise, work, studies, leisure, and entertainment.
- **Bluetooth 5.3 Connectivity:** Ensures faster, more stable connections with greater efficiency for seamless audio.
- **Convenient Touch Controls:** One-handed control for music playback, calls, and voice assistant.
- **Water and Sweat-Resistant (IPX5):** No worries about water and sweat, even during intense activities.

Official product video showcasing the JadeAudio JW1 Open Ear Headphones.

WHAT'S IN THE BOX

Your JadeAudio JW1 package includes the following items:

- JW1 Open Ear Headphones (Left and Right)

- Charging Case
- USB Charging Cable



14.2mm

ダイナミックドライバー搭載
オープンイヤーでも、
力強く自然な低音を実現

イヤホン本体は
1回の充電で最長6時間再生
充電ケースと合わせると、
最大18時間再生可能



The JW1 headphones neatly stored within their charging case.

SETUP

Charging the Headphones

Before first use, fully charge your JW1 headphones and charging case.

1. Place the headphones into their respective slots in the charging case.
2. Connect the USB charging cable to the charging port on the case and to a compatible USB power source.
3. The indicator light on the case will show the charging status. A full charge for the case takes approximately 6 hours. The headphones will charge automatically when placed in the case.

便利なタッチ操作

左右両方のイヤホンユニットにタッチ・コントロール搭載
音楽再生/音声通話/音声アシスタントを片手で操作可能



ダブルタップ：再生/一時停止/応答/通話終了
トリプルタップ：左/1曲戻る、右/1曲進む
4回タップ：音声アシスタントを起動
5秒長押し：電源オン

The JW1 charging case, ready for connection to a power source.

Pairing with a Device

The JW1 headphones utilize advanced Bluetooth 5.3 technology for fast and stable connections.

1. Ensure the headphones are charged and removed from the charging case. They will automatically enter pairing mode, indicated by a flashing light.
2. On your device (smartphone, tablet, laptop, etc.), go to the Bluetooth settings menu and turn Bluetooth on.
3. Search for "JW1" in the list of available devices and select it to connect.
4. Once successfully connected, you will hear an audio prompt, and the indicator light on the headphones will change to a steady light or turn off, depending on the model.

忘れるほど、軽い

イヤホンの重量は片耳わずか9.5g。
長時間着けていても、疲れにくく快適です



Diagram illustrating the Bluetooth 5.3 connectivity of the JW1 headphones.

OPERATING YOUR JW1 HEADPHONES

Wearing the Headphones

The JW1 features an open-ear, non-in-ear design for maximum comfort and situational awareness.

1. Gently place the ear hook over the top of your ear.
2. Position the speaker unit so it rests comfortably near your ear canal, without entering it.
3. Adjust the headphones for a secure and comfortable fit. The ergonomic design ensures stability even during active movement.

計算された着け心地

JW1は、人間工学に配慮して設計されています
耳にかかる力を丁寧に調整したイヤーフックデザインは、
さまざまな形状の耳にしっかりとフィットし、
アクティブに動くシーンでも落ちにくく快適です



Visual guide for correctly wearing the JW1 Open Ear Headphones.

Touch Controls

Both the left and right earbud units are equipped with touch controls for convenient operation. Refer to the table below for specific functions:

Action	Control
Play/Pause/Answer/End Call	Double tap
Previous Track	Triple tap left earbud
Next Track	Triple tap right earbud
Wake Voice Assistant	Four taps
Power On	Long press 5 seconds

Bluetooth 5.3 対応

より高速で安定した接続を実現するBluetooth5.3に対応
ゲームや動画再生時もスムーズです



Illustration of the touch control area on the JW1 headphones.

MAINTENANCE AND CARE

Water and Sweat Resistance

The JW1 headphones are designed with IPX5 water and sweat resistance, making them ideal for active use. To ensure longevity:

- After intense workouts or exposure to water, always wipe the headphones dry with a soft, clean cloth.
- Ensure the charging contacts on both the headphones and the case are completely dry before placing the headphones back into the charging case. Moisture on contacts can cause damage.
- Note: The sound tube, ventilation holes, microphone, and the charging case itself are not IPX5 rated and should be protected from direct water exposure.

IPX5の防水性能

雨の中でも、ジムで汗を流すときでも
問題なく使える、高い防水性能を実現しました。



*イヤホンに水や汗が付着した場合は、充電ケースに入れる前に充電接点を乾かしてください。
*イヤホンのサウンドチューブ、通気孔、マイクホール、充電ケースはIPX5防水には対応していません。

The JW1 headphones are designed to withstand splashes and sweat.

Cleaning

Use a dry, soft, lint-free cloth to clean the headphones and charging case. Avoid using abrasive materials, solvents, or harsh chemicals, as these may damage the product's finish or internal components.

TROUBLESHOOTING

If you encounter any issues with your JW1 headphones, please refer to the following common problems and solutions:

Issue	Possible Cause	Solution
No Sound	Headphones not connected; Low battery; Device volume too low	Ensure headphones are paired; Charge headphones; Increase volume on device and headphones

Issue	Possible Cause	Solution
Cannot Pair	Headphones out of range; Already connected to another device; Pairing mode not active	Move device closer; Disconnect from other devices; Place headphones in case then remove to re-enter pairing mode
Intermittent Connection	Bluetooth interference; Device too far; Obstructions between device and headphones	Move away from other wireless devices; Reduce distance to device; Ensure clear line of sight
Touch Controls Unresponsive	Dirty sensor; Software glitch	Clean the touch sensor area; Place headphones in case and remove to restart them
Charging Issue	Dirty charging contacts; Faulty charging cable or adapter	Clean charging contacts with a dry cotton swab; Try a different USB cable and power adapter

SPECIFICATIONS

Feature	Detail
Model Name	JW1
Brand	JadeAudio
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	Open Ear
Form Factor	Open Ear
Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Battery Life (Headphones)	Up to 6 Hours per charge
Total Playtime (with Case)	Up to 18 Hours
Charging Time (Case)	Approx. 6 Hours
Water Resistance Level	Water Resistant (IPX5)
Control Method	Touch
Material	Silicone or TPE (Thermoplastic Elastomer)
Item Weight	7.4 ounces
Package Dimensions	6.81 x 5.2 x 1.97 inches
Manufacturer	JadeAudio
Country of Origin	China

WARRANTY AND SUPPORT

For detailed warranty information, technical support, or service inquiries regarding your JadeAudio JW1 Open Ear Headphones, please refer to the warranty card or documentation included with your purchase. You may also visit the official JadeAudio website for the most up-to-date support resources and contact information.