

[manuals.plus](#) /› [Luyiilo](#) /› **Luyiilo Smart Watch for Kids, Model X32 Instruction Manual**

Luyiilo X32

Luyiilo Smart Watch for Kids - Model X32 Instruction Manual

Brand: Luyiilo | Model: X32

1. INTRODUCTION

Welcome to the Luyiilo Smart Watch for Kids, Model X32. This device is designed to provide engaging entertainment and educational features for children aged 4-12. It includes a touch screen, HD camera, 26 puzzle games, an alarm clock, and various other functions to support learning and fun. Please read this manual thoroughly to ensure proper use and maintenance of the watch.



Figure 1.1: Luyiilo Smart Watch for Kids, Model X32

2. PRODUCT OVERVIEW

2.1 Key Features

- **Durable Design:** Equipped with two high-strength toughened films to protect the screen from accidental falls and collisions. The strap is made of high-quality, skin-friendly silicone that is waterproof and resistant to deformation.
- **Educational Functions:** Includes 13 educational functions and 26 different puzzle games designed to develop brain and logic skills for children aged 3-6 years.
- **HD Camera & Video Recording:** Features a 300,000-pixel camera for capturing photos and videos. An 8GB SD card is included, capable of storing up to 10,000 photos or over 6 hours of video.
- **Long-lasting Battery:** A rechargeable 400mAh battery provides 7-14 days of standby time.
- **Multi-functional:** Includes time tools, torch (flashlight), music player, recorder, calculator, calendar, pedometer, and more.

2.2 What's in the Box

- Luyiilo Kids Smart Watch (1 unit, includes SD Card)
- USB-Type C Cable (1 unit)
- Touch Screen Glass Protector (2 units)
- Instructions Manual (1 unit)



Figure 2.1: Package Contents

3. SETUP

3.1 Charging the Watch

Before first use, fully charge the Luyiilo Smart Watch. Connect the provided USB-Type C cable to the charging port on the side of the watch and plug the other end into a compatible USB power adapter (not included). The watch screen will indicate charging status. A full charge typically takes approximately 2 hours.

3.2 Screen Protector Installation

To enhance screen durability, install one of the provided screen protectors. Carefully clean the watch screen with a soft cloth. Peel off the protective film from the screen protector, align it with the watch screen, and gently press it down to remove any air bubbles.

Watch Screen Glass Protector



Figure 3.1: Screen Protector Application

3.3 Power On/Off

- **To Power On:** Press and hold the Power button (located on the side of the watch) until the screen illuminates.
- **To Power Off:** Press and hold the Power button until the power-off option appears on the screen, then select 'Power Off'.

4. OPERATING INSTRUCTIONS

4.1 Navigation

The Luyiilo Smart Watch features a responsive touch screen for easy navigation. Swipe left or right to browse through different applications and functions. Tap an icon to open an application. Use the physical buttons on the side for quick access to specific features or to return to the previous screen.

Detail for Watch



Figure 4.1: Watch Details and Controls

4.2 Changing Watch Faces

The watch offers multiple interesting wallpapers and watch faces. From the home screen, swipe up or down, or tap and hold the screen to access the watch face selection menu. Choose from various analog and digital designs to personalize the watch's appearance.

4.3 Camera & Video Recording

Access the camera application from the main menu. The 300,000-pixel camera allows children to capture photos and record videos. Tap the camera icon to take a photo or the video icon to start/stop recording. All media is saved to the included 8GB SD card.

HD Camera and Video



Figure 4.2: HD Camera Feature

4.4 Music Player

The watch includes a music player. You can upload MP3 files to the watch's SD card via the USB-Type C cable. Access the 'Music' application to play, pause, skip tracks, and adjust volume.

4.5 Games

The Luyiilo Smart Watch comes with 26 built-in puzzle games and 13 educational functions. These games are designed to be engaging and help develop logic, concentration, and judgment skills. Access the 'Games' application from the main menu to select a game.

26 Educational Games



Figure 4.3: Educational Games

4.6 Time Tools

The 'Time Tools' application includes an alarm clock, stopwatch, and timer. Set alarms for daily routines, use the stopwatch for timing activities, or set a timer for specific durations.

4.7 Pedometer

The built-in pedometer tracks daily steps, encouraging physical activity. Access the 'Pedometer' application to view step counts.

4.8 Flashlight

The watch includes a small flashlight function. Activate it from the 'Torch' application for convenience in low-light conditions.

4.9 Parental Controls

The Luyiilo Smart Watch includes parental control options to manage usage and ensure appropriate content access. Refer to the detailed instruction manual for specific settings and configurations.

Your browser does not support the video tag.

Video 4.1: Overview of Smart Game Watch for Kids features, including navigation and various applications.

5. MAINTENANCE

5.1 Cleaning

To clean the watch, wipe it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the screen or casing.

5.2 Battery Care

To prolong battery life, avoid extreme temperatures. Charge the watch regularly, even if not in use, to prevent deep discharge. Do not leave the watch uncharged for extended periods.

5.3 Water Resistance

The silicone strap is waterproof, but the watch dial itself is not fully waterproof. Avoid submerging the watch in water, such as during swimming or showering, to prevent damage.

6. TROUBLESHOOTING

6.1 Watch Not Turning On

- Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to attempt a forced restart.

6.2 Screen Unresponsive

- Restart the watch by holding the Power button.
- Ensure the screen is clean and dry.

6.3 Short Battery Life

- Reduce screen brightness.
- Close unused applications running in the background.
- Limit continuous video recording or game playing.

7. SPECIFICATIONS

- **Model Number:** X32
- **Product Dimensions:** 2.3 x 0.7 x 9.8 inches
- **Item Weight:** 3.21 ounces
- **Manufacturer Recommended Age:** 36 months - 12 years
- **Battery:** 400mAh rechargeable
- **Camera:** 300,000 pixels
- **Storage:** 8GB SD card (included)
- **Screen:** LCD Touch Screen with toughened film protection



Figure 7.1: Product Dimensions

8. SAFETY INFORMATION

- This product is intended for children aged 36 months to 12 years. Adult supervision is recommended during use.
- Do not attempt to disassemble or modify the watch. This may cause damage or injury.
- Keep the watch away from extreme heat sources and direct sunlight.
- Dispose of the battery and electronic components responsibly according to local regulations.

9. WARRANTY AND SUPPORT

Specific warranty details and customer support contact information are not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for the most up-to-date warranty and support information.

| | |
|---|--|
|  <p>Quick Start Guide EN ES FR DE PT IT</p> <p>X32 40 Inputs, 20 Bus Digital Mixing Console with 32 Programmable Midas Preamps, 24 Multifunction Faders, 128 LCDs, 32 Channel Audio Interface and 10" Touch Screen</p> <p>Behringer</p> | <p>Behringer X32 Digital Mixing Console Quick Start Guide</p> <p>Get started quickly with the Behringer X32 digital mixing console. This guide provides an overview of basic operations, features, and setup for the X32, including its 40 inputs, 32 Midas preamps, and extensive connectivity for professional audio applications.</p> |
|  <p>Quick Start Guide EN ES FR DE PT IT</p> <p>WING 48 Channel, 28-Bus Full Stereo Digital Mixing Console with 24 Fader Control Surface and 10" Touch Screen</p> <p>Behringer</p> | <p>Behringer WING Quick Start Guide: 48-Channel Digital Mixing Console</p> <p>A concise guide to the Behringer WING digital mixing console, covering its features, hardware, main screens, patching, setup, safety instructions, and firmware updates. Learn about its 48 channels, 10-inch touchscreen, flexible routing, and professional audio capabilities.</p> |
|  <p>Quick Start Guide EN ES FR DE PT IT</p> <p>WING 48 Channel, 28-Bus Full Stereo Digital Mixing Console with 24 Fader Control Surface and 10" Touch Screen</p> <p>Behringer</p> | <p>Behringer WING Digital Mixing Console Quick Start Guide</p> <p>A quick start guide for the Behringer WING 48-Channel, 28-Bus Full Stereo Digital Mixing Console with 24-Fader Control Surface and 10" Touch Screen, covering setup, features, and specifications.</p> |
|  <p>MAG Serisi LCD Monitör MAG 274QPF X32 (DCH) MAG 274QRFW X32 (DCH) Kullanım Kılavuzu</p> | <p>MSI MAG Serisi LCD Monitör Kullanım Kılavuzu</p> <p>MSI MAG 274QPF X32 ve MAG 274QRFW X32 LCD monitörler için kapsamlı kullanım kılavuzu. Kurulum, OSD ayarları, teknik özellikler ve sorun giderme bilgileri içerir.</p> |
|  <p>Quick Start Guide EN ES FR DE PT IT</p> <p>WING 48 Channel, 28-Bus Full Stereo Digital Mixing Console with 24 Fader Control Surface and 10" Touch Screen</p> <p>Behringer</p> | <p>Behringer WING Digital Mixing Console Quick Start Guide</p> <p>A comprehensive guide to getting started with the Behringer WING, a 48-channel digital mixing console featuring a 24-fader control surface and a 10" touch screen. Learn about its features, hardware, screens, routing, and updates.</p> |
|  <p>Seria MAG Monitor LCD MAG 274QPF X32 (DCH) MAG 274QRFW X32 (DCH) Podręcznik użytkownika</p> | <p>MSI MAG 274QPF X32 / MAG 274QRFW X32 Podręcznik użytkownika</p> <p>Przewodnik po instalacji, konfiguracji i obsłudze monitorów MSI MAG 274QPF X32 oraz MAG 274QRFW X32. Zawiera informacje o funkcjach, danych technicznych i rozwiązywaniu problemów.</p> |