

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Imetec](#) /

› **Imetec Adapto Tartan Festival Heated Blanket 160x120cm User Manual**

### Imetec 26010

## Imetec Adapto Tartan Festival Heated Blanket

Model: 26010 | Size: 160x120 cm

### INTRODUCTION

This user manual provides essential information for the safe and effective use of your Imetec Adapto Tartan Festival Heated Blanket. Please read all instructions carefully before first use and retain this manual for future reference.

### IMPORTANT SAFETY WARNINGS

**Failure to follow these safety instructions may result in fire, electric shock, or injury.**

- This product heats rapidly. Avoid placing it on or near flammable materials.
- Keep out of reach of children and pets.
- Do not use if the product is damaged or wet.
- Always unplug the product when not in use.
- Do not use with a generator, inverter, or any power source other than a standard wall outlet.
- Do not use if folded, bunched, or creased. This can cause overheating.
- Do not insert pins or other sharp objects into the blanket.
- Do not dry clean. Follow washing instructions carefully.
- Regularly inspect the blanket and power cord for any signs of wear or damage.



Image: The Imetec Adapto Tartan Festival Heated Blanket, folded to show its tartan pattern and soft inner lining, with the detachable control unit visible.

## SETUP INSTRUCTIONS

- 1. Unpack:** Carefully remove the heated blanket from its packaging.
- 2. Inspect:** Before first use, visually inspect the blanket and the control unit for any signs of damage. Do not use if any damage is observed.
- 3. Connect Control Unit:** Ensure the control unit is securely plugged into the blanket's connector.
- 4. Position:** Lay the blanket flat on a bed, sofa, or other desired surface. Ensure it is not folded, bunched, or creased during use.
- 5. Plug In:** Plug the power cord into a standard 230V electrical outlet.



Image: A close-up view of the Imetec heated blanket's digital control unit, showing the power button and temperature settings.

## OPERATING INSTRUCTIONS

---

The Imetec Adapto Tartan Festival Heated Blanket features Adapto technology for personalized comfort and safety.

- 1. Power On:** Press the power button on the digital control unit to turn on the blanket. The LED display will illuminate.
- 2. Select Temperature:** Use the temperature control buttons (usually marked with numbers 1-6) to select your desired heat level. The blanket offers 6 temperature settings. The Adapto technology will automatically adjust the heat based on your body temperature and the ambient environment.
- 3. Set Timer (Automatic Shut-off):** The control unit includes an automatic shut-off timer. You can set it for 1, 3, or 9 hours. Refer to the symbols on the control unit for specific timer settings.
- 4. Power Off:** To turn off the blanket, press the power button again. Always unplug the blanket from the wall outlet when not in use.



Image: A person comfortably seated on a couch, covered by the Imetec heated blanket, holding the control unit.

## CARE AND MAINTENANCE

---

Proper care ensures the longevity and safe operation of your heated blanket.

- **Disconnect Control Unit:** Always disconnect the control unit from the blanket before cleaning.
- **Washing:** The blanket can be washed by hand or in a machine at a maximum temperature of 30 °C (86 °F). Use a mild detergent.
- **Drying:** Do not tumble dry. Air dry the blanket completely before reattaching the control unit and using it again. Ensure no moisture remains in the electrical connections.
- **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal heating elements.



Image: A person carefully placing the Imetec heated blanket into a washing machine for cleaning.

## TROUBLESHOOTING

If you encounter issues with your heated blanket, please refer to the following common solutions:

- **Blanket not heating:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify the control unit is firmly connected to the blanket.
- Check if the power button on the control unit is pressed and the LED display is active.
- Ensure the blanket is laid flat and not folded or bunched, which can trigger safety features.

- **Blanket heats unevenly:**

- Ensure the blanket is spread out evenly without any folds or creases.
- The Adapto technology adjusts heat based on environment; allow a few minutes for it to stabilize.

- **Control unit display not working:**

- Unplug the blanket from the wall, wait 1 minute, then plug it back in.
- Ensure the control unit is properly connected to the blanket.

If the problem persists after attempting these solutions, discontinue use and contact customer support.

## TECHNICAL SPECIFICATIONS

Feature	Specification
<b>Brand</b>	Imetec
<b>Model Name</b>	Imetec Adapto Tartan Festival
<b>Model Number</b>	26010
<b>Dimensions</b>	160 x 120 cm
<b>Material</b>	Polyester
<b>Color</b>	Orange/Grey (Tartan Pattern)

<b>Power</b>	150 Watts
<b>Voltage</b>	230 Volts
<b>Temperature Settings</b>	6
<b>Special Features</b>	Adapto Technology, Electro Block Safety System, Rapid Heating, Automatic Shut-off (1, 3, or 9 hours), Detachable Control, Machine Washable
<b>Item Weight</b>	1.5 Kilograms

## **WARRANTY AND SUPPORT**

---

For warranty information and customer support, please refer to the documentation included with your product or visit the official Imetec website. Keep your proof of purchase for any warranty claims.

© 2023 Imetec. All rights reserved.