Qhou KRIB-XQB201A-GREY6

Qhou KRIB-XQB201A-GREY6 Full Automatic Washing Machine User Manual

Brand: Qhou | Model: KRIB-XQB201A-GREY6

1. Introduction

Thank you for choosing the Qhou KRIB-XQB201A-GREY6 Full Automatic Washing Machine. This compact and efficient appliance is designed to simplify your laundry routine with its versatile features and user-friendly operation. It combines washing and spinning functions in one unit, making it ideal for spaces with limited room. Key features include a multi-function control panel with 10 washing programs, 4 water level modes, and 8 water level selections. The LED display provides clear information, and the automatic imbalance adjustment system ensures stable and quiet operation. For added safety, a child lock function is integrated.





Figure 1.1: Front view of the Qhou KRIB-XQB201A-GREY6 Full Automatic Washing Machine.

2. IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please read and follow all instructions carefully before using the washing machine.

- Always connect the appliance to a properly grounded outlet.
- Do not operate the washing machine if the power cord or plug is damaged.
- Keep children and pets away from the appliance during operation. Utilize the child lock function for added safety.
- Do not wash items that are soiled with flammable liquids or explosive substances.
- Ensure the water inlet and drain hoses are securely connected to prevent leaks.
- Do not open the top lid during the spin cycle to avoid injury.
- Unplug the machine from the power outlet before cleaning or performing any maintenance.



Figure 2.1: Safety Child Lock feature for preventing accidental operation.

3. PRODUCT OVERVIEW

3.1 Dimensions and Capacity

The Qhou KRIB-XQB201A-GREY6 is designed to be compact yet offers a generous capacity for your laundry needs. Its dimensions are approximately 20 inches (D) x 20 inches (W) x 34 inches (H), and it can hold up to 15.6 pounds of laundry.



Figure 3.1: Product dimensions and key specifications.



Figure 3.2: Large capacity for various clothing items.

3.2 Components

The washing machine features a durable construction with essential components for effective cleaning:

- Water Inlet: For connecting the water supply.
- Stainless Steel Inner Tub: Honeycomb design for gentle yet effective washing.
- Built-in Filter: Easily removable for lint and debris collection.
- Sturdy Washing Machine Impeller: Ensures thorough agitation of clothes.
- Fill Hose: Premium quality hose included for water connection.
- Drain Hose: Included for water drainage.



Figure 3.3: Internal and external components of the washing machine.

3.3 Control Panel

The intuitive control panel features an LED display and various buttons for program selection, water level adjustment, and other functions.

- **Programs:** 10 washing programs including Standard, Soft, Quick Wash, Heavy Duty, Soak Wash, Wash Only, Spin Only, Tub Clean, Tub Air Dry, and Wash Recycle.
- Water Level/Powder Level: Options for High (7/8), Middle (5/6), Low (3/4), and Minimum (1/2).
- Delay Start: Set a delayed start time for your wash cycle.
- Child Lock: Locks all buttons to prevent accidental changes.
- Process Display: Shows the current stage of the washing cycle.



Figure 3.4: Detailed view of the multi-function control panel.



Figure 3.5: Smart Control Panel with LED Display for easy operation.

4. SETUP

4.1 Placement

Due to its compact and lightweight design, this washing machine is highly portable and suitable for various living spaces. Choose a stable, level surface near a water source and drain. Ideal locations include:

- RVs and Campers
- Dorms
- Apartments
- Bathrooms



Figure 4.1: Applicable scenes for the portable washing machine.



Figure 4.2: Ideal for various occasions and small spaces.

4.2 Water and Drain Connection

Connect the provided fill hose to a suitable water tap and the water inlet on the back of the machine. Ensure connections are tight to prevent leaks. Position the drain hose securely into a sink, bathtub, or designated drain. The drain hose should be positioned to allow for proper gravity drainage or connected to a standpipe.

4.3 Power Connection

Plug the washing machine into a standard 110-120V/60Hz grounded electrical outlet. Ensure the power cord is not pinched or damaged.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. Load Laundry: Open the top lid and place clothes evenly inside the stainless steel inner tub. Do not overload

the machine beyond its 15.6 lbs capacity.

- 2. Add Detergent: Add the appropriate amount of detergent to the dispenser.
- 3. **Select Program:** Use the "Program" button on the control panel to choose one of the 10 available washing programs (e.g., Standard, Quick Wash, Heavy Duty).
- 4. **Select Water Level:** Use the "Water Level" button to select the desired water level (High, Middle, Low, Minimum) based on your laundry load.
- 5. **Start Cycle:** Press the "Start/Pause" button to begin the washing cycle. The machine will automatically fill with water and proceed through the selected program.
- 6. **Child Lock:** To activate the child lock, press and hold the "Child Lock" button for a few seconds. This will lock all control panel buttons. Repeat to deactivate.



Figure 5.1: The 2-in-1 compact design for washing and spinning.

5.2 Automatic Imbalance Adjustment

The washing machine is equipped with an automatic imbalance adjustment system. If the laundry load becomes unbalanced during the spin cycle, the machine will detect this and attempt to redistribute the load to reduce vibration and noise, ensuring stable operation.



Figure 5.2: Automatic Balance Adjustment for safety and noise reduction.

6. MAINTENANCE

6.1 Cleaning the Built-in Filter

Regularly clean the built-in filter to remove lint and debris, ensuring optimal drainage and preventing clogs. The filter is designed for easy removal and cleaning.

6.2 Tub Clean Program

Utilize the "Tub Clean" program periodically to clean the inner tub and prevent the buildup of detergent residue and odors. Refer to the control panel section for program selection.

7. TROUBLESHOOTING

If you encounter issues with your washing machine, please refer to the following common solutions before contacting customer support:

Problem	Possible Cause	Solution
Machine does not start	Power cord not plugged in; Lid not closed properly; Child lock activated.	Ensure power cord is securely plugged in; Close the lid completely; Deactivate child lock.
No water intake	Water tap closed; Water inlet hose kinked or blocked.	Open water tap; Straighten water inlet hose; Check for blockages.
Water not draining	Drain hose kinked or blocked; Drain filter clogged.	Straighten drain hose; Clean the built-in filter.
Excessive vibration/noise	Machine not level; Laundry load unbalanced.	Adjust leveling feet to ensure stability; Redistribute laundry evenly.

8. SPECIFICATIONS

Feature	Detail
Brand	Qhou
Model Number	KRIB-XQB201A-GREY6
Color	Gold
Capacity	15.6 Pounds
Product Dimensions (D x W x H)	20 x 20 x 34 inches
Item Weight	43 Pounds
Rated Voltage	110-120V/60Hz
Rated Power	260W
Hydraulic Pressure	0.03-0.78Mpa
Washing Noise Level	59 dB
Spinning Noise Level	69 dB
Waterproof Class	IPX4
Material	Polyimide
Installation Method	Freestanding

Feature	Detail
Controls Type	Push Button
Included Components	Drain Hose

9. WARRANTY AND SUPPORT

The Qhou KRIB-XQB201A-GREY6 Full Automatic Washing Machine comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions not covered in this manual, please contact Qhou customer service. Please have your model number and purchase information ready when contacting support.

Documents - Qhou - KRIB-XQB201A-GREY6



KRIB-XQB201A-GREY6 Automatic Washing Machine User Guide

A comprehensive user guide for the KRIB-XQB201A-GREY6 Automatic Washing Machine, covering control panel instructions, program selection, common faults, and error codes.

lang:en score:38 filesize: 3.74 M page_count: 1 document date: 2023-10-17



[pdf] User Manual Installation Guide Instructions Guide

1 Administrator User Manual Qhou KRIB XQB201A GREY6 Full Automatic Washing Machine Gold C1beN HxnYL m media amazon images I |||

Warning: This appliance is not intended for use by persons including children whose physical, sensory or mental capabilities may be different or reduced, or who lack experience or knowledge, unless such persons receive supervision or training to operate the appliance by a person responsible for th...

lang:en score:37 filesize: 5.03 M page_count: 8 document date: 2023-02-13