

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Yoobure](#) /

› [Yoobure Nightstand with Charging Station and LED Lights, Model B0CD2CFT3D - Instruction Manual](#)

Yoobure B0CD2CFT3D

Yoobure Nightstand with Charging Station and LED Lights

MODEL: B0CD2CFT3D

Introduction

Thank you for choosing the Yoobure Nightstand with Charging Station and LED Lights. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new nightstand. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The Yoobure Nightstand, showcasing its LED lighting, charging station, and fabric drawers.

Safety Information

WARNING: This product requires assembly. Ensure all parts are securely fastened before use. Do not exceed the weight limit of 100 lbs to maintain stability. Keep away from heat sources and liquids to prevent damage. Always use the adjustable foot pads to ensure stability on uneven surfaces.

- Always place the nightstand on a flat, stable surface.
- Do not allow children to climb on or play with the nightstand.
- Ensure all electrical connections are secure and away from water.
- Unplug the charging station from the wall outlet before cleaning or if not in use for extended periods.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Image: An exploded diagram showing all individual parts and hardware included in the package for assembly.

- Top Panel with Integrated Charging Station
- Middle Shelf Panel
- Bottom Frame
- Metal Frame Supports (Left and Right)
- Fabric Drawers (2 units)
- Drawer Handles (2 units)
- LED Light Strip with Controller

- Adjustable Foot Pads (4 units)
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual

Assembly Instructions

Assembly typically requires one person and takes approximately 30-60 minutes. All necessary tools are included.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the 'Package Contents' section and the provided parts diagram to identify each piece.
2. **Assemble the Metal Frame:** Attach the side metal frame supports to the bottom frame using the provided screws. Ensure all connections are finger-tight before fully tightening.
3. **Install Middle Shelf:** Slide the middle shelf panel into the designated grooves or attach it to the frame using screws, depending on the design.
4. **Attach Top Panel:** Secure the top panel, which includes the charging station, to the top of the metal frame using the appropriate screws.
5. **Install Adjustable Foot Pads:** Screw the four adjustable foot pads into the bottom of the metal frame. Adjust them as needed to ensure the nightstand is level.
6. **Assemble Fabric Drawers:** Insert the bottom support panel into each fabric drawer. Attach the drawer handles to the front of each fabric drawer using the small screws. Be careful not to overtighten, especially with fabric material.
7. **Insert Drawers:** Slide the assembled fabric drawers into their respective compartments in the nightstand frame.
8. **Install LED Light Strip:** Carefully peel the adhesive backing from the LED light strip and attach it to the underside of the middle shelf or the designated area. Connect the LED strip to its controller and then to a USB port on the charging station or a separate USB power adapter.
9. **Final Check:** Ensure all screws are tightened, and the nightstand is stable. Plug the power cord of the charging station into a wall outlet.

Note: An assembly video may be available online. Please check the Yoobure official website or product page for additional visual guidance.

Operating Instructions

Charging Station

The integrated charging station provides convenient power access for your electronic devices.



Image: A detailed view of the charging station, highlighting the two USB ports and two AC outlets.

- **AC Outlets:** The nightstand is equipped with two standard 120V/12A AC outlets. Plug in lamps, laptops, or other small appliances.
- **USB Ports:** Two 5V/2A USB ports are available for charging smartphones, tablets, and other USB-powered devices.
- **Power Cord:** The charging station features a 6.5-foot power cord for flexible placement.

To use, simply plug the nightstand's main power cord into a wall outlet. Then, connect your devices to the available AC outlets or USB ports.

LED Lights

The nightstand features an LED light strip with various modes to enhance your room's ambiance.



Image: The nightstand with its LED lights illuminated, alongside illustrations of the remote control and smartphone app for light customization.

- **Control Methods:** The LED lights can be controlled via a remote control or a dedicated smartphone application.
- **Light Modes:** Choose from 22 dynamic modes, 7 static color modes, music sync functionality, and a timing function.
- **Brightness and Color:** Adjust brightness and select from a wide range of RGB colors to suit your preference.

Refer to the separate LED light strip manual (if included) for detailed instructions on pairing the remote or app and customizing light settings.

Maintenance

- **Cleaning:** Wipe the wooden and metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. For fabric drawers, spot clean with a mild detergent and allow to air dry.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Tightening:** Periodically check and tighten all screws to ensure the nightstand remains stable.
- **Electrical Components:** Keep the charging station and LED lights free from dust and debris. Do not attempt to disassemble or repair electrical components yourself.

Troubleshooting

- **Charging Station Not Working:**
 - Ensure the nightstand's power cord is securely plugged into a functional wall outlet.
 - Check if the wall outlet itself is receiving power (test with another device).
 - Verify that your device's charging cable is properly connected and functional.
- **LED Lights Not Turning On/Responding:**
 - Ensure the LED light strip is properly connected to its controller and a power source (e.g., a USB port on the charging station).
 - Check the batteries in the remote control, if applicable.
 - If using the app, ensure Bluetooth is enabled on your device and the app is correctly paired with the LED controller.
 - Try unplugging and re-plugging the LED light strip's power connection.

- **Nightstand is Wobbly:**

- Adjust the foot pads at the bottom of the nightstand to level it on uneven surfaces.
- Check and tighten all assembly screws.

If you encounter issues not listed here or require further assistance, please contact Yoobure customer support.

Specifications

Feature	Specification
Brand	Yoobure
Model	B0CD2CFT3D
Product Dimensions (D x W x H)	11.81" x 15.75" x 23.62"
Maximum Weight Recommendation	100 Pounds
Color	Black
Frame Material Type	Metal
Top Material Type	Engineered Wood
Drawer Material	Fabric
Number of Drawers	2
Number of Shelves	1 (open shelf)
AC Outlets	2 (120V/12A)
USB Ports	2 (5V/2A)
Power Cord Length	6.5 feet
LED Light Features	22 Dynamic Modes, 7 Static Modes, Music Sync, Timing Function
Assembly Recommendation	1 person, tools included

Warranty and Support

The Yoobure Nightstand comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims, technical support, or any questions regarding your product, please contact the Yoobure customer service team. Our support team aims to assist within 12 hours.

Contact Information: Please refer to the contact details provided on your purchase receipt or the official Yoobure website.

