

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Panasonic](#) /
- › [Panasonic TX-65MXW834 65-inch 4K Ultra HD LED Smart TV User Manual](#)

Panasonic TX-65MXW834

Panasonic TX-65MXW834 65-inch 4K Ultra HD LED Smart TV

User Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Panasonic TX-65MXW834 65-inch 4K Ultra HD LED Smart TV. Please read this manual thoroughly before using the product and retain it for future reference. This television integrates advanced display technologies, including HDR Bright Panel Plus and the HXC Processor, for stunning visuals. It also features the Fire TV operating system for seamless access to streaming services and smart functionalities.



SAFETY INFORMATION

Always adhere to the following safety precautions to prevent electric shock, fire, damage, or injury:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing. Refer all servicing to qualified personnel.
- Ensure proper ventilation; do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Unplug the TV from the power outlet during lightning storms or when unused for long periods.
- Keep batteries away from children and dispose of them properly.

WHAT'S IN THE BOX

Verify that all components are present before proceeding with the setup:

- Panasonic TX-65MXW834 65-inch Smart TV
- Remote Control
- AAA Batteries (2x) for Remote Control
- Power Cable
- TV Stand Feet (2x) and Screws
- User Manual (this document)
- Quick Start Guide

SETUP

1. Attaching the TV Stand

Carefully place the TV screen-down on a soft, clean surface. Align the stand feet with the designated slots on the bottom of the TV and secure them with the provided screws. Ensure the stand is firmly attached before placing the TV upright.




Figure 2: TV dimensions and stand installation guide.

2. Connecting Peripherals

Connect your external devices such as cable boxes, gaming consoles, or sound systems to the appropriate ports on the back of the TV. The Panasonic TX-65MXW834 offers a variety of connectivity options:

- **HDMI Ports (4x):** For high-definition video and audio devices. One port supports eARC for enhanced audio return channel.
- **USB Ports (2x):** For connecting USB storage devices.
- **Ethernet (LAN) Port:** For wired internet connection.
- **Digital Audio Output (Optical/Toslink):** For connecting to external audio systems.
- **Antenna/Cable Input:** For connecting an antenna or cable TV.
- **Headphone Jack:** For private listening.
- **CI (Common Interface) Slot:** For conditional access modules.



Figure 3: Rear view of the TV with port layout.

3. Initial Power-On and Network Setup

Plug the power cable into the TV and then into a wall outlet. The TV will power on and guide you through the initial setup process, including language selection, channel scanning, and network connection. You can connect to your home network via Wi-Fi or Ethernet.

For Wi-Fi setup, select your network from the list and enter the password. For Ethernet, simply connect a network cable to the LAN port.



Figure 4: Fire TV user interface during initial setup.

OPERATING YOUR TV

1. Basic Operation

- **Power On/Off:** Press the Power button on the remote control.
- **Input Selection:** Use the "Input" button on the remote to switch between HDMI, TV, and other sources.
- **Volume Control:** Use the Volume Up/Down buttons.

- **Channel Navigation:** Use the Channel Up/Down buttons for broadcast TV.

2. Fire TV Smart Features

Your Panasonic TV comes with integrated Fire TV OS, providing access to a vast library of streaming content and smart applications. Navigate the Fire TV home screen using the remote control to find your favorite movies, TV shows, and apps.



Figure 5: Access popular streaming services through Fire TV.

3. Voice Control with Alexa

The included remote control features a built-in microphone and Alexa button. Press and hold the Alexa button, then speak your command to control the TV, search for content, launch apps, or even control compatible smart home devices.



Figure 6: Using Alexa voice commands with your TV.

You can also integrate your TV with other smart home devices, such as Ring video doorbells, to view live feeds directly on your screen.




Figure 7: Smart home integration example with Ring doorbell.

4. Picture and Sound Settings

Your TV features advanced picture and sound technologies for an immersive viewing experience. Access the settings menu to adjust brightness, contrast, color, and other display options. The TV supports Multi HDR formats including HDR10+, Dolby Vision, and HLG for optimal picture quality.




Figure 8: Multi HDR support for enhanced visuals.

For audio, the TV features high-quality box-bottom speakers and supports Dolby Atmos for rich, immersive sound.

You can also connect external Bluetooth audio devices like headphones or speakers.



Figure 9: Immersive audio experience with Dolby Atmos.



 Bluetooth®



Figure 10: Bluetooth audio connectivity.

5. Optimal Gaming Experience

The TV includes a Game Mode and supports HDMI 2.1 features like HRF/VRR (High Refresh Rate/Variable Refresh Rate) to ensure smooth and responsive gaming without lag.



Figure 11: Enhanced gaming with Game Mode and HDMI 2.1 features.

MAINTENANCE

To ensure the longevity and optimal performance of your TV, follow these maintenance guidelines:

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray liquid directly onto the screen.
- **Casing Cleaning:** Use a soft, dry cloth to wipe the TV casing. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or objects. Regularly clean dust from these areas.
- **Power Cord:** Periodically check the power cord for any damage. If damaged, contact qualified service personnel for replacement.

TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
No Power	Check if the power cable is securely plugged into the TV and the wall outlet. Ensure the outlet has power. Try a different outlet.
No Picture/Sound	Verify the correct input source is selected. Check HDMI/audio cable connections. Restart connected devices.
Remote Control Not Working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Wi-Fi Connection Issues	Restart your router and modem. Re-enter the Wi-Fi password. Move the TV closer to the router or use a wired Ethernet connection.

Problem	Possible Solution
Apps Not Loading/Crashing	Ensure the TV's software is up to date. Clear the app's cache or reinstall the app. Restart the TV.

If the problem persists after trying these solutions, please contact Panasonic customer support.

SPECIFICATIONS

Detailed technical specifications for the Panasonic TX-65MXW834:

Feature	Detail
Model Name	LED TV TX-65MXW834
Screen Technology	LCD
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Dimensions (W x H x D)	145.3 x 91.2 x 31.8 cm (with stand)
Weight	25.8 Kilograms
Connectivity	Bluetooth, Ethernet, HDMI (4x, 1x eARC), WLAN (Wi-Fi)
Supported Internet Services	Netflix, Prime Video, Disney+, YouTube, and more via Fire TV OS
Special Features	Intelligent Voice Recognition (Alexa), HDR Bright Panel Plus, HXC Processor, Multi HDR (HDR10+, Dolby Vision, HLG), Dolby Atmos, Game Mode (HDMI 2.1 HRF/VRR)
Energy Efficiency Class (SDR)	G (110 kWh/1000h)
Energy Efficiency Class (HDR)	G (228 kWh/1000h)

For detailed energy information, refer to the official EU product data sheet:

Produktdatenblatt (DELEGIERTE VERORDNUNG (EU) 2019/2013 DER KOMMISSION)

Parameter		Parameter oder Wert und Genauigkeit	Einheit
1	Name oder Handelsmarke des Lieferanten	Panasonic	
	Adresse des Lieferanten	Panasonic Testing Centre Panasonic Marketing Europe GmbH Winsbergring 15, 22525 Hamburg, Germany	
2	Modellkennung	TX-65MXW834	
3	Energieeffizienzklasse bei StandardDynamikumfang (SDR)	G	
4	Leistungsaufnahme im Ein-Zustand bei Standard-Dynamikumfang (SDR)	110	W
5	Energieeffizienzklasse (HDR)	G	
6	Leistungsaufnahme im Ein-Zustand bei hohem Dynamikumfang (HDR), falls vorhanden	228	W
7	Leistungsaufnahme im Aus-Zustand, falls zutreffend	0	W
8	Leistungsaufnahme im Bereitschaftszustand, falls zutreffend	0,5	W
9	Leistungsaufnahme im vernetzten Bereitschaftsbetrieb, falls zutreffend	2,0	W
10	Art des elektronischen Displays	Fernsehgerät	✓
		Monitor	
		Signage-Display	
		sonstige	
11	Seitenverhältnis	16 : 9	ganze Zahl
12	Bildschirmauflösung (Pixel)	3840 x 2160	Pixel
13	Bildschirmdiagonale	164,0	cm
14	Bildschirmdiagonale	65	Zoll
15	Sichtbare Bildschirmfläche	114,8	dm ²
16	Verwendete Panel-Technologie	LED LCD	
17	Automatische Helligkeitsregelung (ABC) vorhanden	JA	
		NEIN	✓
18	Spracherkennungssensor vorhanden	JA	
		NEIN	✓
19	Anwesenheitssensor vorhanden	JA	
		NEIN	✓
20	Bildwiederholfrequenz(Standard)	60	Hz
21	Mindestens garantierte Software- und Firmware-Aktualisierungen (ab dem Zeitpunkt der Beendigung des Inverkehrbringens)	8	Jahr
22	Mindestens garantierte Verfügbarkeit von Ersatzteilen (ab dem Zeitpunkt der Beendigung des Inverkehrbringens)	8	Jahr
23	Mindestens garantierte Produktunterstützung	8	Jahr
	Mindestlaufzeit der vom Lieferanten angebotenen allgemeinen Garantie	8	Jahr
24	Art der Stromversorgung (Netzteil)	Intern	✓
		extern	
		extern genormt	
25	Externes Netzteil (nicht genormt, und in der Verkaufsverpackung enthalten)		
i			
ii	Eingangsspannung	0	V
iii	Ausgangsspannung	0	V
26	Genormtes externes Netzteil (oder geeignetes Netzteil, falls nicht in der Verkaufsverpackung enthalten)		
i	Normbezeichnung oder Liste	0	
ii	Benötigte Ausgangsspannung	0	V
iii	Benötigte Stromstärke	0	A
iv	Benötigte Stromfrequenz	0	Hz

Figure 12: EU Product Data Sheet.



ENERG



Panasonic

TX-65MXW834




110 kWh/1000h

ABCDEF**G**

HDR

228 kWh/1000h

3840 px



2019/2013

Figure 13: EU Energy Label.

Official EU Product Database Link: <https://eprel.ec.europa.eu/qr/1401868>

WARRANTY AND SUPPORT

Your Panasonic TX-65MXW834 TV comes with a manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions, including the warranty period and coverage details. For technical support, service, or warranty claims, please contact Panasonic customer service. You can find contact information on the official Panasonic website or in the documentation provided with your TV.

Online support and FAQs may also be available on the Panasonic support portal. Always provide your model number (TX-65MXW834) and serial number when contacting support.

© 2023 Panasonic Corporation. All rights reserved.

Model: TX-65MXW834