

HIFIT HFT-PB-026

User Manual for HIFIT 6-Drawer Dresser

Model: HFT-PB-026
Brand: HIFIT

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HIFIT 6-Drawer Dresser. Please read this manual thoroughly before beginning assembly or use to ensure proper function and longevity of your furniture.

IMPORTANT SAFETY INFORMATION

Always follow these safety guidelines to prevent injury or damage to the product.

- **Tip-Over Restraint:** This dresser is equipped with an anti-tipping device. It is crucial to install this device to prevent serious injury from furniture tip-over. Secure the dresser to a wall using the provided hardware.
- **Weight Limits:** Do not overload drawers or the top surface. The top surface supports up to 132 lbs (60 kg).
- **Assembly:** Assembly should be performed by at least two adults. Ensure all parts are present and undamaged before beginning. Do not use power tools unless specifically instructed, as overtightening can damage components.
- **Placement:** Place the dresser on a flat, level surface. Avoid placing it in areas with high humidity or direct sunlight to prevent warping or discoloration.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the dresser.

PARTS LIST

Verify all components are present before assembly. If any parts are missing or damaged, please contact HIFIT customer support.

Dresser Components

Part	Description	Quantity
Top Panel	Main top surface of the dresser.	1
Side Panels	Left and right side frames.	2

Part	Description	Quantity
Back Panel	Rear support panel.	1
Drawer Fronts	Front face of each drawer.	6
Drawer Sides	Side pieces for each drawer.	12
Drawer Backs	Rear piece for each drawer.	6
Drawer Bottoms	Base for each drawer.	6
Drawer Slides	Metal rails for smooth drawer operation.	12 pairs
Handles	Black aluminum alloy handles.	6
Anti-tipping Device	Wall anchor strap and hardware.	1 set
Assembly Hardware	Screws, dowels, cam locks, etc.	1 pack

SETUP AND ASSEMBLY

The HIFIT 6-Drawer Dresser requires assembly. Follow these steps carefully. It is recommended to have two people for assembly.

- Unpack and Organize:** Open the packaging and lay out all components on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Identify all parts using the provided parts list.
- Assemble the Main Frame:**
 - Attach the side panels to the base and top frame using the specified hardware (cam locks and dowels). Ensure all connections are secure.
 - Install the back panel into the grooves of the main frame.
- Install Drawer Slides:**
 - Attach the cabinet-side drawer slides to the interior of the dresser frame using screws. Ensure they are level and aligned.
 - Attach the drawer-side slides to the drawer boxes.



With Anti-tripping Device



Image: Detailed view of the dresser's dimensions and the anti-tipping device mechanism. The image highlights the overall width (47.2 inches), depth (17.3 inches), and height (32 inches), along with the dimensions of an individual drawer. A close-up inset shows the metal bracket of the anti-tipping device.

4. Assemble Drawers:

- Connect the drawer sides, front, and back panels. Secure the drawer bottom into the grooves.
- Attach the black aluminum alloy handles to the front of each drawer using the provided screws.



Image: The HIFIT 6-Drawer Dresser with all six drawers pulled open, showcasing their storage capacity. The drawers are filled with various folded clothing items, demonstrating effective organization.

5. **Insert Drawers:** Carefully align the drawer slides and push each assembled drawer into its respective slot until it clicks into place.
6. **Install Anti-tipping Device:**
 - Locate a suitable wall stud behind the dresser.
 - Attach one end of the anti-tipping strap to the back of the dresser using the provided screw.
 - Attach the other end of the strap to the wall stud using the appropriate wall anchor and screw. Ensure the strap is taut.

OPERATING INSTRUCTIONS

Your HIFIT 6-Drawer Dresser is designed for easy and smooth operation.

- **Opening and Closing Drawers:** Gently pull or push the black handles to open and close the drawers. The smooth roller slides ensure effortless movement.

- **Storage Capacity:** The six spacious drawers are ideal for organizing clothing, linens, books, documents, and other household items. The top surface can be used for decorative items, lamps, or even a television (supports up to 132 lbs).
- **Multi-functional Use:** This dresser is versatile and can be used in various rooms, including bedrooms, living rooms, hallways, or home offices.



Image: An illustrative image demonstrating the internal organization of the 6-Drawer Dresser. Icons above the dresser suggest categories like T-shirts, pants, toys, diapers, skirts, scarves, socks, and hats, indicating its suitability as a comprehensive storage organizer.



Image: A top-down view of the Farmhouse Fluted Dresser with multiple drawers open. The drawers contain neatly folded clothing, small boxes, and accessories, highlighting the practical storage solutions.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage.
- **Drawer Slides:** Periodically check the drawer slides for smooth operation. If they become stiff, a small amount of silicone lubricant can be applied.
- **Hardware:** Occasionally check all screws and fasteners to ensure they are tight. Retighten if necessary, but do not overtighten.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions:

Common Issues and Solutions

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned slides, debris in tracks, loose screws.	Check alignment of drawer slides. Clean tracks of any debris. Tighten all screws on slides and drawer boxes. Apply silicone lubricant if needed.
Dresser wobbles or is unstable.	Uneven floor, loose assembly hardware, anti-tipping device not installed.	Ensure the dresser is on a level surface. Adjust furniture levelers if present. Retighten all assembly screws. Install the anti-tipping device securely to a wall.
Gaps between drawers or panels.	Incorrect assembly, loose connections.	Review assembly instructions to ensure all parts are correctly oriented and fully engaged. Tighten all cam locks and screws.
Damage during shipping or assembly.	Manufacturing defect or mishandling.	Contact HIFIT customer support with details and photos of the damage for assistance.

PRODUCT SPECIFICATIONS

- **Brand:** HIFIT
- **Model Name:** 6 Drawer Double Dresser
- **Model Number:** HFT-PB-026
- **Color:** Oak
- **Product Dimensions (D x W x H):** 17.3"D x 47.2"W x 32"H
- **Item Weight:** 103.8 Pounds
- **Mounting Type:** Freestanding (with wall anchor recommended)
- **Room Type:** Living Room, Home Office, Study Room, Bedroom, Hallway, Entryway
- **Special Feature:** Decorative frame, Sturdy, Smooth Roller Slides, Aluminum Alloy Handles, Anti-tipping Device
- **Assembly Required:** Yes
- **Product Care Instructions:** Wipe with Dry Cloth
- **Top Surface Weight Capacity:** Up to 132 lbs (60 kg)



Aluminum Alloy Handles

lightweight & wear-resistant

Smooth Roller Slides

easy to pull out



Sturdy Base

stable type & no
accumulation of dust

Decorative Frame

excellent craftsmanship &
enhancement of stability



Image: A composite image showcasing four distinct features of the dresser: lightweight and wear-resistant aluminum alloy handles, easy-to-pull-out smooth roller slides, a stable and dust-free sturdy base, and the excellent craftsmanship of the decorative fluted frame that enhances stability.

WARRANTY AND SUPPORT

HIFIT is committed to providing quality products. For any questions, missing parts, or issues, please contact our customer support team.

- **Customer Service:** Our post-sale service team is available 24/7 to assist you. Refer to the contact information provided with your purchase or visit the official HIFIT store on Amazon for support.
- **Warranty Information:** Please retain your proof of purchase for any warranty claims. Specific warranty details may vary; refer to the documentation included with your product for comprehensive information.
- **Online Resources:** For additional information and product updates, visit the [HIFIT Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CD2MLSF9>

More documents and user manuals: <https://manuals.plus/>