

YKR-T/011E

# Instruction Manual for Replacement Remote Control

Model: YKR-T/011E

## PRODUCT OVERVIEW

---

This document provides instructions for the replacement remote control, model YKR-T/011E, designed for use with AUX Lorient Air Conditioners. This remote is a compatible replacement and may not offer all functions present on your original equipment manufacturer (OEM) remote control.

The remote control is designed for ease of use and provides essential functions for operating your air conditioning unit.

## SETUP

---

### 1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



**Figure 1:** Back of the remote control, indicating the battery compartment and model number YKR-T/011E.

## 2. Initial Use

This replacement remote control is typically ready for use immediately after battery installation. No complex pairing or programming is usually required. Point the remote directly at your AUX Lorient Air Conditioner unit and press the desired function button.

*Note:* If you experience issues, ensure there are no obstructions between the remote and the air conditioner's receiver. For optimal performance, it is recommended to verify compatibility with your specific air conditioner model, especially if certain functions do not respond as expected.

## OPERATING INSTRUCTIONS

---

Familiarize yourself with the buttons on your remote control. The layout is designed for intuitive operation of your air conditioner.




Figure 2: Front of the remote control, displaying all functional buttons.

### Button Functions:

- **ON/OFF:** Powers the air conditioner unit on or off.
- **COOL:** Activates the cooling mode.
- **HEAT:** Activates the heating mode (if supported by your A/C unit).
- **SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets a timer for the unit to turn on or off.
- **MODE:** Cycles through various operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **+/- (Temperature Adjustment):** Increases or decreases the set temperature.
- **MENU/OK:** Used for navigating menus or confirming selections (functionality may vary based on A/C unit).
- **L/R SWING:** Controls the horizontal swing of the air deflector.
- **U/D SWING:** Controls the vertical swing of the air deflector.

*Important Note:* As a replacement remote, some advanced or specific functions present on your original remote may not be available or fully functional with this unit. This is normal for universal or replacement remote controls.

## Battery Replacement:

Replace batteries when the remote's range decreases or buttons become unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

## Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

## Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and A/C unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the A/C unit.
Some functions do not work.	This is a replacement remote; not all original functions may be supported. Incompatibility with specific A/C unit features.	Verify the remote's compatibility with your specific AUX Lorient Air Conditioner model. Understand that some advanced features may not be transferable.
Remote works intermittently.	Low battery power. Infrared sensor on A/C unit is dirty or obstructed.	Replace batteries. Clean the infrared sensor on your A/C unit.

If problems persist after attempting these solutions, consider contacting the seller or referring to your air conditioner's original manual for further assistance.

## SPECIFICATIONS

<b>Model:</b>	YKR-T/011E
<b>Compatibility:</b>	Suitable for AUX Lorient Air Conditioner (YKR-T/011E series)
<b>Material:</b>	ABS Plastic
<b>Color:</b>	Black or White (shipped randomly)
<b>Power Source:</b>	2 x AAA Batteries (not included)

## WARRANTY AND SUPPORT

Specific warranty information for this replacement remote control is not provided by the manufacturer in the available product details. For any warranty claims or technical support, please refer to the seller or retailer from whom the product was purchased.

It is recommended to retain your purchase receipt as proof of purchase for any potential support inquiries.

© 2023 Generic. All rights reserved.  
This manual is for informational purposes only.